

CDHD2S-PN-RS

Servo Drive

User Manual



Revision History

Document Revision	Date	Remarks
1.0	June 01, 2026	CDHD2S-PN-RS Initial release.

Copyright Notice

2023 Servotronix Motion Control Ltd.Servotronix Motion Control Ltd. All rights reserved.

No part of this work may be reproduced or transmitted in any form or by any means without prior written permission of Servotronix Motion Control Ltd.

Disclaimer

The information in this manual was accurate and reliable at the time of its release. Servotronix Motion Control Ltd.reserves the right to change the specifications of the product described in this manual without notice at any time.

Trademark

ServoStudio2 is the trademark of Servotronix Motion Control Ltd.

Profinet is a registered trademark of PROFIBU and PROFINET International (PI).

Windows is a registered trademark of Microsoft Corporation.

Contact Information

Servotronix Motion Technology Development(Shenzhen)Ltd.

Address: 13B01, Block B, Kelu Building, No. 99 Baoshen Road, Songpingshan Community, Xili Street, Nanshan District, Shenzhen,Guangdong,China

Tel: 400-111-8669

Website: www.servotronix.cn

Technical Support

If you need assistance with the installation and configuration of the CDHD2S drive, contact Servotronix technical support.

Tel: 400-111-8669

Unpacking

The package contains only one CDHD2S drive. Upon arrival, please open the package and remove all packaging materials. Check the product to ensure that there is no visible damage in CDHD2S drive. If damage is found, please inform the carrier immediately.

Contents

1. Introduction	1
1.1 CDHD2S-PN-RS Product Overview	1
1.2 CDHD2S-PN-RS model	2
1.3 Order Information	2
1.4 CDHD2S-PN-RS Product Label	4
1.5 CDHD2S-PN-RS File Package	4
2. Safety and Standards	5
2.1 Safety Symbols	5
2.2 Safety Guide	5
2.2.1 Installation safety	6
2.2.2 Operational safety	7
2.2.3 Maintenance safety	7
2.3 Material Safety Data	8
2.4 Certifications	8
3. Specifications	10
3.1 Dimensions	10
3.2 Electrical and Mechanical Specifications	14
3.3 Control Specifications	22
3.4 Protection Functions and Environmental Specifications	23
3.5 STO/Functional Safety Specification	23
3.6 Communication Specifications	24
3.7 Input/Output Specification	24
3.8 Motor Feedback Specification	25
3.9 Secondary Feedback Specifications	26
4. Drive Setup	27
4.1 Setup Overview	27
4.2 Power Up	27
4.3 Drive Address	27
4.4 Setup Preparation	28
4.4.1 Connector - control board	28
4.4.2 Connector - power board	28
4.4.3 Host system	30
4.4.4 Fieldbus device files	31
4.5 System Wiring	32
4.5.1 CDHD2S-1D5/003 (medium-voltage) system wiring	32
4.5.2 CDHD2S-4D5/006 (medium-voltage) system wiring	33
4.5.3 CDHD2S-008/010/013 (medium-voltage) system wiring	34
4.5.4 CDHD2S-003/006 (high-voltage) system wiring	35
4.5.5 CDHD2S-012 (high-voltage) system wiring	36

4.5.6 CDHD2S-024/030 (high-voltage) system wiring	37
4.5.7 CDHD2S-040 system wiring	38
4.6 Electromagnetic Interference Suppression	39
4.6.1 CE filtering technology	39
4.6.2 Grounding	39
4.6.3 Shielding and connection	40
4.6.4 Input power supply filtering	41
4.6.5 Other electromagnetic interference suppression suggestions	42
4.7 Matters Needing Attention in Electrical System	42
4.7.1 Fuse	42
4.7.2 Leakage current	42
4.8 Mechanical Installation	43
4.8.1 Installation of CDHD2S-PN-RS	43
4.8.2 Installing multiple units	43
4.9 Control Board Connection	44
4.9.1 CDHD2S-PN-RS control board pins	45
4.9.2 CDHD2S-PN-RS panel wiring diagram	47
4.9.3 RS232 serial communication - C7	48
4.9.4 PROFINET - C5 and C6	48
4.9.5 Daisy chain and gantry communication - C8	48
4.9.6 Controller interface - C2	48
4.9.7 Machine interface - C3	55
4.9.8 Motor brake wiring	56
4.9.9 Secondary feedback wiring	58
4.9.10 Motor feedback interface - C4	59
4.9.11 Motor feedback wiring	59
4.9.12 Gantry system wiring	70
4.10 Power Board Connection	71
4.10.1 CDHD2S-1D5/003 (medium-voltage) power board pin assignment	72
4.10.2 CDHD2S-4D5/006 (medium-voltage) power board pin assignment	73
4.10.3 CDHD2S-008/010/013(medium-voltage)power board pin assignment	74
4.10.4 CDHD2S-003/006 (high-voltage) power board pin assignment	75
4.10.5 CDHD2S-012 (high-voltage) power board pin assignment	76
4.10.6 CDHD2S-040 (high-voltage) power board pin assignment	77
4.10.7 CDHD2S-040 (high-voltage) power board pin assignment	78
4.10.8 STO-P1	79
4.10.9 Motor power - P2, P4	80
4.10.10 Regenerative Resistors - P3, P5	80
4.10.11 AC input - bus power and logic power - P3, P4, P5	81
4.11 Regeneration	82

4.11.1 Overview of regenerative energy	82
4.11.2 Calculation of regenerative resistance	83
4.11.3 Regenerative resistor overload protection	87
4.11.4 Regenerative resistor parameters	87
4.12 Firmware Update	88
4.12.1 Firmware update preparation	88
4.12.2 Firmware update options	88
4.12.3 Updating firmware via serial connection	89
4.12.4 Restoration operation after firmware update	90
4.12.5 Ember mode	90
5. Motor Setup	92
5.1 Motor Setup Wizard	92
5.2 Drive Identification	96
5.3 Motor Installation	97
5.4 Motor Initialization	97
5.5 Current limit	98
5.6 Velocity limit	98
5.7 Position limit	98
5.8 Motor Direction	99
5.9 New Motor Wizard	99
6. Application Setup	103
6.1 Parameters	103
6.1.1 Configuration of parameters	103
6.1.2 Management of parameters - drive memory	103
6.2 Application Setup Wizard	104
6.3 Communication	111
6.3.1 Serial baud rate	112
6.4 Power Rating	113
6.5 Feedback	113
6.5.1 Incremental encoder	114
6.5.2 Sine encoder	116
6.5.3 sensAR absolute magnetic encoder	116
6.5.4 BiSS-C interface	117
6.5.5 EnDat2.x bidirectional interface	117
6.5.6 Encoder analog output	118
6.5.7 Resolver*	118
6.5.8 Calibration of resolver* and sine encoder	119
6.6 Secondary feedback	126
6.6.1 Overview of secondary feedback (dual loop control)	126
6.6.2 Secondary feedback device	127

6.6.3 Secondary feedback bus	127
6.6.4 Secondary feedback unit	127
6.6.5 Secondary feedback parameters	129
6.7 Motor Unit	130
6.8 Foldback current	131
6.9 Digital Input	131
6.10 Digital output	132
6.11 Digital Output Control Using Comparison Matching (PCOM)	132
6.11.1 PCOM fixed cycle configuration	133
6.11.2 PCOM table configuration	134
6.12 Analog input	136
6.12.1 Analog input 1	136
6.12.2 Analog input 2	136
6.12.3 Using analog input as velocity command and current limit	137
6.13 Analog output	138
6.14 Disabled Mode	138
6.14.1 Active disable	139
6.14.2 Dynamic braking	142
6.15 Motor Brake Control Via Relay	144
6.16 Motor temperature sensor	145
6.17 Error Correction	146
6.17.1 Overview of error correction	146
6.17.2 Error correction table - example	146
6.17.3 Error correction function of CDHD2S-PN-RS	147
6.17.4 Error correction parameters and commands	148
6.17.5 Error correction feedback unit	148
6.17.6 Error correction settings	149
6.18 Gantry System	156
6.18.1 Gantry system overview	156
6.18.2 Gantry type	156
6.18.3 Gantry control mode	159
6.18.4 Gantry operation mode	159
6.18.5 Gantry parameters and commands	160
6.18.6 Gantry setup	161
6.19 Homing	163
6.19.1 Index homing and motor resolver*	163
6.19.2 Index homing and single/multi-turn encoder	164
6.19.3 Switch positive edge homing	164
6.19.4 Gantry system homing	164
7. Operations	166

7.1Power on the drive	166
7.2Drive Operation Mode	166
7.3Current Operation	167
7.3.1 Serial current operation	167
7.3.2 Analog current operation	167
7.3.3 Current control	167
7.4Velocity Operation	167
7.4.1 Serial velocity operation	167
7.4.2 Analog velocity operation	168
7.4.3 Velocity control	168
7.5Position Operation	172
7.5.1 Serial position operation	172
7.5.2 Position control	174
7.6Gearing/Pulse Train Operation	176
7.6.1 Pulse and direction	177
7.6.2 CW/CCW (up/down) counting	180
7.6.3 Encoder follower (master/slave)	180
8. Turning	181
8.1CDHD2S-PN-RS HD Controller	181
8.2CDHD2S-PN-RS HD Controller Autotuning	182
8.3Drive-based autotuning	182
8.3.1 Drive-based autotuning - fast	183
8.3.2 Drive-based autotuning - advanced	183
8.4PC-based Autotuning	191
8.5Summary of Autotuning Parameters	194
8.6Record and evaluate performance	194
8.6.1 Diagnosis	194
8.6.2 Recording data in ServoStudio2	195
8.6.3 Recording data in the terminal	197
8.6.4 Evaluate PTPVCMD	198
8.6.5 Evaluation of ICMD and/or PE oscillation	199
8.7Current Command Low Pass Filter	200
8.8Gear filter	202
8.9Moving Smoothing Filter	203
8.10Notch filter	204
8.11Anti-vibration Filter	204
8.12Gain - Manual Tuning	209
8.13Flexible compensation tuning	212
8.14Dual feedback position control loop debugging	213
8.15Gantry Tuning	215

8.16	Tuning Questions - Q&A	219
9.	PROFINET settings	221
9.1	Hardware Wiring	221
9.2	Drive Settings	222
9.2.2	Drive Command Interface Mode Settings	222
9.2.3	Drive IP and Device Name Settings	222
9.3	Application example of CDHD2S-PN-RS with Siemens S7-1500	225
9.3.1	Install GSD Files	225
9.3.2	Packet 111 Configuration and Application (RT)	227
9.3.3	Packet 112 Configuration and Application (RT)	233
9.3.4	Packet 105 Configuration and Application (IRT)	235
9.3.5	Packet 105 Configuration and Application (IRT)	238
9.3.6	Packet 105 +750/910 Configuration	251
9.3.7	Packet 105 +900 configuration and application	255
9.3.8	Packet 111 +920 Configuration and Application	261
9.4	PROFINET operation	263
9.4.1	PROFINET newsletter	263
9.4.2	Messages	263
9.4.3	I/O Data Signal	266
9.4.4	Control Word Definition	269
9.4.5	Status Word Definition	277
9.4.6	General Features	283
9.4.7	Detailed explanation of the function of message 111	284
9.4.8	Detailed explanation of the function of message 112	293
10.	Functional Safety	295
10.1	Safety Torque Shutdown (STO) Overview	295
10.2	STO Module in Servo Drive	295
10.3	STO system requirements	296
10.4	Use STO	297
10.5	STO Maintenance	299
11.	Trouble shooting	301
11.1	Report Generator	301
11.2	Faults and Warnings	301
11.3	Warning, error and fault messages	302
11.4	Warning messages	302
11.4.1	Error messages - manufacturers only	305
11.4.2	Fault messages	311
	Digital Display	311
11.5	Fieldbus status-LED	315
11.5.1	Status LED - PROFINET	315

11.5.2 Status LED - PROFINET	315
------------------------------------	-----

1. Introduction

1.1 CDHD2S-PN-RS Product Overview

CDHD2S-PN-RS is a high-performance servo drive based on innovative technology and advanced control algorithms. CDHD2S-PN-RS is optimized based on the second generation of this series of servo drives, and has made many improvements and enhancements in terms of functionality and performance.

For CDHD2S-PN-RS drive options, please refer to the ordering information.

The CDHD2S-PN-RS drive using a medium voltage power supply (AC 120/240V) is the medium-voltage model, and the drive using a high voltage power supply (AC 380/400/480V) is the high-voltage model.



CDHD2S-1D5/CDHD2S-003 CDHD2S-4D5/CDHD2S-006 CDHD2S-008/CDHD2S-010/CDHD2S-013
 figure1-1 CDHD2S-PN-RS AC 120/240V (medium-voltage)model



CDHD2S-003/006 CDHD2S-012 CDHD2S-024/030 CDHD2S-040

figure1-2 CDHD2S-PN-RS AC 380/400/480V (High-Voltage)Model

1.2 CDHD2S-PN-RS model

Different models in the CDHD2S-PN-RS servo drive series use different communication methods and protocols. The table below shows the different models and their features.

table1-1 CDHD2S-PN-RS Model - Communication and Protocol

CDHD2S-PN-RS model	Physical layer	Communication protocol	Configuration language
CDHD2S-PN-RS uses the PROFIdrive protocol on PROFINET.	Serial port (USB)	ASCII commands	VarCom
	Simulation	±10V	
	PROFINET	Communication: PROFIdrive on PROFINET	VarCom PROFINET

1.3 Order Information

The ordering options shown below include all drive models in the CDHD2S-PN-RS product line. To inquire about product availability, please contact Servotronics.

Purchase channel: SERVOTRONIX Flagship Store on Taobao.

table1-2 CDHD2S-PN-RS Ordering Plan

			CDHD2S	–	012	4D	PND	–	RS
CDHD2S-PN-RS Servo Drive – HD Series									
Power specifications									
	120/240VAC		380/400/460/480VAC						
	Cont [Arms]	Peak [Arms]	Cont [Arms]	Peak [Arms]					
1D5	1.5	4.5							
003	3	9	3	9					
4D5	4.5	18							
006	6	18	6	18					
008	8	31.8							
010	10	31.8							
012			12	24					
013	13	31.8							
024			24	72					
030			30	90					
040			40	120					
Input power supply									
2A	MV input power supply •Single phase input 120 L-L VAC +10% -15% 50/60 Hz •Single phase input 240 L-L VAC +10% -15% 50/60 Hz •Three phase input 120-240 L-L VAC +10% -15% 50/60 Hz								
4D	HV input power supply •Three phase input 380 L-L VAC +10% -15% 50/60 Hz •Three phase input 400 L-L VAC +10% -15% 50/60 Hz •Three phase input 480 L-L VAC +10% -15% 50/60 Hz 24VDC control board power supply								
Communication interface and motor type					analog input				
PND	PROFINET, USB, Analog Voltage, Pulse Train Ref. . Rotary servo motors, linear motors and DD motors				2				
PNR	PROFINET, USB, Analog Voltage, Pulse Train Ref. . PNR models are only suitable for rotary motors				2				
PNU	Meets US standard UL 61800-5-1. PROFINET, USB, Analog Voltage, Pulse Train Ref, RS232 . Rotary servo motors, linear motors and DD motors. Limited to certain models: CDHD2S-4D52APNU-RS/CDHD2S-0062APNU-RS; PNU models are not available for other power specifications.				2				
Special options									
RS	Rexel Models								
Blank	Blank								

1.4 CDHD2S-PN-RS Product Label

Different models of products may look exactly the same. See the product label on the back panel of the drive for model numbers and specifications. The following picture shows the Profinet model label.

SERVOTRONIX www.servotronix.com
Made in China




Model : CDHD2S-0034DPND-RS

INPUT : 3PH AC 400/480V
2.8A@400V, 2.3A@480V 50/60Hz

OUTPUT : 3PH AC 0~480V
3A 0~599Hz
1.63kVA @400V, 1.77kVA @480V

S / N : 223J-0616314 **Rev :** A01

MAC : 1C8259435DA2 **FW :** 3.0.8P **Enclosure :** IP20

	注意 CAUTION	请务必仔细阅读使用手册，并按其规定操作。 Read manual carefully and follow the safety instructions before use.
	警告 WARNING	断开电源后请等待5分钟再维护，否则有触电危险。 Disconnect the power supply and wait for 5 minutes before maintenance. Risk of electric shock.
	注意 CAUTION	通电后不要触摸散热器，否则有烫伤危险。 Do not touch heatsink when power is ON. Risk of burn.
		必须可靠接地。 Use correct PE earthing technique.

Servotronix Motion Technology Development(Shenzhen)Ltd.
13B01, Block B, Kelu Building, No. 99 Baoshen Road, Songpingshan Community, Xili Street, Nanshan District, Shenzhen, Guangdong, China

SERVOTRONIX www.servotronix.com
Made in China




Model : CDHD2S-0062APNU-RS

INPUT : 1PH/3PH AC 120/240V
10A@1PH, 5.8A@3PH 50/60Hz

OUTPUT : 3PH AC 0~240V
6A 0~599Hz
0.9kVA @120V, 1.5kVA @240V

S / N : 223J-0610062 **Rev :** A01

MAC : 1C8259435DA2 **FW :** 3.0.8P **Enclosure :** IP20

	Dangerous Voltage Tension Dangereuse	Residual voltage. Risk of electric shock. Wait 5 minutes after removing power before servicing. Voltage résiduel. Attendez 5 minutes après mise hors tension avant de manipuler.
	Caution Attention	Read manual & follow the safety instructions Use correct PE earthing technique. Lisez le manuel et suivez les consignes de sécurité
	Hot Surface Surface Chaude	Do not touch heatsink. May cause burns. Ne touchez pas le dissipateur thermique. Risque de brûlure.

CE certification

UL certification

figure1-3 Profinet model label

1.5 CDHD2S-PN-RS File Package

The CDHD2S-PN-RS servo drive's file package contains the following manuals.

The CDHD2S-PN-RS manual can be downloaded from the product page of the Servotronix website (<http://www.servotronix.com/products/cdhd-servo-drives/>).

Note: The files can also be found in the online help package included with the ServoStudio2 software.

2. Safety and Standards

2.1 Safety Symbols

Safety symbols indicate that personal injury or equipment damage is likely to occur if specified precautions and safe operating practices are not followed. The following safety warning symbols are used on the drive and documentation.

table2-1 Safety Warning Symbols

Symbol	Meaning	Description	ISO7000/IEC60417
	Warning Attention	Prompting caution when operating the equipment. Prompting the operator to know the current situation, or the operator needs to take measures to avoid adverse consequences. Invitation à la prudence lors de l'exploitation de l'équipement. Inviter l'opérateur à prendre connaissance de la situation actuelle; l'opérateur doit prendre des mesures pour éviter des conséquences défavorables.	0434
	Dangerous voltage Gefährliche Spannung	Prompting dangerous voltage. Signalisation d'une tension dangereuse.	5036
	Protective grounding mise à la terre de protection	Indicating any terminal, or protective grounding electrode terminal, used for connection to the outer conductor to provide protection in the event of a fault. Signalisation de tout borne ou borne d'électrode de mise à la terre de protection, destinée au raccordement au conducteur extérieur pour assurer la protection en cas de défaut.	5019
	Warning, hot surface Attention: surface chaude	The marked object is hot and you should be careful when touching it. L'objet marqué est chaud; vous devez faire attention en le touchant.	5041

2.2 Safety Guide

The CDHD2S-PN-RS servo drive is used as a component within the machine system.

Machine manufacturers and integrators must ensure personnel safety and machine system integrity.

Machine manufacturers and/or integrators must take into account the intended use of the CDHD2S-PN-RS drive when performing a risk assessment. Based on the results of the assessment, appropriate security measures must be implemented.

CDHD2S-PN-RS drives must be used in compliance with all applicable safety regulations and directives and all technical specifications and requirements.



CDHD2S-PN-RS drives use dangerous voltage. They must be properly grounded.

Les entraînements CDHD2S-PN-RS sont soumis à une tension dangereuse. Ils doivent être correctement reliés à la mise à la terre de protection.



Machine manufacturers and machine owners are responsible for machine operator safety.

Les constructeurs de machines et les propriétaires des machines sont responsables de la sécurité des opérateurs.

The machine owner and machine operator are responsible for ensuring that access to hazardous areas is prohibited while the machine is energized (unless equipped with appropriate functional safety mechanisms).



Le propriétaire de la machine et l'opérateur sont responsables de garantir que l'accès aux zones dangereuses est interdit lorsque la machine est sous tension (sauf si des mécanismes de sécurité fonctionnelle adaptés sont installés).

Only qualified personnel should perform installation, operation, service and maintenance procedures. These qualified personnel must have sufficient technical training and knowledge to anticipate and identify potential hazards that may arise when using the product, modifying settings, and operating the mechanical, electrical, and electronic components of the entire machine system.

All persons performing work on the product must be fully familiar with all applicable standards, directives and accident prevention regulations for performing such work.

2.2.1 Installation safety

Note:

Improper handling of the CDHD2S-PN-RS can cause personal injury and/or equipment damage.

When connecting the CDHD2S-PN-RS to other control devices, be sure to follow two basic guidelines to prevent damage to the drive:

- The CDHD2S-PN-RS must be grounded via the ground wire of the AC mains power supply.
- Any drive controller, PLC or PC connected to the CDHD2S-PN-RS must be connected to the same ground wire as the CDHD2S-PN-RS.



Lors de la connexion du CDHD2S-PN-RS à d'autres appareils de commande, respecter impérativement deux consignes fondamentales pour éviter d'endommager l'entraînement :

- Le CDHD2S-PN-RS doit être relié à la terre par le fil de terre de l'alimentation secteur alternatif.
- Tout contrôleur d'entraînement, automate programmable (API) ou ordinateur personnel connecté au CDHD2S-PN-RS doit être raccordé au même fil de terre que ce dernier.

- Before installing or commissioning CDHD2S-PN-RS, review all relevant product information.
- Install the machine in accordance with product specifications and installation instructions.
- All system components must be grounded. Provide electrical safety via a low-resistance ground connection (Category I based on EN/IEC618005-1). The motor shall be connected to the protective earth conductor by a separate earth conductor with a rating no less than that of the motor wire.

- As part of the machine design, the machine manufacturer must prepare a machine hazard analysis and take appropriate measures to ensure that unexpected activities do not cause physical injury and/or equipment damage.
- The drive complies with IP20 (IEC60529 standard) and Type 1 (UL50) requirements; therefore, the machine builder must select a suitable enclosure. The enclosure must meet at least IP54 (IEC60529 standard) and Type 2 (UL50) requirements, be composed of metal or 5VA flammability rated materials, and have no openings on the bottom.
- The leakage current of the protective ground wire is greater than 3.5mA; therefore, in order to comply with the requirements of IEC61800-5-1 and UL508C, double PE connections can be used (one is grounded through the main power ground wire, and the other is connected to the grounded equipment base through the heat sink), or use a copper connecting cable with a cross-sectional area greater than 10mm². Use drive mounting screws and PE coupling screws to meet this requirement.
- The yellow wire with/without one or more green stripes may not be used except for protective grounding.
- Power cables should be rated at least 600V, 75°C.

2.2.2 Operational safety

Note: The machine manufacturer is responsible for equipment safety implementation, testing and certification. The machine manual must clearly state operating and maintenance conditions and safety precautions.

- Perform all equipment operations in accordance with product specifications and installation instructions.
- Equipment manufacturers must provide power disconnect devices in compliance with local regulations.
- During operation, all protective covers and cabinet doors remain closed.
- During operation, this equipment has live parts and hot parts. CDHD2S-PN-RS heat sink temperatures can reach 90°C. Even if the motor is not turning, control and power cables can carry high voltage.
- Machine tool axes subjected to suspended loads or unbalanced loads must be provided with additional mechanical safety blocks (such as motor-controlled brakes) to prevent the load from falling out of control. The CDHD2S-PN-RS drive cannot keep the load suspended when the STO function is activated. If the load is not properly protected, serious injury may occur.

2.2.3 Maintenance safety

Note: Improper handling of the CDHD2S-PN-RS can cause injury and/or equipment damage.

- Before performing maintenance on the CDHD2S-PN-RS (or the machine it drives), please review all relevant product information.

- Perform maintenance procedures in accordance with product maintenance requirements and instructions.
- To avoid electric arc and personal injury and damage to electrical contacts, never disconnect or connect the product with power on.
- After the equipment is powered off, wait at least 5 minutes before touching or disconnecting normally live parts (such as capacitors, switch contacts, screw connections).
- Before touching the device, measure the electrical contacts with a meter. Make sure the DC voltage is below 30V before handling the components.

2.3 Material Safety Data

CDHD2S-PN-RS is marked in accordance with the SJ/T11364, which applies to electronic and electrical products sold within the territory of the People's Republic of China.

The hazardous substance data in the table below complies with China's RoHS2.0: *Restriction of the Use of Certain Hazardous Substances in Electronic and Electrical Equipment* issued on January 21, 2016.



CDHD2S-PN-RS contains specific hazardous substances and can be used safely for 20 years, after which it should be recycled.

table2-2 Hazardous Substances

Part Name	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent chrome (Cr VI)	Polybrominated biphenyls (PBB)	Polybrominated diphenyl ethers (PBDE)
Metal parts	X	O	O	O	O	O
Plastic parts	O	O	O	O	O	O
Electrical parts	X	O	O	O	O	O
Contacts	O	O	O	O	O	O
Cables and accessories	O	O	O	O	O	O

O indicates that the content of the hazardous substance in all homogeneous materials of this part is below the limit requirements specified in GB/T26572.

X indicates that the content of the hazardous substance in at least one homogeneous material of the component exceeds the limit requirements specified in GB/T26572.

2.4 Certifications

CDHD2S-PN-RS(except CDHD2S-4D52APNU-RS and CDHD2S-0062APNU-RS) will be tested and certified according to the following standards.

table2-3 Certification standard

Standard	Directives/Instructions	Certification mark
IEC61800-5-1	Low voltage directive 2014/35/EU Adjustable speed electrical power drive systems	

IEC61800-5-2:2017	Machinery directive 2006/42/EC Adjustable speed electrical power drive systems - safety requirements - functional	
IEC61800-3	Electromagnetic compatibility (EMC) directive 2004/108/E Adjustable speed electrical power drive systems	
IEC61800-3	Electromagnetic compatibility (EMC) directive 2014/30/EU Adjustable speed electrical power drive systems For second environment	
EN50581	European directive 2011/65/EURoHS (Restriction of Hazardous Substances) Declaring compliance with the technical documentation required to comply with substance restriction requirements.	
SJ/T11364	Marking for the restriction of the use of hazardous substances in electronic and electrical products (China RoHS2.0) Hazardous substances in electronic and electrical products; environmentally friendly service life and recyclability.	
EUREACH	Registration, Evaluation, Authorisation and Restriction of Chemicals (EC)1907/2006 The production and use of chemicals and their potential effects on human health and the environment.	
International Electrotechnical Commission (IEC) European Norm (EN) Underwriter Laboratories Inc. (UL) Canadian Standards Association (CSA) European Parliament and Council of European Union		

CDHD2S-4D52APNU-RS and CDHD2S-0062APNU-RS will be tested and certified according to the following standards.

table2-4 Certification standard

UL 61800-5-1	Power Conversion Equipment Open or enclosed equipment that supplies power to control a motor or motors operating at a frequency or voltage different than that of the input supply.	
CSA C22.2 NO. 274-17	Industrial Control Equipment Control and protective devices, and accessory devices, rated at not more than 1500V, for starting, stopping, regulating,controlling, or protecting electric motors, generators, heating apparatus, or other equipment used to control an industrial process that is intended to be installed and used in non-hazardous locations.	
Underwriters Laboratory (UL) Canadian Standards Association (CSA)		

3. Specifications

3.1 Dimensions

Various models of CDHD2S-PN-RS drives are housed in many different enclosures. The appearance dimensions of the enclosure are as shown in the figure below.




figure3-1 CDHD2S-1D5/CDHD2S-003 (medium-voltage) - dimensions (mm)




figure3-2 CDHD2S-4D5/CDHD2S-006 (medium-voltage) - dimensions (mm)




figure3-3 CDHD2S-008/CDHD2S-010/CDHD2S-013 (medium-voltage) - dimensions (mm)




figure3-4 CDHD2S-003/CDHD2S-006 (high-voltage) - dimensions (mm)




figure3-5 CDHD2S-012 (high-voltage) - dimensions (mm)




figure3-6 CDHD2S-024/CDHD2S-030 (high-voltage) - dimensions (mm)




figure3-7 CDHD2S-040 (high-voltage) - dimensions (mm)

3.2 Electrical and Mechanical Specifications

table3-1 Mechanical and electrical specifications-CDHD2S-1D5/CDHD2S-003 (120/240 VAC)

Single phase AC 120/240V	Specification	Medium-voltage CDHD2S-1D5	Medium-voltage CDHD2S-003
Rating			
Input power circuit: L1, L2	Rated voltage (VAC Line-Line) $\pm 10\%$	120/240	120/240
	Line frequency (Hz)	50/60	50/60
	120/240VAC	1Phase	1Phase
	Continuous current (1 phase Arms)	2.5	5
	Line fuse (FWP, or equivalent)	4	6
	Voltage-endurance (primary to ground)	1500VAC (2121VDC)	1500VAC (2121VDC)
Control circuit input power (L1C, L2C)	120 ± 10 or 240 ± 10 VAC	Single phase	Single phase
STO (safety torque shutdown)	STO power supply (DC voltage)	24 $\pm 10\%$	24 $\pm 10\%$
STOFuse(TimeDelay)	120 or 240 VAC (A)	1.5	1.5
Drive output	Continuous output current [Arms]	1.5	3
	Continuous output current (Apeak)	2.12	4.24
	Peak output current (Arms) 2s	4.5	9
	Peak output current (Apeak) 2s	6.3	12.72
	kVA, 120V AC voltage	0.28	0.44
	kVA, 240V AC voltage	0.37	0.74
	PWM frequency (kHz)	16	16
Soft start	Maximum soft-start surge current (A)	7	7
	Maximum charging time (ms)	350	350
Hardware			
Unit weight	kg	0.7	0.75
Connecting hardware	PE grounding screw size/torque	M4/1.35Nm	M4/1.35Nm
Line number	Control circuit (AWG) (under 3 meters)	24-28	24-28
	Main circuit motor circuit (AWG)	18	18
	Main circuit AC input (AWG)	18	18
	PE grounding screw	M4	M4
Installations	Installation of Book		
Net distance	Left and right (mm)	15	15
	Top/bottom (mm)	50	50
Voltage trip			
	Low voltage trip (nominal) (DC voltage)	100	100
	Overvoltage trip (DC voltage)	420	420
Power supply temperature			
Fan	Usually run at a quarter of power; when the temperature exceeds the trigger temperature of the high-speed fan, it works at full power.	No	Yes
	Temperature to trigger high-speed fan (°C)	NA	45 $\pm 5\%$
Power module	Overheating fault regulation (°C) power module	80 $\pm 5\%$	80 $\pm 5\%$
	Overheating fault unregulation (°C) power module	95	95

Single phase AC 120/240V	Specification	Medium-voltage CDHD2S-1D5	Medium-voltage CDHD2S-003
External regenerative resistor (B1+, B2)			
External regenerative resistor requirements (regenerative resistor is not provided with the drive)	Peak current (A)	6.3	12.7
	Minimum resistance (Ω)	64	31.5
	Power rating (W)	System related	System related
Application information	Internal bus capacitance (μ F)	330	660
	VLOW (regenerative circuit off) (DC voltage)	380	380
	VMAX (regenerative circuit on) (DC voltage)	400	400

table3-2 Mechanical and electrical specifications-CDHD2S-4D5/CDHD2S-006 (120/240 VAC)

Single or three phase AC 120/240V	Specification	Medium-voltage CDHD2S-4D5	Medium-voltage CDHD2S-006
Rating			
Input power circuit: L1, L2, L3	Rated voltage (VAC Line-Line) $\pm 10\%$	120/240	120/240
	Line frequency (Hz)	50/60	50/60
	120VAC	1 phase or 3 phase	1 phase or 3 phase
	240VAC	1 phase	1 phase
	Continuous current (1 phase/3 phase, Arms)	8.5/4	10/5.8
	Line fuse (FWP, or equivalent)	10	10
	Voltage-endurance (primary to ground)	1500VAC (2121VDC)	1500VAC (2121VDC)
Control circuit input power (L1C, L2C)	120 ± 10 or 240 $\pm$ VAC	Single phase	Single phase
STO (safety torque shutdown)	STO power supply (DC voltage)	24 $\pm 10\%$	24 $\pm 10\%$
STOFuse(TimeDelay)	120 or 240 VAC (A)	1.5	1.5
Drive output	Continuous output current [Arms]	4.5	6
	Continuous output current (Apeak)	6.63	8.48
	Peak output current (Arms) 2s	18	18
	Peak output current (Apeak) 2s	25.45	25.45
	kVA, 120V AC voltage	0.5	0.7
	kVA, 240V AC voltage	1.1	1.5
	PWM frequency (kHz)	16	16
Soft start	Maximum soft-start surge current (A)	7	7
	Maximum charging time (ms)	250	250
Hardware			
Unit weight	kg	0.97	0.97
Connecting hardware	PE grounding screw size/torque	M4/1.35Nm	M4/1.35Nm
Line number	Control circuit (AWG) (under 3 meters)	24-28	24-28
	Main circuit motor circuit (AWG)	16	16
	Main circuit AC input (AWG)	16	16
	PE grounding screw	M4	M4
Installations	Installation of Book		
Net distance	Left and right (mm)	15	15
	Top/bottom (mm)	50	50
Voltage trip			
	Low voltage trip (nominal) (DC voltage)	100	100
	Overvoltage trip (DC voltage)	420	420
Power supply temperature			

Single or three phase AC 120/240V	Specification	Medium-voltage CDHD2S-4D5	Medium-voltage CDHD2S-006
Fan	Usually run at a quarter of power; when the temperature exceeds the trigger temperature of the high-speed fan, it works at full power. Temperature to trigger high-speed fan (°C)	Yes 45 ± 5%	Yes 45 ± 5%
Power module	Overheating fault regulation (°C) power module Overheating fault unregulation (°C) power module	80 ± 5% 115	80 ± 5% 115
External regenerative resistor(B1+, B2)			
External regenerative resistor requirements (regenerative resistor is not provided with the drive)	Peak current (A) Minimum resistance (Ω) Power rating (W)	25.5 16 System related	25.5 16 System related
Application information	Internal bus capacitance (μF) VLOW (regenerative circuit off) (DC voltage) VMAX (regenerative circuit on) (DC voltage)	940 380 400	940 380 400

table3-3 Mechanical and electrical specifications-CDHD2S-008/CDHD2S-010//CDHD2S-013 (120/240 VAC)

Single or three phase AC 120/240V	Specification	Medium-voltage CDHD2S-008	Medium-voltage CDHD2S-010	Medium-voltage CDHD2S-013
Rating				
Input power circuit: L1, L2, L3	Rated voltage (VAC Line-Line) ± 10%	120/240	120/240	120/240
	Line frequency (Hz)	50/60	50/60	50/60
	120/240VAC	1 phase or 3 phase	1 phase or 3 phase	3 phase
	Continuous current (1 phase/3 phase, Arms)	11/6.5	13.6/8	10
	Line fuse (FWP, or equivalent)	10	10	15
Control circuit input power (L1C, L2C)	Voltage-endurance (primary to ground)	1500VAC (2121VDC)	1500VAC (2121VDC)	1500VAC (2121VDC)
	120 ± 10 or 240 ± VAC	Single phase	Single phase	Single phase
STO (safety torque shutdown)	STO power supply (DC voltage)	24 ± 10%	24 ± 10%	24 ± 10%
STOFuse(TimeDelay)	120 or 240 VAC (A)	1.5	1.5	1.5
Drive output	Continuous output current [Arms]	8	10	13
	Continuous output current (Apeak)	11.31	14.14	18.38
	Peak output current (Arms) 2s	31.8	31.8	31.8
	Peak output current (Apeak) 2s	44.96	44.96	44.96
	kVA, 120V AC voltage	1.1	1.3	1.7
	kVA, 240V AC voltage	1.7	2.2	2.8
	PWM frequency (kHz)	8	8	8
Soft start	Maximum soft-start surge current (A)	15	15	15
	Maximum charging time (ms)	350	350	350
Hardware				
Unit weight	kg	1.15	1.15	1.15

Single or three phase AC 120/240V	Specification	Medium-voltage CDHD2S-008	Medium-voltage CDHD2S-010	Medium-voltage CDHD2S-013
Connecting hardware	PE grounding screw size/torque	M4/1.35Nm	M4/1.35Nm	M4/1.35Nm
Line number	Control circuit (AWG) (under 3 meters)	24-28	24-28	24-28
	Main circuit motor circuit (AWG)	14	14	14
	Main circuit AC input (AWG)	14	14	14
	PE grounding screw	M4	M4	M4
Installations	Installation of Book			
Net distance	Left and right (mm)	15	15	15
	Top/bottom (mm)	50	50	50
Voltage trip				
	Low voltage trip (nominal) (DC voltage)	100	100	100
	Overvoltage trip (DC voltage)	420	420	420
Power supply temperature				
Fan	Usually run at a quarter of power; when the temperature exceeds the trigger temperature of the high-speed fan, it works at full power.	Yes	Yes	Yes
	Temperature to trigger high-speed fan (°C)	45 ± 5%	45 ± 5%	45 ± 5%
Power module	Overheating fault regulation (°C) power module	80 ± 5%	80 ± 5%	80 ± 5%
	Overheating fault unregulation (°C) power module	115	115	115
External regenerative resistor(B1+, B2)				
External regenerative resistor requirements (regenerative resistor is not provided with the drive)	Peak current (A)	40	40	40
	Minimum resistance (Ω)	10	10	10
	Power rating (W)	System related	System related	System related
Application information	Internal bus capacitance (μF)	2110	2110	2110
	VLOW (regenerative circuit off) (DC voltage)	380	380	380
	VMAX (regenerative circuit on) (DC voltage)	400	400	400

table3-4 Mechanical and electrical specifications-CDHD2S-003/CDHD2S-006/CDHD2S-012 (380/480 VAC)

Three phase AC 400/480V	Specification	High-voltage CDHD2S-003	High-voltage CDHD2S-006	High-voltage CDHD2S-012
Rating				
Input power circuit: L1, L2, L3	Rated voltage (VAC Line-Line) ±10%	400/480	400/480	400/480
	Line frequency (Hz)	50/60	50/60	50/60
	380/480VAC	3 Phase	3 Phase	3Phase
	Continuous current (3 phase Arms)	2.8@400V 2.3@480V	5.7@400V 4.6@480V	11.0@400V 9.2@480V

Three phase AC 400/480V	Specification	High-voltage CDHD2S-003	High-voltage CDHD2S-006	High-voltage CDHD2S-012
	Line fuse (FWP, or equivalent)	10	10	50
	Voltage-endurance (primary to ground)	1800VAC (2520VDC)	1800VAC (2520VDC)	1800VAC (2520VDC)
Control circuit input power (P2)	24VDC±10%	24VDC±10% 2Arms	24VDC±10% 2Arms	24VDC±10% 2Arms
STO(safety torque off)	STO power supply (DC voltage)	24VDC±10% STO 1.0Arms	24VDC±10% STO 1.0Arms	24VDC±10% STO 1.0Arms
STO Fuse(Time Delay)	24VDC±10%	1.5	1.5	1.5
Drive output	Continuous output current [Arms]	3	6	12.0
	Continuous output current (Apeak)	4.24	8.48	16.97
	Peak output current (Arms) 2s	9	18	24
	Peak output current (Apeak) 2s	12.72	25.45	33.84
	kVA, 380V AC voltage	1.63	3.11	6.22
	kVA, 480V AC voltage	1.77	3.68	7.36
	PWM frequency (kHz)	8	8	8
Soft start	Maximum soft-start surge current (A)	7	7	9
	Maximum charging time (ms)	1300	1300	1300
Hardware				
Unit weight	kg	2.1	2.1	3.2
Connecting hardware	PE grounding screw size/torque	M4/1.35Nm	M4/1.35Nm	M4/1.35Nm
Line number	Control circuit (AWG) (under 3 meters)	24-28	24-28	24-28
	Main circuit motor circuit (AWG)	12-14	12-14	12-14
	Main circuit AC input (AWG)	12-14	12-14	12-14
	PE grounding screw	M4	M4	M4
Installations	Installation of Book			
Net distance	Left and right (mm)	25	25	25
	Top/bottom (mm)	50	50	50
Voltage trip				
	Low voltage trip (nominal) (DC voltage)	350	350	350
	Overvoltage trip (DC voltage)	800	800	800
Power supply temperature				
Fan	Operates at full power	NO	Yes	Yes
	Temperature to trigger high-speed fan (°C)	NA	50±5%	50±5%
Power module	Overheating fault regulation (°C) power module	80±5%	80±5%	80±5%
	Overheating fault unregulation (°C) power module	115	115	115

Three phase AC 400/480V	Specification	High-voltage CDHD2S-003	High-voltage CDHD2S-006	High-voltage CDHD2S-012
External regenerative resistor (B1+, B2)				
Internal regenerative resistor (B1+, B2)	Peak current (A)	16	16	35
	Resistance (Ω)	48	48	22
	Power	90	90	100
External regenerative resistor requirements (regenerative resistor is not provided with the drive)	Peak current (A)	23	23	35
	Minimum resistance (Ω)	33	33	22
	Power rating (W)	System related	System related	System related
Application information	Internal bus capacitance (μF)	410	410	820
	VLOW (regenerative circuit off) (DC voltage)	750	750	750
	VMAX (regenerative circuit on) (DC voltage)	770	770	770
Brake output				
	Opening voltage (VDC) at 24VDC logic supply and rated current (minimum)	23.5	23.5	23.5
	Leakage current when closing the gate (mA)	<2	<2	<2
	Maximum current (A)	1.3	1.3	1.3
	Short circuit protection	Yes	Yes	Yes
	Maximum opening time (ms)	20	20	20
	Maximum shutdown time (ms)	20	20	20

table3-5 Mechanical and electrical specifications-CDHD2S-024/CDHD2S-030 (400/480 VAC)

Three phase AC 380/480V	Specification	High-voltage CDHD2S-024	High-voltage CDHD2S-030	High-voltage CDHD2S-040
Rating				
Input power circuit: L1, L2, L3	Rated voltage (VAC Line-Line) ±10%	380/480	380/480	380/480
	Line frequency (Hz)	50/60	50/60	50/60
	380/480VAC	3Phase	3Phase	3Phase
	Continuous current (3 phase Arms)	24	30	40
	Line fuse (FWP, or equivalent)	100	125	150
	Voltage-endurance (primary to ground)	1800VAC (2520VDC)	1800VAC (2520VDC)	1800VAC(2520VDC)
Control circuit input power (P2)	24VDC±10%	24VDC±10% 3.5Arms	24VDC±10% 3.5Arms	24VDC±10% 3.5Arms
STO and STO2(safety torque off)	STO power supply (DC voltage)	24VDC±10%	24VDC±10% STO 1.0Arms STO2 0.5Arms	24VDC±10% STO 1.0Arms STO2 0.5Arms
STO Fuse(Time Delay)	24VDC±10% (Arms)	1.5	1.5	3.5
Drive output	Continuous output current [Arms]	24	30	40
	Continuous output current (Apeak)	33.94	42.3	56.56
	Peak output current	72	90	120

	(Arms) 2s			
	Peak output current (A _{peak}) 2s	102	126	169.68
	kVA, 380V AC voltage	12.2	15.1	20
	kVA, 480V AC voltage	15.4	19.0	25
	PWM frequency (kHz)	8	8	4
Soft start	Maximum soft-start surge current (A)	10	10	28
	Maximum charging time (ms)	1500	1500	1500
Hardware				
Unit weight	kg	10.5	10.5	14.5
Connecting hardware	PE grounding screw size/torque	M4/1.35Nm	M4/1.35Nm	M4/1.35Nm
Line number	Control circuit (AWG) (under 3 meters)	24-28	24-28	24-28
	Main circuit motor circuit (AWG)	12	10	10
	Main circuit AC input (AWG)	12	10	10
	PE grounding screw	M4	M4	M4
Installations	Installation of Book			
Net distance	Left and right (mm)	30	30	30
	Top/bottom (mm)	50	50	50
Voltage trip				
	Low voltage trip (nominal) (DC voltage)	350	350	350
	Over-voltage trip (DC voltage)	800	800	800
Power supply temperature				
Fan	Operates at full power	No	No	No
	Temperature to trigger high-speed fan (°C)	NA	NA	NA
Power module	Overheating fault regulation (°C) power module	80±5%	80±5%	80±5%
	Overheating fault unregulation (°C) power module	115	115	115
External regenerative resistor (B1+, B2)				
Internal regenerative resistor (B1+, B2)	Peak current (A)	51.3	51.3	51.3
	Resistance (Ω)	15	15	15
	Power	300	300	800
External regenerative resistor requirements	Peak current (A)	77	100	80
	Minimum resistance (Ω)	10	8.4	9.6
(regenerative resistor is not provided with the drive)	Power rating (W)	System related	System related	System related
Application information	Internal bus capacitance (μF)	1640~1820	1640~2275	2400~2730
	VLOW (regenerative circuit off) (DC voltage)	750	750	750
	VMAX (regenerative circuit on) (DC voltage)	770	770	770
Brake output				

	Opening voltage (VDC) at 24VDC logic supply and rated current (minimum)	23.5	23.5	NA
	Leakage current when closing the gate (mA)	<2	<2	
	Maximum current (A)	<2	<2	
	Short circuit protection	Yes	Yes	
	Maximum opening time (ms)	20	20	
	Maximum shutdown time (ms)	20	20	

3.3 Control Specifications

table3-6 Control specifications

Features		Specification
Motor	Type	DC brushless motor, DC brush motor, voice coil motor, rotary servo motor, linear servo motor
	Automatic motor phasing	Auto-configuration of motor phase, encoder direction and Hall phase sequence.
Operation mode	Optional control mode	Current (torque) control, velocity control, position control, HD control, double-loop control, gantry control
Current (torque) control	Performance	Refresh rate 31.25μs(32KHz), output sine wave
	Step response time	The actual current reaches the command current within two cycles, i.e. 62.5μs
	Control loop	DQ, PI, feedforward
	Reference command*	Analog DC voltage ± 10V, serial port RS232 or USB, Profinet
	Autotuning	Automatic setting of current control loop parameters
Velocity control	Performance	Refresh rate 125μs (8kHz)
	Optional velocity control loop	PI, PDFF, standard pole placement, advanced pole placement, standard pole placement high-frequency, dump active pole placement
	Filter	First order low pass filter, double first order low pass filter, notch filter, high-pass filter, bandpass filter, user-defined polynomial filter
	Reference command	Analog DC voltage ± 10V, serial port RS232 or USB, Profinet
Position control	Performance	Refresh rate 250μs (4kHz)
	Control loop	PID and feedforward
	Reference command*	Electronic gearing pulse and direction, serial port RS232 or USB, Profinet
HD control	Performance	Refresh rate 125μs (8kHz)
	Control loop	Nonlinear control algorithm provides low tracking error, smooth motion with zero or minimum settling time; it includes an adaptive feedforward feature that is applied at the end of motion to deliver zero or minimum settling time.
	Filter	One second order low pass filter, two notch filters, and other filters for handling flexible and resonant systems
	Reference command*	Velocity: Analog DC voltage ± 10V, serial port RS232 or USB, Profinet Position: Pulse, serial port RS232 or USB, Profinet
	Autotuning	Automatic inertia load measurement, automatic setting and optimization of HD control loop parameters.
Gantry control	Control loop	Position control of H-shaped mechanical structure
Brake	Method	Controller braking, dynamic braking, electromechanical braking by the motor.
Seven-segment display	User interface	7-segment LED (green) to display drive status
GUI	User interface	Windows based ServoStudio2 application
	Function	Setup connection, drive information, power information, motor, feedback, input/output selection/configuration, action setting/tuning, fault history/display, setup wizard, expert view
Electronic gearing	Method	User defined input signal ratio
Rotation unit	Position	Velocity, count, degree
	Rate	Rps, rpm, deg/s
	Acceleration/Deceleration	Rps/s, rpm/s, deg/s ²
Linear device	Position	Count, pitch, mm, μm
	Rate	mm/s, μm/s
	Acceleration/Deceleration	mm/s ² , μm ² /s

3.4 Protection Functions and Environmental Specifications

table3-7 Protection functions and environmental specifications - all CDHD2S-PN-RS models

Features	Specification
Protection function	Including but not limited to: low/overvoltage, overcurrent, drive and motor overheating, motor feedback, drive feedback, feedback loss, secondary feedback loss, STO signal not connected, not configured, circuit failure.
Compliance	IEC61800-5-1: Low voltage directive 2006/95/EC. Adjustable speed electrical power drive systems EN61800-5-2:2017: Machinery directive 2006/42/EC. Adjustable speed electrical power drive systems - safety requirements - functional IEC61800-3: Electromagnetic compatibility (EMC) directive 2004/108/E. Adjustable speed electrical power drive systems EN50581: Supporting the basic requirements of the EU RoHS directive 2011/65/EU. Restriction of the Use of Certain Hazardous Substances in Electronic and Electrical Equipment REACH: Regulation (EC) No 1907/2006 Regulations on the chemicals and their safe use.
Environment	Ambient temperature: working temperature 0-45°C, storage temperature 0-70°C Humidity: 10-90% Height: If the height requirements are specified in accordance with the IEC61800-5-1, the CDHD2S-PN-RS should be used below 2,000 meters. Vibration: 1.0g
Working conditions	IP20 rating; IEC60664-1 Degree 2 Please do not use it in places with corrosive or flammable gases, water, oil or chemicals, dust (including iron powder) and salt.

3.5 STO/Functional Safety Specification

Note: STO certification for all CDHD2S-PN-RS models is currently pending.

table3-8 STO electrical specifications

Features	Parameter	
STO power supply	Rated voltage	24V DC voltage
	Voltage class, based on EN61131-2 Type 2 exception (operating voltage is 15V DC instead of 11V DC)	DC voltage 15-30V: STO function is not activated (action allowed) DC voltage 0-5V: STO function is activated (action suppression) DC voltage 5-15V: STO function is undefined and not guaranteed
	Power supply - external	SELV/PELV required
	Power supply - internal	STO jumper required
Cable	Maximum length	30m
	Line number	22-24AWG
Current loss		Under the condition of DC voltage 15V<300mA; under the condition of DC voltage 24V<200mA; under the condition of DC voltage 30V<150mA
Maximum response time	Movement suppression time range	40ms
Maximum duration of OSSD test pulse	Drive ignoring OSSD test pulse	1ms
OSSD test pulse Maximum frequency of	Absolute maximum frequency of 1ms test pulse successfully filtered by the drive	475Hz

3.6 Communication Specifications

table3-9 Communication specifications

Features	Specification
PROFINET	Application rules: IEC 61800-7-203 (Profidrive) IEC 61784-2 (PROFINET)
	Communication method: RT communication, IRT communication
	Communication cycle: 500μs or more
RS232	Based on ASCII, ServoStudio2, HyperTerminal
	Baud rate: 115200bit/s
	Maximum cable length: 10 meters
USB*	Based on ASCII, ServoStudio2, HyperTerminal
	Baud rate: 115200bit/s
	Maximum cable length: 3 meters
Daisy chain loop	Maximum 8 axes. Axis address setting range 0-99
	Maximum cable length: 1 meters

*Some features are not available on all models. Please refer to the *Ordering Information*.

3.7 Input/Output Specification

table3-10 Input/output specifications

Features	Specification	
	CDHD2S-PN-RS model	Profinet
First analog input	Voltage range	Analog DC voltage $\pm 10V$ difference
	Input resolution	16-bit (14-bit for versions with two analog inputs)
	Input impedance	8k Ω (20k Ω when using two analog inputs)
	Bandwidth (-3db)	8kHz
	Accuracy	2%
Second analog input	Voltage range	Analog DC voltage $\pm 10V$ difference
	Input resolution	14-bit
	Input impedance	20k Ω
	Bandwidth (-3db)	8kHz
	Accuracy	2%
Pulse train	Signal	RS422 line receiver
	Maximum input frequency	5MHz
Equivalent encoder output	Signal	AB quadrature output and exponential differential output; RS422 line transmitter
	Maximum output frequency	5MHz
Digital input	Number	8
	Signal	Configurable; optical isolation. Sinking type or sourcing type signal input.
	Voltage	24V (IEC61131)
	Electromagnetic interference protection	Yes
	Maximum input current	6mA
	Transmission delay time	1ms
	Frequency	1kHz
	Number	3
Fast digital input	Signal	Configurable; optical isolation. Sinking type or sourcing type signal input.
	Voltage	24V (IEC61131)
	Electromagnetic interference protection	Yes
	Maximum input current	12.5mA

Features	Specification	
	CDHD2S-PN-RS model	Profinet
	Transmission delay time	1μs
	Frequency	1MHz
Digital output	Number	6
	Signal	Configurable; optical isolation. Open-collector Sinking type or sourcing type signal input.
	Voltage	24V (IEC61131)
	Electromagnetic interference protection	Yes
	Maximum input current	100mA
	Battery overload protection	Yes
	Transmission delay time	1ms
	Number	2
Fast digital input	Signal	Configurable; optical isolation. Open-collector Sinking type or sourcing type signal input.
	Voltage	5 to 24V
	Maximum input current	50mA
	Transmission delay time	1μs
	Signal	Configurable analog output
Analog output	Voltage	±10V
	Resolution	12-bit
	Bandwidth	2kHz
	Maximum load	100kΩ
	Signal	Configurable analog output
Fault output relay	Voltage	24V
	Maximum current	1A

3.8 Motor Feedback Specification

table3-11 Motor feedback specifications - all CDHD2S-PN-RS models

Features	Specification	
Power supply	Drive supply voltage	DC voltage 5V (DC voltage 8V*)
	Maximum supply current from drive to main encoder**	320mA@5V 140mA@8V
Cable	Maximum length	50 meters for sensAR encoder. For other feedback devices, refer to the device specifications.
Incremental encoder	Differential RS422 or RS485	AB quadrature, with or without index, 8-channel Tamagawa (Tamagawa) Encoder
	AB quadrature maximum input frequency	5MHz (before quadrature)
	Minimum index pulse width	1μs
Hall sensor	Signal	Open-collector single-ended type (optional differential type)
Sine encoder	Signal	Sine/cosine differential, with or without Hall
	Signal level	1Vpp@2.5V
	Maximum input frequency	300kHz
	Protocol	EnDat2.1, HIPERFACE
	Input impedance	120Ω
Serial synchronous encoder	Interpolation	Maximum 16384 (14 bits)
	Signal	Synchronous encoder differential data and clock Data only for asynchronous encoders
	Protocol	sensAR, EnDat2.2, BiSS-C (up to 26 bits), Nikon, Tamagawa
Motor temperature	Signal	Thermistor PTC or NTC, user-defined fault threshold

*Some features are not available on all models. Please refer to the *Ordering Information*.

**The maximum combined current of the motor and secondary feedback must not exceed 500mA.

3.9 Secondary Feedback Specifications

table3-12 Secondary feedback specifications - all CDHD2S-PN-RS models

Features	Specifications	
Power supply	Drive supply voltage	5V DC voltage
	Maximum supply current from drive to encoder*	320mA
Incremental encoder	Differential RS422 or RS485	AB quadrature, with or without index
	AB quadrature maximum input frequency	5MHz (before quadrature)
	Minimum index pulse width	1μs
Serial encoder	Signal	Synchronous encoder differential data and clock. Data only for asynchronous encoders.
	Protocol	EnDat2.2, BiSS-C (up to 26 bits)
Analog	Drive supply voltage	5V DC voltage
Function		Dual loop, master/slave unit or handwheel, encoder reader

*The maximum combined current of the motor and secondary feedback must not exceed 500mA.

4. Drive Setup

4.1 Setup Overview

Perform the following steps to install and set up the CDHD2S-PN-RS system.

1. Install CDHD2S-PN-RS.
2. Perform all wiring and cabling connections as required by the application:
Controller input/output and/or mechanical input/output
 - Motor feedback
 - Fieldbus device (if used)
 - CANopen network: Set the 120Ω terminal resistance switch as needed
 - Safe torque shutdown (STO), or bypass using jumpers
 - Motor
 - Regenerative resistor (if required)
 - Motor brake (if required)
 - Medium-voltage type: AC voltage input
 - Low-voltage type: DC voltage input
3. Connect the drive to the host.
4. Power on the drive and the host. Please refer to the *Power Up*.
5. Install ServoStudio2 software. Please refer to the ServoStudio2 manual.
6. If necessary, define the drive communication address. Please refer to the *Drive Addressing*.

4.2 Power Up

After all hardware connections are made, you can power on the drive.

Note: If the logic power and bus AC power are separate, it is recommended to turn on the logic power before turning on the bus AC power.

Check the digital display on the front panel of the CDHD2S-PN-RS.

On initial power-up, the digital display shows that the drive parameters are not saved (e). By configuring the drive and saving the parameters to the drive, this fault can be cleared.

4.3 Drive Address

If only one drive is connected to the host, the drive address setting defaults to 0 and no definition is required.

If multiple drives are connected to the host, each drive must be assigned a unique communication address. Address 0 is not available when configuring a daisy chain loop.

- High-voltage type: VarCom variable ADDR sets the drive address. Then enter SAVE and restart the drive.
- High-voltage type: Set the drive address with the rotary address switch on the front panel. Then restart the drive.

The new address only takes effect after (save and) drive restart.

Set drive address

In an Profinet network, it is not necessary to assign a physical node address (identification number) to the device; the Profinet controller will assign addresses. Two or more drives connected in an Profinet network can be set to the same physical address; the Profinet controller will automatically set the slave ID.

In a PROFINET network, the PROFINET controller distinguishes the device through the MAC address of the drive. The node name and IP address can be configured, but the node address does not take effect.

4.4 Setup Preparation

4.4.1 Connector - control board

For more information about cables, Please refer to the *Cables* section.

table4-1 Connector for controller interface C2

Interface	Item	Part Number
C2	Welding plug connector	11201707000447

table4-2 Connector for machine interface C3

Interface	Item	Part Number
C3	Welding plug connector	11201707000439

table4-3 Connector for controller interface C2 Connector for feedback C4

Interface	Item	Part Number
C4	Welding plug connector	11201707000440

table4-4 Connector for fieldbus communication (Profinet) C5/C6

Interface	Item	Servotronic part number	Part Number
C5/C6	Connector	44915-0011	/

table4-5 Connector for RS232 serial communication C7(medium-voltage)

Interface	Item	Servotronic part number	Part Number
C7	Connector	15EDGKN-3.5-06P	/

table4-6 Connector for RS232 serial communication C8(high-voltage)

Interface	Item	Servotronic part number	Part Number
C8	Connector	NELTRON 4401-10SR 或 COXOC 304A-10PSAAA03	/

4.4.2 Connector - power board

Note: All connectors for power board are provided with the drive.

table4-7 Connector for CDHD2S-003(low-voltage),CDHD2S-1D5/003(medium-voltage)

Interface	Function	Manufacturer part number	Servotronic part number
P1	STO	15EDGKNGB-4P4-GSn-3.5 wire diameter: 16-28AWG	11201707002095

P2	Motor phase line interface	SC-T300B-4P4-BKAu-5 wire diameter: 18AWG	11201707001995
P3	AC power input and regenerative resistor interface	SC-T300B-6P6-BKAu-5 wire diameter: 18AWG	11201707001996

table4-8 Connector for CDHD2S-4D5/006 (medium-voltage)

Interface	Function	Manufacturer part number	Servotronics part number
P1	STO	15EDGKNGB-4P4-GSn-3.5 wire diameter: 16-28AWG	11201707002095
P2	Motor phase line interface	SC-T300B-4P4-BKAu-5 wire diameter: 16AWG	11201707001995
P3	AC power input and regenerative resistor interface	SC-T300B-7P7-BKAu-5 wire diameter: 16AWG	11201707001997

table4-9 Connector for CDHD2S-008/010/013 (medium-voltage)

Interface	Function	Manufacturer part number	Servotronics part number
P1	STO	15EDGKNGB-4P4-GSn-3.5 wire diameter: 16-28AWG	11201707002095
P2	Motor phase line interface	F9A-4P4-BKAu-7.5 wire diameter: 14AWG	11201707002295
P3	AC power input and regenerative resistor interface	F9A-7P7-BKAu-7.5 wire diameter: 14AWG	11201707002275

table4-10 Connector for CDHD2S-003/006 (high-voltage)

Interface	Function	Manufacturer part number	Servotronics part number
P1	STO	15EDGKNGB-4P4-GSn-3.5 wire diameter: 16-28AWG	11201707002095
P2	24V logic power input	15EDGKNM-2P2-GSn-3.5 wire diameter: 16-28AWG	11201707001436
P3	AC power input and regenerative resistor interface	5EDGKDG-6P6-GSn-7.62-UL wire diameter: 12-14AWG	11201707002355
P4	Motor brake	RoHS SPCB-2P2-GSn-7.62 wire diameter: 14-17AWG	11201707000304
P5	Motor phase line interface	5EDGKDG-3P3-GSn-7.62-UL wire diameter: 12-14AWG	11201707002335

table4-11 Connector for CDHD2S-012 (high-voltage)

Interface	Function	Manufacturer part number	Servotronics part number
P1	STO	15EDGKNM-4P4-GSn-3.5 wire diameter: 16-28AWG	11201707001435
P2	24V logic power input	15EDGKNM-2P2-GSn-3.5 wire diameter: 16-28AWG	11201707001436
P3	AC power input and regenerative resistor interface	5EDGKDG-6P6-GSn-7.62-UL wire diameter: 12-14AWG	11201707002355
P4	Motor brake	RoHS SPCB-2P2-GSn-7.62 wire diameter: 14-17AWG	11201707000304
P5	Motor phase line interface	5EDGKDG-3P3-GSn-7.62-UL wire diameter: 12-14AWG	11201707002335

table4-12 Connector for CDHD2S-024 (high-voltage)/CDHD2S-030 (high-voltage)

Interface	Function	Manufacturer part number	Servotronics part number
P1	STO	15EDGKNM-4P4-GSn-3.5 wire diameter: 16-28AWG	11201707001435
P2	STO2	15EDGKNM-4P4-GSn-3.5 wire diameter: 16-28AWG	11201707001435
P3	24V logic power input	15EDGKNM-2P2-GSn-3.5 wire diameter: 24-28AWG	11201707001436
P4	Motor brake	RoHS SPCB-2P2-GSn-7.62 wire diameter: 14-17AWG	11201707000304
P5	AC power input and regenerative resistor interface	5EDGKDG-6P6-GSn-7.62-UL wire diameter: 10-12AWG	11201707002355
P6	Motor phase line interface	5EDGKDG-3P3-GSn-7.62-UL wire diameter: 10-12AWG	11201707002335

table4-13 Connector for CDHD2S-040(high-voltage)

Interface	Function	Manufacturer part number	Servotronics part number
P1	STO	15EDGKNM-4P4-GSn-3.5 wire diameter: 16-28AWG	11201707001435
P2	STO2	15EDGKNM-4P4-GSn-3.5 wire diameter: 16-28AWG	11201707001435
P3	24V logic power input	15EDGKNM-2P2-GSn-3.5 wire diameter: 24-28AWG	11201707001436
P4	Motor brake	RoHS SPCB-2P2-GSn-7.62 wire diameter: 14-17AWG	11201707000304
P5	AC power input and regenerative resistor interface	5EDGKDG-6P6-GSn-7.62-UL wire diameter: 8AWG	11201707002355
P6	Motor phase line interface	F6AKHM-3P3-GSn-10.16 wire diameter: 6-8AWG	11201707000002

4.4.3 Host system

The following computer systems and software are required:

- 2GHzCPU
- 1GBRAM
- 1000MB of free hard drive space (after installing .net4)
- Communication interface to the drive; one of the following:
 - USB port
 - USB port and USB-to-RS232 adapter (with ferrite beads)
 - RS232 port
- Operating system: Windows7, Windows8, Windows10, 32-bit or 64-bit.
- For ServoStudio2, the recommended screen resolution is 1280x800; the minimum resolution is 1024x800.
- It is recommended to set your Windows monitor to small - 100% (default).
- Net4 (please refer to the .NET Framework System Requirements for details). If .NET4 is not installed on your computer, ServoStudio2 will guide you through the installation but will not install it automatically.
- ServoStudio2, a graphical software interface for configuring and testing the drive. Download from the Servotronics website or contact technical support.

Please refer to *Software Installation* in the ServoStudio2 manual.

Note: ServoStudio2 provides compatibility with CDHD2S-PN-RS firmware version 2.0 and above.

Install ServoStudio2

1. Download the ServoStudio2 software installation file from the Servotronics website or contact technical support.
2. Install ServoStudio2 software on the host computer.
3. After installation is complete, launch ServoStudio2 from the Windows Start menu or from the shortcut on the desktop.

If an error appears when installing software and the system cannot find the file specified, please do the following:

- Copy the installation file to the computer hard disk.
- Right-click the installation file and select "Run as administrator."

Install USB device driver of CDHD2S-PN-RS.

The first time you connect a drive to a host through a USB port, Windows may display the New Hardware Discovery wizard, or a new driver will be added to Windows Device Manager with an error or warning symbol.

1. If Windows activates the "New Hardware" wizard, press "Skip getting drives from the network" when this prompt appears. Open Windows Device Manager.
2. In the Ports or Universal Serial Bus Controllers section, find the device marked "Unknown".
3. Right-click on the unknown device and select "Update Driver".
4. Select "Browse my computer" and browse to the following location:
C:\ProgramFiles(x86)\Servotronics\ServoStudio2\Drivers\
5. Make sure the "Include subfolders" option is checked, then click "Next."
6. When the Windows prompt appears, click "Install."

Note: The USB driver has two layers, and you may need to repeat the "Update Driver" procedure again.
CDHD2S-PN-RS USB drives are digitally signed.

4.4.4 Fieldbus device files

- EDS file of CDHD2S-PN-RS on the host computer or PLC controller (if CAN protocol is used). Download from the Servotronics website or contact technical support.
- XML file of CDHD2S-PN-RS on the host or PLC controller (if Profinet protocol is used). Download from the Servotronics website or contact technical support.
- GSD file of CDHD2S-PN-RS on the host computer or PLC controller (if PROFINET protocol is used). Download from the Servotronics website or contact technical support.

4.5 System Wiring

4.5.1 CDHD2S-1D5/003 (medium-voltage) system wiring

CDHD2S




figure4-1 CDHD2S-1D5/CDHD2S-003 120-240VAC (medium-voltage) PN model system wiring

4.5.2 CDHD2S-4D5/006 (medium-voltage) system wiring

CDHD2S




figure4-2 CDHD2S-4D5/CDHD2S-006 120-240VAC(medium-voltage) PN model system wiring

4.5.3 CDHD2S-008/010/013 (medium-voltage) system wiring

CDHD2S




figure4-3 CDHD2S-008/CDHD2S-010/CDHD2S-013 120-240VAC (medium-voltage) PN model system wiring

4.5.4 CDHD2S-003/006 (high-voltage) system wiring




figure4-4 CDHD2S-003/CDHD2S-006 400-480VAC (high-voltage) model system wiring

4.5.5 CDHD2S-012 (high-voltage) system wiring




figure4-5 CDHD2S-012 400-480VAC (high-voltage) model system wiring

4.5.6 CDHD2S-024/030 (high-voltage) system wiring




figure4-6 CDHD2S-024/CDHD2S-030 380-480VAC (high-voltage) model system wiring

4.5.7 CDHD2S-040 system wiring




figure4-7 CDHD2S-040 380-480VAC (high-voltage) model system wiring

4.6 Electromagnetic Interference Suppression

4.6.1 CE filtering technology

The CDHD2S-PN-RS drive complies with the CE standards specified in the *Standard Certification*. Proper bonding, grounding and filtering techniques must be used to meet this standard.

There are usually two types of noise current. The first is conductive noise emission through the ground loop. The quality of the system grounding is inversely proportional to the line noise amplitude. These conducted emissions have a common mode characteristic from line to neutral point (or ground). The second is radiation high-frequency noise emission, which is usually line-to-line capacitive coupling and it is specific in nature.

To properly install an EMI filter, the enclosure should have an unpainted metal surface. This leaves more surface area in contact with the filter housing and provides a lower impedance path between that housing and the backplane. In turn, the backplane has a high-frequency ground bus connection to the enclosure or ground.

4.6.2 Grounding

When connecting the CDHD2S-PN-RS to other control devices, be sure to follow two basic guidelines to prevent damage to the drive:

- The CDHD2S-PN-RS must be grounded via the ground wire of the AC mains power supply.
- Any drive controller, PLC or PC connected to the CDHD2S-PN-RS must be connected to the same ground wire as the CDHD2S-PN-RS.




figure4-8 CDHD2S-PN-RS system grounding

System grounding is critical to the operation of the drive system.

The AC input voltage ground wire must be connected to the PE terminal located on the front panel of the CDHD2S-PN-RS. This is good for safety and reduces electromagnetic interference.

The system uses a single point ground (star wiring) to avoid ground loops.

It is strongly recommended to mount the CDHD2S-PN-RS on a metal backplane and provide a high frequency ground to ground the backplane. Electrical connections are provided throughout the entire back of the drive panel. It is recommended to use current-conducting plate such as aluminum or galvanized steel sheet. For painted and other coated metal panels, remove any coating behind the drive. The goal is to provide a low impedance path between the filter, drive, power supply, and ground for high frequency signals that may cause electromagnetic interference. Use flat braided wire or copper busbar for high frequency grounding. When connecting to high frequency ground, use the shortest braided wire possible.

Ensure good connections between cabinet components. Connect the back panel and cabinet door to the cabinet body with multiple conductive braided wires. The grounding connection must not be made by hinges or mounting bolts. Ensure that the cabinet is well grounded with the right grounding system. The grounding lead shall be the same as or

smaller than the main power lead.

The host computer must also be properly grounded.

4.6.3 Shielding and connection




figure4-9 Schematic Diagram of Grounding for Motor Power Cables and Feedback Cables

To minimize noise emissions and maximize drive system immunity, motor and feedback cables must be shielded and properly connected to a ground surface.

The shield must be connected to ground at both ends of the cable. Its purpose is to reduce the impedance between the cable shield and the rear panel.

It is recommended to connect all shielded cables to the rear panel

Motor and feedback shielded cables should be placed as close to the drive as possible. Connect this exposed cable shield to the rear panel using non-insulated metal cable clamp or connector clamp.

It is recommended to use shielded busbars for star shield connection

4.6.4 Input power supply filtering

CDHD2S-PN-RS electronic system components require EMI AC line filtering in the input power lines to meet CE requirements for industrial environments.

Pay attention to the calibration system size. The filter type is determined based on the rated voltage and current values of the system and the phase of the input line (1 phase or 3 phase). One input line filter is available for multi-axis control application.

For the recommended line filter manufacturer name and part number for the CDHD2S-PN-RS, please refer to the *Line Filters*. The use of the input power filter should follow the following guidelines:

- The filter keeps the wires in and out of the power filter separate.
- The filter must be mounted on the same panel as the drive.
- The filter must be installed as close as possible to the drive to prevent noise from capacitive coupling into other signal lines and cables.
- When installing the filter to the panel, remove any paint or material coating. If possible, use unpainted metal backplane.
- The filter is equipped with a ground terminal and must be grounded.
- Filters can produce high leakage currents. The filter must be grounded before connecting the power supply.
- The filter should not be touched for 10 seconds after power is removed.

4.6.5 Other electromagnetic interference suppression suggestions

Power and control cables should be routed separately. The recommended distance is at least 200mm to improve anti-interference. If the input power supply and wires need to cross, make sure they cross at a 90° angle.

Feedback lines may not be extended as this would cause shielding interruption and may interfere with signal processing.

Connect the cable normally. If you need to tap the cable, please use a connector with a metal back shell. Make sure that the two shells are connected along the periphery of the sheath. No part of the wiring should be unshielded. Never tap cables through the terminal strip.

For differential input of analog signals, use a twisted pair shielded signal cable, both ends connecting shield.

4.7 Matters Needing Attention in Electrical System

4.7.1 Fuse

Circuit protection shall comply with the *National Electrical Code* and/or regulations set forth by national, state, provincial and/or local authorities.

- US fuse: RK5, CC, J or class T, AC 600V/200kA, time delay. It must be UL and CSA certified; UR recognition alone is not enough.
- EU fuse: type gRL or gL, 400V/500V, time delay.
- Fuse holder: Standard fuse holder, or finger-safe fuse holder that meets IEC60529. For example:
 - Bussmann: CH series modular fuse holders, fuse size less than 30A, class J, 3-pole: CH30J3.
 - Ferraz: Ultrasonic fuse, fuse size less than 30A, class J, 3-pole: US3J3I.

4.7.2 Leakage current

PE conductor leakage current comes from a combination of equipment and cable leakage current. The leakage current frequency pattern includes multiple frequencies from which the residual current circuit breaker is estimated as 50Hz. Therefore, leakage current cannot be measured with a traditional multimeter.

According to experience, based on the PWM frequency of the output stage, the following assumptions can be made about the leakage current on the cable:

- $I_{leak} = n \times 20\text{mA} + L \times 1\text{mA/m}$, output stage 8kHz PWM frequency
- $I_{leak} = n \times 20\text{mA} + L \times 2\text{mA/m}$, output stage 16kHz PWM frequency

(where I_{leak} = leakage current, n = number of drives, L = motor cable length)

Since the leakage current of PE is greater than 3.5mA, it meets the requirements of doubling PE connection or using connecting cables with cross-sectional area greater than 10mm^2 as stipulated in IEC61800-5-1 standard. This requirement is met using PE terminals and PE connecting screws.

4.8 Mechanical Installation

4.8.1 Installation of CDHD2S-PN-RS

Mount the CDHD2S-PN-RS on a grounded conductive metal panel using the bracket on the back of the CDHD2S-PN-RS. The metal panel must be strong enough. For installation dimensions, please refer to the *Dimensions*.

4.8.2 Installing multiple units

When multiple CDHD2S-PN-RS units are installed side by side in a cabinet or enclosure, it is recommended that the minimum unit spacing is 10mm. The recommended minimum top and bottom clearance for all CDHD2S-PN-RS models is 50mm.

It is important to keep the ambient temperature within the enclosure not exceeding 45°C . If the CDHD2S-PN-RS unit is installed on a backplane, also ensure that the backplane temperature does not exceed 45°C . It is recommended to install a cooling fan at the bottom of the cabinet for optimal circulation.




figure4-10 Installing multiple CDHD2S-PN-RS units in the cabinet

4.9 Control Board Connection

The control board interface varies depending on the specific CDHD2S-PN-RS model. See the table below for details.

table4-14 Controller board interface

CDHD2S-PN-RS model		PN
Function	Interface	
USB serial communication	C1	■
RS232 serial communication	C7	■
Profinet communication	C5+C6	■
Daisy chain communication	C8	■
Controller interface	C2	■
Pulse and direction input		■
Equivalent encoder output		■
Analog input		2
Analog output		1
Digital input	C2 C3	8
Fast digital input		3
Digital output		6
Fast digital input		2
Machine interface	C3	■
Secondary feedback		■
Fault relay		■
Motor feedback interface	C4	■
Sine encoder		■
Motor temperature sensor		■
Motor feedback 8V power supply		■

4.9.1 CDHD2S-PN-RS control board pins

CDHD2S




figure4-11 CDHD2S-PN-RS medium-voltage model control board pin assignment

CDHD25




figure4-12 CDHD25-PN-RS high-voltage model control board pin assignment

4.9.2 CDHD2S-PN-RS panel wiring diagram

CDHD2S




figure4-13 CDHD2S-PN-RS (MV) model panel pin assignment




figure4-14 CDHD2S-PN-RS (HV) model panel pin assignment

4.9.3 RS232 serial communication - C7

During debugging, the drive can be connected to the host through interface C7 (RS232 port). Alternatively you can use interface C1 (USB port).

Note: The CDHD2S-PN-RS USB drive is digitally signed.

4.9.4 PROFINET - C5 and C6

Interfaces C5 and C6 are RJ45 ports used as transmitter and receiver for drives operating on the PROFINET networks. The LEDs on interfaces C5 and C6 indicate the fieldbus status. Please refer to the *Fieldbus Status-LED*.

For detailed information on the installation, configuration and operation of drives used on PROFINET networks, please refer to the *CDHD2S PROFINET Reference Manual*.

An adapter can be used to connect the RJ45 port to the D9 interface. Please refer to the *D9-RJ45 Adapter*.

4.9.5 Daisy chain and gantry communication - C8

The CDHD2S-PN-RS can be addressed and controlled via a daisy chain RS232 line.

In a daisy chain RS232 configuration, all drives must be connected in the daisy chain via interface C8. Each drive must have a unique address so that it can be identified on the network.

The daisy chain drive can be assigned an address from 1 to 99 by setting parameter P0003 from the operation panel or the VarCom variable ADDR.

Address 0 is not available when configuring a daisy chain loop.

4.9.6 Controller interface - C2

Connect digital and analog inputs and outputs according to application requirements.

Unused pins must remain unwired.

The common inputs and common outputs at the controller interface (C2) and machine interface (C3) are connected internally.

The DC voltage 24V power supply and loop can be connected at the controller interface (C2) or the machine interface (C3), but not both.

All digital inputs and digital outputs on all CDHD2S-PN-RS models are optoisolated.

Fast output can only be sink type. All other digital inputs and digital outputs can be connected as source or sink.

If both the fast digital output and the regular digital output are configured as sink type, it is usually possible to use one power supply for all outputs.

It is recommended to use fast output (7 or 8) as the motor brake release signal.

The motor brake requires a separate power supply. If the load is inductive (such as a relay), an external flywheel diode must be added.

table4-15 Controller interface

Pin	Function	Description	Pin	Function	Description
1	Common output		19	Common input	
2	Digital output 1	Optoisolated programmable digital output. Read using OUT1	20	Digital input 2	Optoisolated programmable digital input. Read using IN2
3	Digital input 1	Optoisolated programmable digital input. Read using IN1	21		
4	Equivalent encoder output A-	Equivalent encoder output signal A low (RS422)	22	Equivalent encoder output A+	Equivalent encoder output signal A high (RS422)
5	Equivalent encoder output B-	Equivalent encoder output signal B low (RS422)	23	Equivalent encoder output B+	Equivalent encoder output signal B high (RS422)
6	Equivalent encoder output Z-	Equivalent encoder output index low (RS422)	24	Equivalent encoder output Z+	Equivalent encoder output index high (RS422)
7			25	Grounded	Digital ground
8	Analog input 1+	Differential analog command input high (DC voltage $\pm 10V$)	26	Analog input 1-	Differential analog command input low (DC voltage $\pm 10V$)
9	Direction input +	Direction signal high (RS422), or down counting signal high	27	Direction input -	Direction signal low (RS422), or down counting signal low
	Secondary encoder B+	Secondary encoder input signal B high (RS422)		Secondary encoder B-	Secondary encoder input signal B low (RS422)
10	Grounded	Digital ground	28	Pulse input +	Pulse signal high (RS422), or main encoder signal A high, or up counting signal high
				Secondary encoder A+	Secondary encoder input signal A high (RS422)
11	Pulse input -	Pulse signal low (RS422), or main encoder signal A low, or up counting signal low	29	Grounded	Digital ground

Pin	Function	Description	Pin	Function	Description
	Secondary encoder A-	Secondary encoder input signal A low (RS422)			
12	Fast digital output 8		30	Fast digital output 7	
13	Grounded	Digital ground	31	Digital input 3	Optoisolated programmable digital input. Read using IN3
14	Digital input 4	Optoisolated programmable digital input. Read using IN4	32	Fast digital input 5	Optoisolated programmable fast digital input. Read using IN5
15	Fast digital input 6	Optoisolated programmable fast digital input. Read using IN6	33	Digital output 2	Optoisolated programmable digital output. Read using OUT2
16	Digital output 3	Optoisolated programmable digital output. Read using OUT3	34	Fast digital output 24V loop	
17	Fast digital input 24V		35	Analog input 2-	Second differential analog input low (DC voltage $\pm 10V$)
18	*Analog input 2+	Second differential analog input high (DC voltage $\pm 10V$)	36	Analog output	Analog output; please refer to the digital ground (DC voltage 0-10V)

*Optional; please refer to the *Ordering Information*.

Blank cells indicate unused pins; these pins must remain unwired.

Digital and analog input and output wiring - C2




figure4-15 Digital input wiring - C2




figure4-16 Digital output wiring - C2




figure4-17 Analog input wiring - C




figure4-18 Analog output wiring - C2

Pulse and direction optoisolated wiring - C2

CDHD2S-PN-RS can connect DC voltage 24V single-ended signal PLC to the drive.

This type of signaling requires fast digital input on the CDHD2S-PN-RS controller interface (C2).

For this configuration, CDHD2S-PN-RS inputs 5 and 6 must be set to INMODE17 and 18 respectively. (Applicable/approved in GEARMODE0, 1\2).

- The pulse signal is connected to fast digital input 5 on pin 32.

- The direction signal is connected to fast digital input 6 on pin 15.
- The cable shield on the PLC side can be connected to any available shielded connector.
- The cable shield on the CDHD2S-PN-RS side can be connected to the housing of the 36-pin connector.

Note: The user should provide DC voltage 24V power supply.




figure4-19 Pulse and direction optoisolated input wiring - C2

Pulse and direction optoisolated input wiring - C2

When using the CDHD2 controller interface (C2):

- The pulse signal is received from the controller or PLC on pins 28 and 11.
- The direction signal is received from the controller or PLC on pins 9 and 27.




figure4-20 Pulse and direction optoisolated input wiring - C2




figure4-21 Analog encoder equivalent output wiring - C2

4.9.7 Machine interface - C3

Wire machine inputs and outputs according to your application requirements.

Unused pins must remain unwired.

The common inputs and common outputs on the controller interface (C2) and machine interface (C3) are connected internally.

The DC voltage 24V power supply and loop can be connected at the controller interface (C2) or the machine interface (C3), but not both.

All digital inputs and digital outputs on all CDHD2S-PN-RS models are optoisolated.

Fast output can only be sink type. All other digital inputs and digital outputs can be connected as source or sink.

If both the fast digital output and the regular digital output are configured as sink type, it is usually possible to use one power supply for all outputs.

It is recommended to use fast output (7 or 8) as the motor brake release signal.

The motor brake requires a separate power supply. If the load is inductive (such as a relay), an external flywheel diode must be added.

table4-16 Machine interface - PN mode

Pin	Function	Description	Pin	Function	Description
1	Secondary encoder A+	Secondary encoder input signal A high (RS422)	11	Secondary encoder A-	Secondary encoder input signal A low (RS422)
	Pulse input+	Pulse signal high		Pulse input-	Pulse signal high
2	Secondary encoder B+	Secondary encoder input signal B high (RS422)	12	Secondary encoder B-	Secondary encoder input signal B low (RS422)
	Direction input +	Direction signal high		Direction input -	Direction signal low
3	secondary encoder Z+	Secondary encoder input index high (RS422)	13	secondary encoder Z-	Secondary encoder input index low (RS422)
4	Secondary encoder 5V	Secondary encoder DC voltage 5V power supply	14	Secondary encoder grounding	The 5V DC voltage power supply of the secondary encoder is grounded.
5	Digital input 7	Optoisolated programmable digital input. Read using IN7	15	Digital input 8	Optoisolated programmable digital input. Read using IN8
6	Digital input 9	Optoisolated programmable digital input. Read using IN9	16	Digital input 10	Optoisolated programmable digital input. Read using IN10

Digital input and output wiring - C3




figure4-22 Digital input wiring - C3




figure4-23 Digital output wiring - C3

4.9.8 Motor brake wiring

The CDHD2S-PN-RS medium-voltage does not have enough amperage to activate the motor brake, but the motor brake can be controlled via an external relay. The selection of power supply, relays and diodes depends on the specifications of the motor brake used in the actual application.

You can connect a relay to any digital output on the CDHD2S-PN-RS machine I/F (C3) or controller interface (C2). It is recommended that you connect to the fast digital output connector 7.

The motor brake wiring requirements are as follows:

- Freewheeling diodes: D1 and D2 (for example, PN1N4002)
- Relay: 24V < 100mA
- Relay coil: > 500W
- External power supply: 24V



When using inductive loads (such as motor brakes), be sure to install the freewheeling diode according to the wiring diagram.

When using DC relays to switch inductive loads, such as relay sequence circuits, motor brakes or DC electromagnets, it is important to absorb surges (e.g. with diodes) to protect the contacts; i.e. the digital inputs and outputs of the drive. Switching these inductive loads generates hundreds to thousands of volts of back-EMF, which can severely damage contacts and shorten product life.

Please refer to the *Motor Brake Control via Relays*.




figure4-24 Motor brake wiring CDHD2S-PN-RS (medium-voltage model)

4.9.9 Secondary feedback wiring

The table below shows the most common secondary feedback changes. If you require additional information, or if your motor feedback does not match any of the following, please contact technical support.

Use the "User Motor Pin Number" column in these tables to record the pin number of your specific feedback device for future reference.

Wiring - BiSS-C encoder

table4-17 BiSS-C encoder

Pin Number	Twisted pair cables	User encoder pin number	Signal declarations
1	Twisted pair cables		Serial data+ (SLO+)
11			Serial data- (SLO-)
2	Twisted pair cables		Serial clock+(MA+)
12			Serial clock-(MA-)
4			+5V DC voltage
14			0V DC voltage

Wiring-HEIDENHAIN (EnDat2.x communication only)

table4-18 Feedback wiring - HEIDENHAIN (EnDat2.x communication only)

Pin Number	Twisted pair cables	User encoder pin number	Signal declarations
1	Twisted pair cables		Serial data+
11			Serial data-
2	Twisted pair cables		Serial clock+
12			Serial clock-
4			+5V DC voltage
14			0V DC voltage

Wiring - Incremental encoder AB quadrature, index pulse and Hall

table4-19 Feedback wiring - incremental encoder AB quadrature, index pulse and Hall

Pin Number	Twisted pair cables	User encoder pin number	Signal declarations
1	Twisted pair cables		Incremental encoder A+
11			Incremental encoder A-
2	Twisted pair cables		Incremental encoder B+
12			Incremental encoder B-
3	Twisted pair cables		Incremental encoder Z+
13			Incremental encoder Z-
4			+5V DC voltage
14			0V DC voltage

4.9.10 Motor feedback interface - C4

Connect the motor feedback interface according to the type of feedback device used in the application. For common feedback wiring, please refer to the table in *Motor Feedback Wiring*.

Pins 1, 2, 14 and 15 have dual functions.

Pin 25 of the motor temperature sensor is connected internally to the CDHD2S-PN-RS ground within the drive.

Unused pins must remain unwired.

Note:

- Serial encoder data is bidirectional.
- Serial encoder clock output only.
- The low voltage indication comes directly from the encoder; the drive cannot verify the encoder battery voltage.

table4-20 Motor feedback interface (C4)

Pin	Function	Pin	Function
1	Incremental encoder A+	14	Incremental encoder A-
	SSI encoder data+		SSI encoder data-
2	Incremental encoder B+	15	Incremental encoder B-
	SSI encoder clock+		SSI encoder clock -
3	Incremental encoder Z+	16	Incremental encoder Z-
4	Hall U+	17	Hall U+
5	Hall W+	18	8V power supply
6	/	19*	/
7	/	20*	/
8	/	21*	/
9	Sine encoder sine+	22	Sine encoder sine-
10	Sine encoder cosine+	23	Sine encoder cosine-
11	Encoder feedback power supply	24	Grounded
12	Motor temperature sensor	25	Motor temperature sensor
13	Encoder feedback power supply	26	Shielding

*Not applicable to the current model.

4.9.11 Motor feedback wiring

The table below shows the most common feedback changes. If you require additional information, or if your motor feedback does not match any of the following, please contact technical support.

Use the "User Motor Pin Number" column in these tables to record the pin number of your specific motor for future reference. Use the ServoStudio2 motor setup program and feedback screens to define motor feedback type, resolution and other parameters.

Wiring - sensAR encoder

table4-21 Feedback wiring - sensAR encoder

Pin Number	Twisted pair cables	User motor pin number	Signal declarations
1	Twisted pair cables		Serial data+
14			Serial data-
11			+5V DC voltage
24			0V DC voltage
26			Shielding

Wiring - BiSS-C encoder

table4-22 Table 4-18 Feedback wiring - BiSS-C encoder

Pin Number	Twisted pair cables	User motor pin number	Signal declarations
1	Twisted pair cables		Serial data+ (SLO+)
14			Serial data- (SLO-)
2	Twisted pair cables		Serial clock+ (MA+)
15			Serial clock- (MA-)
11			+5V DC voltage
24			0V DC voltage
26			Shielding

Wiring - Incremental encoder AB quadrature, index pulse and Hall

table4-23 Feedback wiring – incremental encoder AB quadrature, index pulse and Hall

Pin Number	Twisted pair cables	User motor pin number	Signal declarations
1	Twisted pair cables		Incremental encoder A+
14			Incremental encoder A-
2	Twisted pair cables		Incremental encoder B+
15			Incremental encoder B-
3	Twisted pair cables		Incremental encoder Z+
16			Incremental encoder Z-
4			Hall U
17			Hall V
5			Hall W
12	Twisted pair cables		Motor temperature sensor
25			Motor temperature sensor
11			+5V DC voltage
24			0V DC voltage
26			Shielding

Note: If the motor does not support a temperature sensor, do not connect pins 12 and 25.

Wiring – single-ended Hall

table4-24 Feedback wiring – single-ended Hall

Pin Number	Twisted pair cables	User motor pin number	Signal declarations
4			Hall U
17			Hall V
5			Hall W
11			+5V DC voltage
24			0V DC voltage
12	Twisted pair cables		Motor temperature sensor
25			Motor temperature sensor
26			Shielding

Note: If the motor does not support a temperature sensor, do not connect pins 12 and 25.
 Hall is a single-ended signal. To use differential Hall signals, please refer to the related wiring table.

Wiring - Incremental encoder AB quadrature, index pulse and differential Hall

table4-25 Feedback wiring – incremental encoder AB quadrature, index pulse and differential Hall

Pin Number	Twisted pair cables	User motor pin number	Signal declarations
1	Twisted pair cables		Incremental encoder A+
14			Incremental encoder A-
2	Twisted pair cables		Incremental encoder B+
15			Incremental encoder B-
9			Hall U+
22			Hall U-
10			Hall V+
23			Hall V-
3			Hall W+
16			Hall W-
12	Twisted pair cables		Motor temperature sensor
25			Motor temperature sensor
11			+5V DC voltage
24			0V DC voltage
26			Shielding

If the motor does not support a temperature sensor, do not connect pins 12 and 25.

To use differential Hall with AB quadrature and index, connect the Hall to the machine interface as follows: Hall U+ to Machine I/F pin 1, Hall U- to Machine I/F pin 11.

Note:

Hall V+ to machine I/F pin 2, Hall V- to machine I/F pin 12.

Hall W+ to machine I/F pin 3, Hall W- to machine I/F pin 13.

Connect encoders A, B, I and power to the motor feedback connectors.

Each time power is applied, PHASEFIND must be performed.

Wiring - differential Hall only

table4-26 Feedback wiring – differential Hall only

Pin Number	Twisted pair cables	User motor pin number	Signal declarations
9			Hall U+
22			Hall U-
10			Hall V+
23			Hall V-
3			Hall W+
16			Hall W-
12	Twisted pair cables		Motor temperature sensor
25			Motor temperature sensor(GND)
11			+5V DC voltage
24			0V DC voltage
26			Shielding

Wiring – Tamagawa incremental encoder

table4-27 Feedback wiring – Tamagawa incremental encoder

Pin Number	Twisted pair cables	User motor pin number	Signal declarations
1	Twisted pair cables		Incremental encoder A+/Hall U+
14			Incremental encoder A-/Hall U-
2	Twisted pair cables		Incremental encoder B+/Hall V+
15			Incremental encoder B-/Hall V-
3	Twisted pair cables		Incremental encoder Z+/Hall W+
16			Incremental encoder Z-/Hall W-
12	Twisted pair cables		Motor temperature sensor
25			Motor temperature sensor
11			+5V DC voltage
24			0V DC voltage
26			Shielding

If the motor does not support a temperature sensor, do not connect pins 12 and 25.

Incremental encoder with Hall sensor and index pulse.

Note: The signals A, B and Z use the same wiring as the Hall sensors U, V and W. When powered on, the feedback will send Hall readings briefly, and then continuously send A, B and Z signals. Each time power is applied, PHASEFIND must be performed

table4-28 Feedback wiring – sine encoder

Pin Number	Twisted pair cables	User motor pin number	Signal declarations
9	Twisted pair cables		Sine encoder sine+
22			Sine encoder sine-
10	Twisted pair cables		Sine encoder cosine+
23			Sine encoder cosine-
12	Twisted pair cables		Motor temperature sensor
25			Motor temperature sensor
11			+5V DC voltage
24			0V DC voltage
26			Shielding

Note: If the motor does not support a temperature sensor, do not connect pins 12 and 25.
 Each time power is applied, PHASEFIND must be performed.

Wiring - sine encoder with Hall

table4-29 Feedback wiring – sine encoder with Hall

Pin Number	Twisted pair cables	User motor pin number	Signal declarations
9	Twisted pair cables		Sine encoder sine+
22			Sine encoder sine-
10	Twisted pair cables		Sine encoder cosine+
23			Sine encoder cosine-
4			Hall U
17			Hall V
5			Hall W
12	Twisted pair cables		Motor temperature sensor
25			Motor temperature sensor
11			+5V DC voltage
24			0V DC voltage
26			Shielding

Note: If the motor does not support a temperature sensor, do not connect pins 12 and 25.

Wiring - sine encoder with Index

table4-30 Feedback wiring – sine encoder with index

Pin Number	Twisted pair cables	User motor pin number	Signal declarations
9	Twisted pair cables		Sine encoder sine+
22			Sine encoder sine-
10	Twisted pair cables		Sine encoder cosine+
23			Sine encoder cosine-
3	Twisted pair cables		Sine encoder Z+
16			Sine encoder Z-
12	Twisted pair cables		Motor temperature sensor
25			Motor temperature sensor
11			+5V DC voltage
24			0V DC voltage
26			Shielding

Note:

If the motor does not support a temperature sensor, do not connect pins 12 and 25.

Wiring – sine encoder with index and Hall

table4-31 Feedback wiring – sine encoder with index and Hall

Pin Number	Twisted pair cables	User motor pin number	Signal declarations
9	Twisted pair cables		Sine encoder sine+
22			Sine encoder sine-
10	Twisted pair cables		Sine encoder cosine+
23			Sine encoder cosine-
3	Twisted pair cables		Sine encoder Z+
16			Sine encoder Z-
4			Hall U
17			Hall V
5			Hall W
12	Twisted pair cables		Motor temperature sensor
25			Motor temperature sensor
11			+5V DC voltage
24			0V DC voltage
26			Shielding

Note: If the motor does not support a temperature sensor, do not connect pins 12 and 25.

Wiring – Sick5V (HIPERFACE protocol and sine signal)

table4-32 Feedback wiring – Sick5V (HIPERFACE protocol and sine signal)

Pin Number	Twisted pair cables	User motor pin number	Signal declarations
1	Twisted pair cables		Serial data+
14			Serial data-
9	Twisted pair cables		Sine encoder sine+
22			Sine encoder sine-
10	Twisted pair cables		Sine encoder cosine+
23			Sine encoder cosine-
12	Twisted pair cables		Motor temperature sensor
25			Motor temperature sensor
11			+5V DC voltage
24			0V DC voltage
26			Shielding

Note: If the motor does not support a temperature sensor, do not connect pins 12 and 25.

Wiring – Sick8V (HIPERFACE protocol and sine signal)

table4-33 Feedback wiring – Sick8V (HIPERFACE protocol and sine signal)

Pin Number	Twisted pair cables	User motor pin number	Signal declarations
1	Twisted pair cables		Serial data+
14			Serial data-
9	Twisted pair cables		Sine encoder sine+
22			Sine encoder sine-
10	Twisted pair cables		Sine encoder cosine+
23			Sine encoder cosine-
12	Twisted pair cables		Motor temperature sensor
25			Motor temperature sensor
18			+8V DC voltage
24			0V DC voltage
26			Shielding

Note: If the motor does not support a temperature sensor, do not connect pins 12 and 25.

Wiring – HEIDENHAIN (EnDat2.x communication only)

table4-34 Feedback wiring - HEIDENHAIN (EnDat2.x communication only)

Pin Number	Twisted pair cables	User motor pin number	Signal declarations
1	Twisted pair cables		Serial data+
14			Serial data-
2	Twisted pair cables		Serial clock+
15			Serial clock-
12	Twisted pair cables		Motor temperature sensor
25			Motor temperature sensor
11			+5V DC voltage
24			0V DC voltage
26			Shielding

If the motor does not support a temperature sensor, do not connect pins

Note: 12 and 25.

Please refer to the *EnDat2.x Bidirectional Interface*.

table4-35 Feedback wiring - HEIDENHAIN (EnDat2.x with sine/cosine)

Pin Number	Twisted pair cables	User motor pin number	Signal declarations
1	Twisted pair cables		Serial data+
14			Serial data-
2	Twisted pair cables		Serial clock+
15			Serial clock-
9	Twisted pair cables		Sine encoder sine+
22			Sine encoder sine-
10	Twisted pair cables		Sine encoder cosine+
23			Sine encoder cosine-
11			+5V DC voltage
24			0V DC voltage
26			Shielding

Note:

If the motor does not support a temperature sensor, do not connect pins 12 and 25.

Please refer to the *EnDat2.x Bidirectional Interface*.

Wiring – Nikon/Tamagawa | Incremental 17-bit | single-turn

table4-36 Feedback wiring – single-turn: Nikon 17-bit multi-turn | Tamagawa 17-bit incremental single-turn

Pin Number	Twisted pair cables	User motor pin number	Signal declarations
1	Twisted pair cables		Serial data+
14			Serial data-
11			+5V DC voltage
24			0V DC voltage
26			Shielding

Wiring – Nikon/Tamagawa | incremental 17-bit | multi-turn

table4-37 Feedback wiring - multi-turn: Nikon 17-bit multi-turn | Tamagawa 17-bit multi-turn | Sankyo multi-turn

Pin Number	Twisted pair cables	User motor pin number	Signal declarations
1	Twisted pair cables		Serial data+
14			Serial data-
11			+5V DC voltage
24			0V DC voltage
26			Shielding

Note: The encoder backup battery is external to the CDHD2S-PN-RS drive.
 The recommended battery is 3.6V, 1000mAh lithium battery.
 Use backup batteries recommended by the encoder manufacturer.

Wiring – resolver*

table4-38 Feedback wiring - resolver

Pin Number	Twisted pair cables	User motor pin number	Signal declarations
6	Twisted pair cables		Resolver sine+
19			Resolver sine -
7	Twisted pair cables		Resolver cosine+
20			Resolver cosine -
8	Twisted pair cables		Resolver reference+
21			Resolver reference-
12	Twisted pair cables		Motor temperature sensor
25			Motor temperature sensor
24	Grounded		Optional: Inner shielding for each twisted pair (sine, cosine, reference)
26			Cable shielding

4.9.12 Gantry system wiring

The two drives of the two axes of the CDHD2S-PN-RS gantry system can be connected to each other via the C8 or C3 interface.

To ensure immunity to interference, it is strongly recommended to connect the drive via the C3 shielded interface.




figure4-25 Gantry system wiring - pulse train and serial




figure4-26 Gantry system wiring - Profinet

table4-39 Table 4-35 Gantry daisy chain C8 wiring

Gantry master (Y1) Drive	Gantry differential (Y2) drive	Twisted pair cables	Signal declarations
7	7	Twisted pair cables	Serial data Tx+
8	8		Serial data Tx-
9	9	Twisted pair cables	Serial data Rx+
10	10		Serial data Rx-

table4-40 Gantry daisy chain C3 wiring

Gantry master (Y1) Drive	Gantry differential (Y2) drive	Twisted pair cables	Signal declarations
1	1	Twisted pair cables	Serial data Tx+
11	11		Serial data Tx-
2	2	Twisted pair cables	Serial data Rx+
12	12		Serial data Rx-

4.10 Power Board Connection

The power board interface varies with the specific CDHD2S-PN-RS model.

For power board, please refer to the power board pin assignment diagram.



Ensure that the main voltage rating meets the drive requirements. Applying an incorrect voltage may cause the drive to malfunction.

Do not turn on the power supply until all hardware connections are completed.

4.10.1 CDHD2S-1D5/003 (medium-voltage) power board pin assignment




figure4-27 CDHD2S-1D5/003(medium-voltage)power board pin assignment

4.10.2 CDHD2S-4D5/006 (medium-voltage) power board pin assignment




figure4-28 CDHD2S-4D5/006(medium-voltage)power board pin assignment

4.10.3 CDHD2S-008/010/013(medium-voltage)power board pin assignment




figure4-29 CDHD2S-008/010/013(medium-voltage)power board pin assignment

4.10.4 CDHD2S-003/006 (high-voltage) power board pin assignment




figure4-30 CDHD2S-012 (high-voltage) power board pin assignment

4.10.5 CDHD2S-012 (high-voltage) power board pin assignment

CDHD2S




figure4-31 CDHD2S-012 (high-voltage) power board pin assignment

4.10.6 CDHD2S-040 (high-voltage) power board pin assignment




figure4-32 CDHD2S-024/030 (high-voltage) power board pin assignment

4.10.7 CDHD2S-040 (high-voltage) power board pin assignment




figure4-33 CDHD2S-040 (high-voltage) power board pin assignment

4.10.8 STO-P1

Safe Torque Off (STO) is a safety feature that prevents the drive from supplying power to the motor, thereby producing torque. For complete installation and operating details, please refer to the *Safe Torque Off (STO) Overview*

Table 4-37 STOP Interface

Pin	Pin tag	Function
1		24V power supply, provided by STO bypass drive
2		24V loop, provided by STO bypass drive
3	STO-	STO-, provided by short-circuiting the driver
4	STO+	STO+, provided by short-circuiting the driver

Note:

Ensure that the main voltage rating meets the drive requirements. Applying an incorrect voltage may cause the drive to malfunction. Do not turn on the power supply until all hardware connections are completed.




figure4-34 STO bypass plug (medium-voltage model)




figure4-35 STO bypass plug

The STO system configuration is shown in the figure below.




figure4-36 STO-emergency stop circuit wiring - example

4.10.9 Motor power - P2, P4

The motor power interface and connector vary with CDHD2S-PN-RS model.

Please refer to the power board pin assignment diagram.

4.10.10 Regenerative Resistors - P3, P5

The regenerative resistance interfaces and connectors of CDHD2S-PN-RS models are different.

Please refer to the power board pin assignment diagram.

If the application requires a regenerative resistor, connect the regenerative resistor between terminals B1+ and B2.

The resistance value (ohms, W) is defined by the CDHD2S-PN-RS servo drive. The required power is defined by the application. Therefore, each drive has multiple regenerative resistor options.

The manufacturer and part number of regenerative resistor recommended by CDHD2S-PN-RS are listed in the following table.

table4-41 Recommended regenerative resistors for CDHD2S-PN-RS medium-voltage models

Medium voltage	Minimum resistance (Ω)	Peak current (A)
CDHD2S-1D5	64	6.3
CDHD2S-003	31.5	12.7
CDHD2S-4D5	16	25.5
CDHD2S-006	16	25.5
CDHD2S-008	10	40
CDHD2S-010	10	40
CDHD2S-013	10	40

table4-42 The internal regenerative resistor used in CDHD2S-PN-RS high-voltage models

High voltage	Minimum resistance (Ω)	Peak current (A)	Power (W)
CDHD2S-003	48	16	90
CDHD2S-006	48	16	90
CDHD2S-012	22	35	100
CDHD2S-024	15	51.3	300
CDHD2S-030	15	51.3	300
CDHD2S-040	15	51.3	800

table4-43 Recommended regenerative resistors for CDHD2S-PN-RS high-voltage models

High voltage	Minimum resistance (Ω)	Peak current (A)
CDHD2S-003	33	23
CDHD2S-006	33	23
CDHD2S-012	22	35
CDHD2S-024	10	77
CDHD2S-030	8.4	100
CDHD2S-040	9.6	80

4.10.11 AC input - bus power and logic power - P3, P4, P5

The AC input interface and connector vary with CDHD2S-PN-RS model.

On the CDHD2S-1D5 and CDHD2S-003, the regeneration and AC input voltages are combined on one connector. Since these models only support single-phase AC, they do not have an L3 terminal for bus power.

Please refer to the power board pin assignment diagram.

Ensure that the main voltage rating meets the drive requirements. Applying an incorrect voltage may cause the drive to malfunction. Do not turn on the power supply until all hardware connections are completed.

Protect against impact surges:

Bus power (L1-L2-L3): When the bus is powered on, wait for 1 minute before turning it on, whether it is off or not.

Logic power supply (L1C-L2C): After turning off the logic power supply, wait for 1 minute before turning it on again.

Procedure: Connect power

1. Connect the AC input voltage ground wire to the PE terminal located on the front panel of the CDHD2S-PN-RS. Use M4 ring terminal or sector terminal.




figure4-37 Ground terminal

2. Connect L1, L2 and L3 (for bus power).

- If the main voltage comes from a single-phase supply, connect the line and neutral line to L1 and L3.
- If the main voltage comes from a three-phase supply, connect the phases to L1, L2 and L3.

3. Connect L1C and L2C (for logic power).

- If the main voltage comes from a single-phase supply, connect the line and neutral line to L1C and L2C.
- If the main voltage comes from a three-phase supply, connect any two phases to L1C and L2C.

4.11 Regeneration

4.11.1 Overview of regenerative energy

When the motor and load decelerate rapidly, the kinetic energy of the load drives the motor shaft energy back into the drive; this is called regenerative energy, or regeneration. This energy must be dissipated or absorbed.

The undissipated regenerated energy is added to the electrical energy already stored in the bus module capacitors. If the capacitor can store this energy, the system does not require a regenerative resistor.

In some cases, usually due to a high inertia mismatch between the load and motor, too much energy is added to the capacitor, causing the voltage on the capacitor to reach the overvoltage threshold, which then causes the drive to be disabled. To prevent overvoltage and potential damage to the system, excess regeneration energy must be dissipated through a regenerative resistor.

To determine whether the system requires a regenerative resistor and determine the capacity level (if required), please refer to the "calculation of regenerative resistance" to calculate the performance of the system.




figure4-38 Regenerative resistor working circuit

4.11.2 Calculation of regenerative resistance

CDHD2S-PN-RS busbar specifications

table4-44 Busbar specifications - two-phase AC voltage 120/240V

Drive model	Rated voltage (DC voltage)	Low-voltage (DC voltage)	High-voltage (DC voltage)	Maximum voltage (DC voltage)
CDHD2S-1D5	170/340	380	400	420
CDHD2S-003	170/340	380	400	420
CDHD2S-4D5	170/340	380	400	420
CDHD2S-006	170/340	380	400	420

table4-45 Busbar specifications – three-phase AC voltage 380/480V

Drive model	Rated voltage (DC voltage)	Low-voltage (DC voltage)	High-voltage (DC voltage)	Maximum voltage (DC voltage)
CDHD2S-012	540/680	750	770	800
CDHD2S-024	540/680	750	770	800
CDHD2S-030	540/680	750	770	800

Calculate the return energy for each deceleration

$$E_{\text{dec}} = \frac{1}{2}(J_M + J_L)(\omega_1^2 - \omega_2^2)$$

Where:

E_{dec} = Energy returned during deceleration (J or ft·lb)

J_M = Rotor inertia (kg·m² or lb·ft·sec²)

J_L = Load inertia (kg·m² or lb·ft·sec²)

ω_1 = Velocity at the beginning of deceleration (rad/s)

ω_2 = Velocity at the end of deceleration (rad/s)

Determine the energy consumed by the motor

As the current passes through the motor winding resistance, part of the energy is dissipated by the motor:

$$E_{\text{motor}} = 3I_M^2 \cdot (R_M/2) \cdot t_d$$

Where:

E_{motor} = Energy consumed by motor (J)

R_M = Motor resistance (Ω·L)

I_M = Current during deceleration (ARMS/phase)

t_d = Deceleration time (s)

Determine the energy consumed by the friction

$$E_{\text{friction}} = \frac{1}{2} T_f (\omega_1 - \omega_2) t_d$$

Where:

E_{friction} = Energy consumed by friction (J or ft·lb)

T_f = Friction torque (N·m or lb·ft)

ω_1 = Velocity at the beginning of deceleration (rad/s)

ω_2 = Velocity at the end of deceleration (rad/s)

t_d = Deceleration time (s)

Determine the energy consumed by the amplifier

$$E_M = E_{\text{dec}} - E_{\text{motor}} - E_{\text{friction}}$$

Where:

E_M = Total energy consumed by the amplifier (J or ft·lb)

If the energy is less than the energy that the bus module can store, the regenerative resistor is not needed.

E_M should be expressed in joule. The conversion rate from ft·lb to joule is:

$$1 \text{ ft·lb} = 1.356 \text{ J}$$

Determine the energy that the bus module can absorb

$$E_{\text{BUS}} = \frac{1}{2} C (V_M^2 - (V_{\text{NOM}})^2)$$

Where:

E_{BUS} = Energy that the bus module can absorb (J)

C = Bus module capacitance (F); please refer to the *Bus Specifications* section

V_M = Maximum bus voltage (V); please refer to the *Bus Specifications* section.

V_{NOM} = Bus nominal voltage = $\sqrt{2} V_{\text{mains}}$ (V)

Determine whether the regenerative resistor is needed.

If $E_{\text{BUS}} > E_M$, the regenerative resistor is not needed.

If $E_{\text{BUS}} < E_M$, the regenerative resistor is needed.

Determine the resistor value

The procedure for calculating regeneration requirements is twofold. The regenerative resistor value and resistor power must be determined.

Determine the resistance value

$$R_{Max} = \frac{V_M^2}{V_B I_M \sqrt{3}}$$

Where:

V_B = Motor back-EMF - motor loss.

$$V_B = K_B N - \sqrt{3} I_M (R_M/2)$$

V_M = Maximum bus voltage (v); please refer to the *Bus Specifications* section.

K_B = Back-EMF constant (VL-L/rpm)

N = Motor velocity before deceleration (rpm)

I_M = Current during deceleration (ARMS/phase)

R_M = Motor resistance (ΩL-L)

Determine the average power dissipated

$$P_{AV} = \frac{E_M - \frac{1}{2} C (V_{High}^2 - V_{Low}^2)}{t_{cycle}}$$

Where:

E_M = Total energy consumed by the amplifier (J)

C = Bus module capacitance (F); please refer to the *Bus Specifications* section

V_{High} = Hysteresis point: the regenerative circuit is turned on (V); please refer to the *Bus Specifications* section.

V_{Low} = Hysteresis point: the regenerative circuit is closed (V); please refer to the *Bus Specifications* section.

t_{cycle} = Deceleration interval + deceleration time (s)

Determine the resistor power for peak

$$P_{PK} = \frac{V_M^2}{R_{Regen}}$$

R_{Regen} = Regenerative resistor resistance (ΩL-L)

V_M = Maximum bus voltage (v); please refer to the *Bus Specifications* section.

Example for the calculation of regenerative resistor resistance (in US standard units)

Motor and drive specifications

CDHD2S-006 drive, using single-phase AC voltage 240V input

$J_{motor} = 0.000484 \text{ lb} \cdot \text{ft} \cdot \text{sec}^2$

$R_M = 1.32 \Omega$

$$I_{\text{peak}} = 18\text{A}$$

$$T_M = 19.8\text{lb}\cdot\text{ft}$$

$$C = 0.001120\text{F}$$

$$V_M = 420\text{V}$$

$$K_B = 81.2\text{V}/\text{krpm} = 0.0812\text{V}/\text{rpm}$$

$$k_t = 1.188\text{lb}\cdot\text{ft}/\text{A}$$

System specifications

$$T_f = 1.5\text{lb}\cdot\text{ft}$$

$$J_{\text{Load}} = 0.0015\text{lb}\cdot\text{ft}\cdot\text{sec}^2$$

$$V_{\text{Max}} = 2,500\text{rpm} \Rightarrow \omega_M = 261\text{rad/s}$$

$$V_{\text{NOM}} = 240\text{V}_{\text{rms}} = 340\text{VDC}$$

$$\text{Deceleration interval} = 5\text{s}$$

Calculation of deceleration time

$$t_d = \frac{(J_{\text{Motor}} + J_{\text{Load}}) \cdot (\omega_M)}{(T_M + T_f)} = (0.000484 + 0.001) \cdot (261) / (19.8 + 1.5) = 0.0181\text{s}$$

Calculation of current during deceleration

$$I_M = \frac{(J_{\text{Motor}} + J_{\text{Load}}) \cdot \omega_1 - \omega_2}{k_t \cdot t_d} = \frac{0.001 + 0.000484}{1.188} \cdot \frac{261}{0.0181} = 18\text{A}$$

Calculation of energy

$$E_{\text{dec}} = \frac{1}{2} (J_M + J_L) (\omega_1^2 - \omega_2^2) = \frac{1}{2} (0.0015 + 0.000484) (261^2 - 0) = 67.57\text{ft}\cdot\text{lb} = 91.63\text{J}$$

$$E_{\text{motor}} = 3I_M^2 \cdot (R_M / 2) \cdot t_d = 3 \cdot 18^2 \cdot \left(\frac{1.32}{2}\right) \cdot 0.0181 = 11.61\text{J}$$

$$E_{\text{friction}} = \frac{1}{2} T_f (\omega_1 - \omega_2) t_d = \frac{1}{2} \cdot 1.5 \cdot (261 - 0) \cdot 0.0181 = 3.54\text{ft}\cdot\text{lb} = 4.8\text{J}$$

$$E_M = E_{\text{dec}} - E_{\text{motor}} - E_{\text{friction}} = 91.633 - 11.611 - 4.8 = 75.22\text{J}$$

$$E_{\text{BUS}} = \frac{1}{2} C (V_M^2 - V_{\text{NOM}}^2) = \frac{1}{2} \cdot 0.001120 (420^2 - 340^2) = 34.05\text{J}$$

Since $E_M > E_{\text{BUS}}$, a regenerative resistor is needed.

Calculation of resistor specification

$$V_B = K_B N - \sqrt{3} I_M \left(\frac{R_M}{2} \right) = 0.0812 \cdot 2500 - \sqrt{3} \cdot 18 \cdot \left(\frac{1.32}{2} \right) = 182.423 \text{ V}$$

$$R_{MAX} = \frac{V_M^2}{V_B I_M \sqrt{3}} = \frac{420^2}{182.423 \cdot 18 \cdot \sqrt{3}} = 31.02 \Omega$$

$$P_{AV} = \frac{E_M - \frac{1}{2} C (V_{High}^2 - V_{LOW}^2)}{t_{cycle}} = \frac{44.42 - \frac{1}{2} \cdot 0.001120 \cdot (400^2 - 380^2)}{5.03} = 7.1 \text{ W}$$

$$P_{PK} = \frac{V_M^2}{R_{Regen}} = \frac{420^2}{132} = 5686.65 \text{ W}$$

4.11.3 Regenerative resistor overload protection

Motor energy regeneration in CDHD2S-PN-RS is always active.

The motor energy regeneration function has two modes:

- Regeneration with resistor overload protection.

The regenerative resistor circuit requires overload protection to ensure reliable operation of the resistor. In this mode, you can configure the CDHD2S-PN-RS regenerative resistor parameters for protection.

- Regeneration without resistor overload protection. This mode is also called bang-bang mode.

In bang-bang mode, the drive will activate the regenerative resistor when the upper threshold is exceeded (400V for medium-voltage drives, 770V for high-voltage drives); when the bus voltage drops to the lower threshold (400V for medium-voltage drives) 380V,

770V for high-voltage drives), the regenerative resistor will be disabled.



Please use regenerative resistor protection with caution.

If the motor increases the bus voltage and the protection mechanism is activated, it may lead to overvoltage condition.

4.11.4 Regenerative resistor parameters

The regenerative resistor capacity is defined by several parameters.

To activate the regenerative resistor protection function in CDHD2S-PN-RS, parameter REGENRES and/or parameter REGENPOW must be set to a value other than -1, and this is the default value.

VarCom	Description
REGENRES	Regenerative resistor resistance, in ohms.
REGENPOW	Regenerative resistor power, in watts.
REGENMAXONTIME	Maximum time that regenerative resistor can be continuously activated (turned on), in milliseconds.
REGENMAXPOW	Maximum power of regenerative resistor, in watts.

Note: If the system does not have a regenerative resistor, set REGENRES=-1 and REGENPOW=-1. If the system has a regenerative resistor, the "-1" value of REGENRES or REGENPOW will disable the regenerative resistor overload protection algorithm.

4.12 Firmware Update

4.12.1 Firmware update preparation


IMPORTANT: Before updating firmware, make sure to do the following:

- Please refer to the release notes and any other documentation provided with the new firmware.
- Since the parameter settings may be lost during the update, please back up the parameters of each drive in the system and keep these files safe. When the update is completed, the parameters can be reloaded/restored.

To back up parameters, go to the ServoStudio2 Backup and Restore screen and press the Save to Backup button.

4.12.2 Firmware update options

Click the Firmware Download button in the ServoStudio2 drive information screen to open the firmware download dialog box.



The Firmware Download dialog box contains the following fields and controls:

- Firmware Path:** A text field containing "C:\Servotronics\CDHD2_Firmware\CDHD_2_15_2.sfw" and a "Browse" button.
- Axis #:** A text field with "..." as a placeholder.
- ID:** A text field with "..." as a placeholder.
- Progress:** A horizontal progress bar.
- Buttons:** "Start", "Advanced", and "Exit" buttons.
- Close when done:** A checked checkbox.
- Address:** A text field containing "0".
- Port:** A dropdown menu showing "COM1".
- Baud rate:** A dropdown menu showing "115200".
- Ember Mode:** Two radio buttons, "Software" (selected) and "Hardware".
- Restore parameters:** An unchecked checkbox.
- Disable optimization:** An unchecked checkbox.

figure4-39 Firmware download

table4-46

Firmware path	<p>Containing the path and name of the firmware update file.</p> <p>The file name represents the firmware version; for example: 2_00_0*.sfw represents firmware version 2.0.x. The default path is \\My Documents\\ServoStudio2.</p> <p>Click Browse to choose a different path.</p>
Start	Activate firmware update.
Advanced	Expanding the dialog to show additional options
Close when done	When selected, the firmware download dialog box will automatically close after the program is completed.
Address	<ul style="list-style-type: none"> When only one drive is connected to the host, the drive address is not required. <p>Before activating the firmware download process, the software attempts to communicate with the drive that is communicating with the host. Therefore, if the drive responds to serial communication, the firmware download process will continue.</p> <ul style="list-style-type: none"> When multiple drives are connected to the host in daisy chain, the drive address must be specified. <p>After specifying the drive address, the software will be started by sending the command \\, which will stop all drives connected to the selected serial port from responding to serial communications. It then issues the command \\nn, instructing only the drive with address with nn to respond.</p>
Port	The COM port of the host to which the drive is connected. Make sure this COM port is not in use by any other application.
Baud rate	The baud rate must be set to 115200.
Ember mode	<p>Ember is a process for burning new firmware on the flash memory of the drive.</p> <ul style="list-style-type: none"> Software Usually using default software options. Hardware Using this option if the firmware loading process is interrupted and you cannot establish communication with the drive.
Disable optimization	The firmware update process uses optimization methods to improve performance. In rare cases, this optimization may cause the program to fail. In this case, please disable optimization and restart the firmware update.
Restore parameters	<p>When selected, the firmware update process will store all user parameters in memory before downloading the firmware, and restore the parameters after the update. This option can be disabled.</p> <p>This option is not available if the host and the drive are not communicating.</p> <p>Note: Regardless of the setting of this option, it is strongly recommended that you use the Save to Backup option in the Backup and Restore screen to preserve existing drive parameters before updating firmware.</p>

4.12.3 Updating firmware via serial connection

Procedure: Updating drive firmware via serial connection

1. Download the firmware file (*.sfw) of the drive from the product webpage to the host.
2. In the ServoStudio2 drive information screen, click "Download Firmware".

The Firmware Download dialog box opens, allowing you to send a firmware file to the drive via the serial communication link.

3. Browse and select the firmware file.
4. Click "Start" to download the firmware file to the drive.
During the firmware update process, the digital display shows E:



figure4-40

This process takes several minutes.

When the process is completed, the new firmware will start running.

5. Download the drive parameter file to the drive.
6. Perform "Save" to save the parameters in the non-volatile drive memory.
7. Restart the power and run the machine.

If machine behavior has changed, please contact technical support.

8. Retrieve the parameter file from the drive and save the file for future reference and backup.

9. Repeat the firmware update procedure for each drive in the machine.

4.12.4 Restoration operation after firmware update

Procedure: Restoration operation after firmware update

1. Go to the ServoStudio2 Drive Information screen in ServoStudio2 and check the drive firmware version to verify that the new firmware has been loaded.
2. Open the Backup and Restore screen and click the "Restore" button to reload the previously backed up drive parameters
3. Check the version release notes and set all parameters that may have been added to the new version.
4. Save parameters to non volatile parameter memory: execute the serial command "Save", or click the "Save" button on the ServoStudio2 toolbar, or use the command C0006 on the operation panel; and wait for the display to show completion.
5. Restart the power and run the machine. If machine behavior has changed, please contact technical support.

4.12.5 Ember mode

Ember is a process for burning new firmware on the flash memory of the drive. The drive must be in Ember mode to load firmware. The drive has two Ember modes, software and hardware.

Generally, you can and should communicate with the drive in software Ember mode to load new firmware.

However, if the firmware loading process is interrupted and you cannot establish communication with the drive, you need to use Ember hardware mode.

To activate hardware Ember mode, use a small screwdriver or similar tool to gently press the hardware Ember switch. This switch is located on the top of the drive next to the daisy chain connector (C8).




figure4-41 Location of hardware Ember switch

Press the switch to set the drive to the serial communication "Boot-Up" mode.

If the drive has a fan, the fan spins at maximum speed. When the firmware is successfully downloaded and the drive is rebooted, the fan speed will return to normal.

In Boot-Up mode, the 5-digit display shows e.

5. Motor Setup

From firmware version 1.40.0, the drive will attempt to detect the motor feedback device and electronic motor nameplate (MTP) upon power-up. If the electronic motor nameplate (MTP) is detected, some motors and feedback parameters will be directly transmitted to the drive and cannot be operated. Therefore, the electronic nameplate makes debugging simple and reliable.

If the electronic motor nameplate is not detected at power-up, you can use the Motor screen or the Motor Setup Wizard to select a motor from the ServoStudio2 database (Motor Library). You only need to select the motor series and motor part number, and ServoStudio2 can prepare the corresponding motor and feedback parameters. This screen allows you to modify and send parameters to the drive, read parameters from the drive and save parameters.

Note: Disable the drive before operating the motor and feedback parameters.
 When the drive is enabled, many parameters can be modified.
 However, proceed with caution as movement behavior will change.
 If parameters cannot be modified while the drive is enabled, ServoStudio2 will prompt you to disable the drive.

5.1 Motor Setup Wizard

The ServoStudio2 Motor Setup wizard provide a quick and easy way to get your drive and motor up and running. This wizard configures basic parameters and current control loops for an unloaded motor.

It is recommended that you use the "Motor Setup" wizard when connecting the host, drive and motor for the first time.

This chapter describes the functions and parameters configured during motor setup and initialization.

Motor Setup - Connection

Usually, the first step in the wizard is to establish communication between the drive and the ServoStudio2 software.

If ServoStudio2 has already communicated with the drive, the wizard will skip this step.




Figure 5-1 Motor setup wizard - connection

1. Select a specific COM port or "Search All".
2. Click "Connect".

Please refer to the *Communication*.

Motor Setup - Drive Information

If ServoStudio2 has already communicated with the drive, the wizard will start with the **Drive Information**.




Figure 5-2 Motor setup wizard - drive information

1. View drive information.
2. Enter a name for the drive and press Enter.

The name field will change from blue to white, indicating that the name has been sent to the drive.

This step also includes an option to restore the factory settings of the drive: Restore Factory Default.

This step also displays and allows setting the "Interface Mode".

- Serial/Pulse/Analog means the drive is active (servo on) and drive commands are transmitted via the serial, pulse or analog interface. COMMODE 0.
- EtherCAT/CANopen or PROFINET means that the drive is active (servo on) and drive commands are transmitted through the EtherCAT, CANopen or PROFINET interface. COMMODE 1.

Motor - Setup - Motor identification and initialization

If the drive detects the electronic motor nameplate, the parameters in this screen will be set automatically and cannot be operated. Just click Next to proceed to the next step.




Figure 5-3 Motor setup wizard - automatic motor detection

If the drive does not detect the electronic nameplate (or the software does not communicate with the drive), you can select the motor from the ServoStudio2 motor library.

If the motor is not listed in the default motor library, click **Define New Motor** and enter the parameters for the specific motor by following the new motor wizard.




Figure 5-4 Motor setup wizard - motor selection

1. Select motor series.
2. Select the motor model.
3. Select the characters that match the label on the motor (# means the field can be ignored).
4. Click Verify to send parameters to the drive and test the motor configuration.



Verification will start the drive and drive the motor!

Motor setup - current, velocity limit and position limit

The wizard provides suggestions for low, medium, or high limits for current and velocity. These values correspond to 25%, 50% and 100% of the maximum respectively.

Please refer to the *Current Limit and Velocity Limit* and *Velocity Limit*.

The wizard also allows setting the position error limit, i.e. the maximum value that will not cause a failure.

Please refer to the VarComPEMAX.

Note: If the limit is set too low, the Autotuning wizard may not produce optimal results.




Figure 5-5 Motor setup wizard - limit

1. Set the velocity and current limit and the position error limit by doing any of the following:

- Select the recommended low, medium or high value.
- Select User Defined and enter your preferred values.

2. Click "Agree" to send the values to the drive.

If the current limit or velocity limit is set to 0 for user defined value, the motion will be prevented.

If the position error limit is set to 0 for user defined value, the position error limit is not set and no fault will occur.

Motor setup - motor direction

This wizard simplifies the process of defining the rotation direction of motion command. Otherwise, the VarCom command is required.

Please refer to the VarComMPHASE and DIR.

To visually test the direction of motion, click and hold the direction button. The test velocity is defined as the percentage of motor continuous current. Use a low value to see the direction of motor movement. The default setting is 5.

The motor setup wizard simplifies the process of defining the rotation direction for positive command. Otherwise, the VarCom command is required.



Figure 5-6 Motor setup wizard - motor direction

1. To verify the direction of motor movement, click "Negative" or "Positive".



"Negative" and "Positive" start the drive and run the motor!

2. To reverse the direction to match the system, enable the Inverse Direction option. Please refer to the VarComMPHASE and DIR.

3. To complete the process, click Save or Done.

Motor Setup - Save

After completing the "Motor Setup", it is recommended that you save the parameters to the non-volatile drive memory and a file on the host for backup.




Figure 5-7 Motor setup wizard - save

Do both of the following:

- Click Save to Drive to save the parameters in the drive RAM to its permanent memory.
- Click Save to PC to save the parameters in the drive RAM to a backup file on your computer. Parameters are saved in text files with TXT or SSV extension. Text files can be edited using Notepad or any other text editor.

It is also recommended that you create an application report:

- Click Generate Report.

When activated, Report Generator will open a dialog box that allows you to enter application and user information. Then generate a set of CSV and TXT files in the compressed file. This file can be attached to an email automatically sent to technical support. You can change the address and send it to other recipients.

Please refer to the *Report Generator* in the ServoStudio2 manual.

5.2 Drive Identification

You can see and confirm drive information in the Motor Setup wizard.

The ServoStudio2 Drive Information screen allows you to view drive properties and define the drive name. The following parameters are used to view and configure drive information:

Table 5-1

VarCom	Description
--------	-------------

INFO	Defined by hardware. Return to the drive model and serial number, as well as the version numbers of firmware, control board, power board and FPGA.
DRIVENAME	User-defined parameters. Used when an application has multiple drives. It is recommended to provide the drive with a name that reflects the function it performs, such as Axis-1.

5.3 Motor Installation

Motor selection and properties can be displayed and confirmed in the "Motor Setup" wizard.

If the drive does not detect an electronic motor nameplate (MTP), the motor screen allows you to define and initialize the motor.

You can select the motor series and motor part number from the ServoStudio2 database (motor library), and ServoStudio2 can prepare the corresponding motor and feedback parameters.

If your motor is not listed in the default motor library, use the New Motor wizard to define a new motor.

The following parameters are used to view and configure motor identification:

Table 5-2

VarCom	Description
MOTORNAME	<p>If you select a motor from the motor library in the ServoStudio 2 database, the name will be assigned automatically. Users can also assign and modify motor names.</p> <p>The motor name always begins with a quotation mark (").</p> <p>For example: "MT-6CC401C"</p>

5.4 Motor Initialization

Motor commutation is performed in the "Motor Setup" wizard.

If the drive does not detect the electronic motor nameplate (MTP), the Motor screen provides verify and stop buttons to start and stop the MOTORSETUP process.

The MOTORSETUP command starts the quick debugging program, which is used to set and define motor commutation parameters.

During the initialization process, the rotating motor mechanically rotates forward/backward for about two turns in forced commutation, and this information does not need to be fed back. MOTORSETUP detects Hall switch status, index position and polarity, electrical phase sequence, direction of motor motion, and feedback resolution per electrical revolution.

Based on the collected data, the drive updates parameters MFBDIR, MPHASE, MPOLES, MENCRES, and MENCZPOS, so that the motors and wiring connected to the drive can be used.

If the program fails, the original values of MFBDIR, MPHASE, MPOLES, MENCRES, and MENCZPOS will be restored.

Note:

Not all parameters are updated during this process. It depends on the parameters in use determined by MENCTYPE.
 The MICON value is very important because this value sets the current limit used in this program.

Program: MOTORSETUP

To perform the "Motor Initialization" process, do the following:

1. Disable drive.
2. Clear any faults in the drive.
3. Enter the command MOTORSETUP (motor setup).

4. Enable the drive (otherwise the process will stop at stage 5/51). The process follows a series of steps.

After the "Motor Initialization" procedure is started (even if the drive is disabled), the digital display shows At1. After the setting is successful, the display returns to normal; if the setting fails, the display shows -5.

To cancel the motor setup process, enter the command MOTORSETUP0

Any parameters modified by the MOTORSETUP program will be restored to their previous values.

To view the status of the program, enter the command MOTORSETUPST.

5.5 Current limit

Modify and/or confirm the current limit in "Motor Setup".

The Current Limit tab in the ServoStudio2 Limit screen allows you to define position limit.

The following parameters are used to define the maximum current of the system and set the current limit for the application.

Table 5-3

VarCom	Description
DIPEAK	Rated peak current of the drive. Defined by hardware. Read only.
MIPEAK	Rated peak current of the motor. This value can be modified.
IMAX	This value is the maximum current of the combination of drive and motor calculated by software. Read only.
ILIM	Current limit of the application. This parameter allows you to limit the peak current of the drive to a value lower than DIPEAK.
ILIMACT	Actual drive current limit. Read only.

5.6 Velocity limit

Modify and/or confirm the velocity limits in the "Motor Setup" wizard.

The Velocity Limit tab in the ServoStudio2 Limit screen allows you to define position limit.

The hardware defines the maximum velocity the drive can calculate.

The following parameters are used to define the maximum velocity of the system and set the velocity limit for the application.

Table 5-4

VarCom	Description
MSPEED	The maximum motor velocity defined in the motor data sheet.
VMAX	This value is the maximum velocity of the combination of drive and motor. VMAX is based on the maximum motor velocity. Read only.
VLIM	Maximum velocity. This parameter allows you to limit the maximum velocity of the motor to a value lower than VMAX.

5.7 Position limit

Modify and/or confirm the position limit during the Motor Setup wizard.

The Position Limit tab in the ServoStudio 2 Limit screen allows you to define position limit.

The following parameters are used to define the position limit mechanism and error tolerance.

Table 5-5

VarCom	Description
PEMAX	Maximum allowable position error without fault, in the unit of count.
PEINPOS	Tolerance window that declares "in position" status.
INMODE#5	The digital input number is defined as a signal indicating whether the position limit has been reached in the positive direction.
INMODE#6	The digital input number is defined as a signal indicating whether the position limit has been reached in the negative direction.
LIMSWITCHPOS LIMSWITCHNEG	Indicating the status of all positive and negative limit events. Read only.
POSLIMMODE	Enable and disable software position limit and/or transient position limit and/or homing limit.
POSLIMPOS POSLIMNEG	Maximum and minimum of the software position limit.

5.8 Motor Direction

When the motion command is positive, the direction of motion can be reversed. For example, the positive direction of a rotating motor can be clockwise or counterclockwise, depending on the application requirements.

Test and/or inverse and/or confirm the direction of motion in the Motor Setup wizard.

The following parameters are used to define the motor direction:

Table 5-6

VarCom	Description
DIR	Motor direction. DIR can be used to inverse the values of position feedback (PFB), velocity (V) and current (ICMD), thus reversing the direction of motor movement.
MPHASE	Resolver/encoder phase related to standard commutation table. To inverse the rotation direction, the value of MPHASE will be increased by 180 degrees.
MFBDIR	Define multiple direction and polarity settings. The value of MFBDIR is set by MOTORSETUP.

Warning!

The values of DIR and MPHASE must be changed simultaneously before the drive is enabled, otherwise commutation failure (motor runaway) may occur.



Attention !

Les valeurs de DIR et MPHASE doivent être modifiées simultanément avant l'activation de l'entraînement ; sinon, une défaillance de commutation (emballement du moteur) peut se produire.

5.9 New Motor Wizard

Note: If the drive detects the electronic motor nameplate, the New Motor Wizard cannot be used during online operation.

If the motor parameters you use are not available in the default motor library series of ServoStudio2, you can use the "New Motor" wizard to define your motor. Once defined, the new motor will be added to the "User Motor" series in the motor library.

The wizard can be activated from the Motor screen or from the Motor Selection step in the Motor Setup wizard.

Click Define New Motor Activation wizard.

Note:


It is recommended that you activate the "New Motor" wizard from the "Motor" screen, as parameters cannot be saved to the "User Motor" library when activating the wizard from "Motor Setup".

A series of dialog boxes will prompt you to provide motor parameters, which you can extract from the motor data table.

The New Motor wizard allows you to select unit and enter the value based on the information in the motor data table. In addition, the wizard includes

unit conversion function. After entering all the data in the wizard, ServoStudio2 will convert the unit to the equivalent value used by the drive. These conversion value will be retained in the motor library and the drive.

New Motor - Motor Specifications



The 'New Motor' dialog box contains the following fields and options:

- Motor Type:** Rotary Motor (dropdown)
- Motor Name:** DEMO (text input)
- Motor Picture File (optional):** (empty text input with a browse button)
- Motor Peak Current:** 15.0 (text input) with unit dropdown: Ampere peak
- Motor Continuous Current:** 5.0 (text input) with unit dropdown: Ampere peak
- Motor Maximum Speed:** 4500 (text input) with unit: rpm
- Motor Inductance:** 4.2 (text input) with unit: mH
- Motor Resistance:** 1.87 (text input) with unit: ohm
- Motor Poles:** 2 (text input)
- Torque Constant:** 0.016 (text input) with unit dropdown: Nm / Ampere peak
- Rotor Inertia:** 0.03 (text input) with unit dropdown: kg-m² * 10⁻³

Buttons at the bottom: CANCEL, BACK, NEXT.


Figure 5-8 New motor definition

Table 5-7

VarCom	Description
MOTORTYPE	Rotary motor/Linear motor

MIPEAK	Motor peak current
MICONT	Motor continuous current
MSPEED	Maximum motor speed
ML	Motor inductance
MR	Motor resistance
MPOLES	Motor poles
MKT	Torque constant (rotatory motor)
MJ	Rotor inertia (rotatory motor)
MKF	Torque constant (linear motor)
MMASS	No-load motor mass (linear motor)
MPITCH	Motor pitch (linear motor)

New Motor - Motor Feedback Selection



The screenshot shows the 'New Motor' dialog box with the following settings:

- Feedback Type: Tamagawa Incremental Encoder (8 wires)
- Feedback Type = 2
- Motor Encoder Type = 11
- Motor Encoder Resolution: 2500
- Lines per revolution: (dropdown menu)

Figure 5-9 New motor - feedback

Table 5-8

VarCom	Description
FEEDBACKTYPE	Feedback type
MENCTYPE	Motor encoder type
MENCRES	Motor encoder resolution

New Motor - Thermal Protection Definition




The screenshot shows the 'New Motor' dialog box with the following settings:

- Motor Over-Temperature Options
- Motor Over-Temperature Mode: 3 - Ignore thermostat input

Figure 5-10 New motor—thermal protection

Table 5-9

VarCom	Description
THERMODE	Motor over-temperature mode



Motor

Select Motor from Library

Family: User Motors [Define New Motor](#)

Model: DEMO

Save Library

Load from Drive

Write to Drive

Copy to User Library

Delete Model

Verify Stop

☒ Skip Motor ML/MR Estimation

0 %

Name	Value	Units
Motor Type	0	
Motor Commutation Type	0	
Motor Name	DEMO	
Motor Peak Current	15.0	A
Motor Continuous Current	5.0	A
Motor Maximum Speed	4500	rpm
Motor Inductance	4.2	mH
Motor Resistance	1.87	Ohm
Motor Poles	2	poles
Torque Constant	0.016	Nm/A
Rotor Inertia	0.03	Kg*m^2*10^-4
Motor Encoder Resolution	2500	Lines per rev
Motor Over-Temperature Mode	3	

Figure 5-11 New motor - verification



Verification will start the drive and drive the motor!

Complete the program according to the location activated by the New Motor wizard.

- If the New Motor wizard is activated from the Motor screen, click these buttons in the following order:
 - a. Save library, to save the motor parameter set to the "User Motor" library.
 - b. Write to the drive, to send parameters to the drive.
 - c. Verify, to test motor configuration.
 - d. Wait for the message "Motor Setup Successfully" to appear.
- If you have activated the "New Motor" wizard from the "Motor Setup" wizard, click Verify to send the parameters to the drive and test the motor configuration. Wait for the message "Motor Setup Successfully" (failing to save the motor to "User Motor" library

6. Application Setup

6.1 Parameters

6.1.1 Configuration of parameters

VarCom is a set of proprietary commands and variables or parameters used to configure drive functions when the host and the drive communicate through a serial connection.

VarCom parameters can be accessed and controlled through the ServoStudio2 software on the graphical interface screen or the command line terminal screen.

When setting parameters, please pay close attention to any alarm or error messages appearing on ServoStudio2 and any flashing codes on the digital display of the drive.

Disable the drive before setting motor and feedback parameters.

Many parameters can be modified while the drive is enabled.

However, special attention should still be paid because the motor behavior may change.

If the parameters cannot be modified when the drive is enabled, a drive disable prompt will be displayed.

6.1.2 Management of parameters - drive memory

The CDHD2S-PN-RS drive has two memory types used to store drive parameters:

- Flash memory: Non-volatile memory. Save drive default parameter values (contained in the drive firmware) and save parameter sets.
- RAM: Volatile memory. Drive working memory. Parameter values are saved in RAM as you configure and test the drive and adjust parameters. If the drive is powered off, any unsaved parameter changes will be lost.

During power-up, the CDHD2S-PN-RS loads parameter values from non-volatile memory into RAM and calculates a checksum of these parameter values. If the checksum is invalid, the default parameter value (hard-coded into the drive firmware) will be loaded into RAM and set as "parameter memory checksum failure" fault.

Specific parameters can be stored on the electronic motor nameplate (MTP), such as those used in the sensAR magnetic encoder. When detected during power-on conditions, these parameter values are loaded directly from the encoder memory into the drive RAM.

The following figure shows the relationship between different memory types and the commands used to manage drive parameters.




Figure 6-1 Memory and parameter management commands

In ServoStudio2, drive parameters can be saved to non-volatile memory at any time by pressing the save button in the toolbar.

6.2 Application Setup Wizard

The Application Setup wizard will guide you through the drive parameter setting procedure according to the special application.

In the first step, the specific "Application Setup" procedure is defined via the selected "Interface Mode". Subsequent steps may include PDO drawing, position unit definition, gear ratio, limit, return and input and output functions.

Note: When the software is offline, all "Interface Mode" will be displayed.
 When the software is communicating with the drive, only relevant modes are displayed.

Application Setup - Communication




Figure 6-2 ServoStudio2 - application setup - communication




Figure 6-3 ServoStudio2 - application setup - communication success




Figure 6-4 ServoStudio2 application setup operation mode (analog command)

It defines the operation mode of the drive system based on the analog command. Please refer to the *Analog Current Operation Mode* and *Analog Velocity Operation Mode*.

Application Setup - Pulse Train




Figure 6-5 ServoStudio2 - application setup - pulse train

It defines the driving method of the drive system working according to a gearing (pulse train). Please refer to the *Gearing/Pulse Train Operation*

Application Setup - Resolution




Figure 6-6 ServoStudio2 - application setup - resolution (pulse train)

It defines the resolution, gear ratio and feedback parameters of the drive system working according to a gearing (pulse train).

Please refer to the *Gearing/Pulse Train Operation*




Figure 6-7 ServoStudio2 - application setup - resolution (analog command)

It defines the resolution, gear ratio and feedback parameters of the drive system working according to the analog command.

Application Setup - Filter



Figure 6-8 ServoStudio2 - application setup – filter (pulse train)

It defines the resolution, gear ratio and feedback parameters of the drive system working according to a gearing (pulse train).




Figure 6-9 ServoStudio2 - application setup - filter (analog command)

It defines the filtering parameters of the drive system working according to the analog command.

Application Setup - Limit




Figure 6-10 ServoStudio2 - application setup - limit (pulse train)

It defines the limit parameters of the drive system working according to a gearing (pulse train).




Figure 6-11 ServoStudio2 - application setup - limit (analog command)

It defines the limit parameters of the drive system working according to the analog command.

Application Setup - PZD

Receive PZD				Transmit PZD			
名称	对象 (Hex)	描述	值	名称	对象 (Hex)	描述	值
PDO 1			0	PDO 1			0

Figure 6-12 ServoStudio2 - application setup - PZD

Application Setup - Position Unit




Figure 6-13 ServoStudio2 - application setup - position unit

It will be displayed when "Interface Mode" is the following mode:

- PROFINET

Application Setup - Input/Output

Application Setup > Inputs/Outputs			
Input			
State	Input	Function	Polarity
☒	1	Remote Enable	☒ Active High
☐	-	Clear Fault	☐
☐	-	Emergency Stop	☐
☐	2	Positive Limit Switch	☒ Active High
☐	3	Negative Limit Switch	☒ Active High
☐	-	Home Switch	☐
☐	-	Touch Probe	☐
☐	-	Home Command	☐
Output			
State	Output	Function	Polarity
☐	-	Active	☐
☐	2	Brake Release Signal	☒ Active High
☒	1	Alarm	☒ Active High
☐	-	Stopped	☐
☐	-	Homing Completed	☐

Figure 6-15 ServoStudio2 - application setup - input/output

It will be displayed when "Interface Mode" is the following mode:

- Profinet
- Pulse train
- Analog command
- USB/RS232

Application Setup - Return

Application Setup > Homing

Home Type

1 Homing on first index mark after disengaging from negative limit

1. Homing Acceleration

16000.000

rpm/s

2. Homing Speed 1 - Switch Search

100.000

rpm

3. Homing Speed 2 - Index Search

20.000

rpm

4. Home Offset

0.000

rev

5. Automatic Homing Mode

☒ 0 -No Action. User must initiate homing manually.

☐ 1 -Drive will attempt to perform homing after power up.



1 Homing on first index mark after disengaging from negative limit

BACK

SAVE

DONE

Figure 6-16 ServoStudio2 - application setup - return

It will be displayed when "Interface Mode" is the following mode:

- Profinet
- Pulsetrain
- USB/RS232

Application Setup - Save

This option appears in the Application Setup - Return step when the software is communicating with the drive.

6.3Communication

Commissioning the drive via PositionUnits requires serial RS232 or USB connection. After configuring the drive, you can connect the drive to a PLC or controller via an Profinet network.

When communicating via serial RS232/USB connection and pulse train/analog interface, the drive must be set to COMM0E0.

Note: When communicating via Profinet networks, the drive must be set to COMM0E1. COMM0E1 is the factory default setting of the drive.

The following parameters are used to configure and monitor communication:

VarCom	Description
--------	-------------

COMMODE0	<p>When COMMODE0 is in effect:</p> <ul style="list-style-type: none"> ● Enable serial RS232/USB communication. ● Disable Profinet communication. ● PROFINET communication accepts parameter reading and writing, real-time data reading, and cannot be enabled. ● Reference commands are received only through the serial/pulse/analog port. ● Drive can be fully controlled through operation panel and ServoStudio 2 (enabling, motor action, parameter modification). <p>Note: The operation panel and ServoStudio 2 are not given priority.</p>
COMMODE1	<p>Only applicable to CDHD2S-PN-RS models.</p> <p>When COMMODE1 is in effect:</p> <ul style="list-style-type: none"> ● Enable profinet communication. ● Serial RS232/USB communication can be used as a tool for monitoring and modifying parameters. ● Reference commands can be received through the serial/pulse/analog port. ● Drive can be fully controlled by the field bus device. ● The drive or motor cannot be enabled through ServoStudio 2 or the operation panel <p>Note: Certain functions must be performed through ServoStudio 2 or the operation panel. These functions are limited to parameters that do not interfere with the operation of the fieldbus. If you want to set parameters that will interfere with the operation of the fieldbus, the drive will issue an error code on the digital display and/or issue an error message on ServoStudio 2.</p>
BAUDRATE	Set the bit rate of serial communication between the drive and the host.
CANBITRATE	Set the bit rate of CAN bus communication between the drive and the host.

You can establish communication between the host and the drive through the ServoStudio2 communication screen. In addition, the first step in the Motor Setup wizard is to configure communication between the host and the drive.

6.3.1 Serial baud rate

The default baud rate of CDHD2S-PN-RS is 115200. If the settings are changed and saved in the non-volatile drive memory, the saved baud rate will be used when the drive is powered on.

For example, when there is a connection problem, you can try to use a lower baud rate.

Procedure: Modify serial baud rate

To modify the baud rate settings, changes must be made both in the drive and in the ServoStudio2 software.

1. Changing the baud rate in the drive:

- Enter the terminal screen.
- Issue a command to change the baud rate; for example: BAUDRATE19200
- Press enter.

When the enter key is pressed, communication is instantly lost and ServoStudio2 goes offline.

2. Changing the baud rate in ServoStudio2.

- Enter the communication screen.
- Select the same baud rate specified in the drive terminal.




Figure 6-17 Serial baud rate

- Press Connect.

If the operation is successful, ServoStudio2 will reconnect the drive and return to online status.

6.4 Power Rating

When a motor is selected from the ServoStudio2 motor library, the rated power parameters are preset and written to the drive. These parameters are defined by the manufacturer and cannot be modified by the user; if you want to modify these parameters, please contact technical support.

Use ServoStudio2 "Power Rating" screen to view current and voltage values and set certain voltage parameters.

The following parameters are used to monitor and control the power rating.

VarCom	Description
DICONT	Drive continuous current. Defined by hardware. Read only.
DIPEAK	Drive peak current. Defined by hardware. Read only.
OVTHRESH	Bus over-voltage protection level Defined by hardware. Read only.
UVMODE	Define how the drive will respond to an under-voltage fault.
UVRECOVER	Define how the drive will return to normal after an under-voltage fault.
UVTHRESH	Bus under-voltage protection level.
UVTIME	Duration of under-voltage fault before it is blocked.
VBUS	Bus voltage (DC).
VBUSREADOUT	Actual bus voltage of the drive. Defined by hardware. Read only.

6.5 Feedback

When the CDHD2S-PN-RS drive system contains an electronic motor nameplate, the specific feedback parameters will be directly transmitted to the drive after power-on, and it is impossible to operate.

When a motor is selected from the ServoStudio2 motor library, the motor feedback parameters are preset and written to the drive. These parameters are defined by the manufacturer and cannot be modified by the user; if you want to modify these parameters, please contact technical support.

FEEDBACKTYPE defines the motor feedback type used in the drive application.

CDHD2S-PN-RS supports a variety of motor feedback devices, including:

- BiSS-C encoder
- EnDat encoder
- HIPERFACE encoder
- Incremental A-quadrature-B encoder, available without Hall sensor (or reversal tracking)
- Nikon encoder
- Resolver*
- sensAR encoder
- Sine encoder
- Tamagawa encoder

6.5.1 Incremental encoder

Type and resolution

CDHD2S-PN-RS supports multiple types of incremental encoders.

The following parameters are used to configure and monitor the incremental encoder.

Table 6-3

VarCom	Description
MENCTYPE	Encoder type used by the motor.
MENCRES	Encoder resolution, number of lines per revolution of motor. For incremental encoders, MENCRES*4 is equal to the encoder count per revolution.

CDHD2S-PN-RS monitors all encoder signal lines. If any wire is damaged, an A/B disconnection fault will be generated (digital display: r4|Fr4)

Hall signal

The CDHD2S-PN-RS supports single-ended (or open collector) and differential Hall signals.

The following parameters are used to configure and monitor the Hall commutation sensor.

Table 6-4

VarCom	Description
HALLSTYPE	Hall signal type.
HALLS	Read the Hall signal status.
HALLSINV	Convert the polarity of a single Hall signal related to the motor phase UVW.

CDHD2S-PN-RS monitors the Hall signal status. If status 000 or 111 is detected, an illegal Hall fault will be generated (digital display: r6|Fr6).

If the differential Hall signal cannot be detected, a differential Hall disconnection fault will be generated (**r38|Fr38**).

Note:

The differential Hall signal can be used simultaneously with the incremental A and B signals, or as a Hall only using the standard motor feedback C4 connector. If your application requires differential Hall signals as well as incremental A, B, and index signals, please contact technical support.

Encoder index

The encoders usually has an additional channel called marker channel, zero pulse, or index channel. The channel outputs a pulse every revolution, usually a very narrow pulse, which is about a quarter of the pulse width of channel A or B, but it may be wider. The encoder index can be used for return (absolute position reference) and commutation alignment.

You can also use the "Find Index" command in the "Motor Feedback" screen of ServoStudio2 to determine the index signal position.

The following parameters are used to configure and monitor the encoder index.

Table 6-5

VarCom	Description
MENCZPOS	Encoder index position.

CDHD2S-PN-RS monitors the index signal line. If any wire is damaged, an index disconnection fault will be generated (digital display: **r5|Fr5**).

Phase Find

The Phase Find program is used to initialize the commutation of the incremental encoder system.

Note: The "Phase Find" program can only be used on balanced axes; it cannot be used on unbalanced mechanisms such as the vertical Z axis. Additionally, it cannot be used when gantry mode is in effect.

You can also use the "Phase Find" command in the "Motor Feedback" screen of ServoStudio2 to determine the correct commutation.

The following parameters are used to configure phase find.

Table 6-6

VarCom	Description
PHASEFINDMODE	Method used in commutation phase find.
PHASEFIND	Start the incremental encoder system commutation initialization program.
PHASEFINDGAIN	Adjust the gain of the phase find mechanism.
PHASEFINDI	Adjust the current of the phase find mechanism.
PHASEFINDTIME	Duration of phase find mechanism in soft start.

6.5.2 Sine encoder

Sine encoders are very similar to incremental encoders. The difference is that sine encoder sends A and B channels to the drive in the form of 1V peak-to-peak sine wave, and incremental encoder generates digital pulses at the same time.

6.5.3 sensAR absolute magnetic encoder

The sensAR series absolute magnetic encoders are developed by Servotronics.

SensAR encoder has an electronic motor nameplate (MTP), which refers to a set of motor parameters embedded in the encoder's non-volatile memory.

CDHD2S-PN-RS attempts to detect the electronic motor nameplate when powered on. If detected, the motor and feedback parameters will be transmitted directly to the drive, and the user cannot operate them.

ServotronicsPRO2 and PRHD2 motors are often equipped with sensAR encoders.

There are two different types of sensAR encoders:

- Single-turn absolute encoder (FEEDBACKTYPE=12): After restarting, the encoder retains its absolute position within one mechanical rotation. The multi-turn absolute position is 0.
- Multi-turn absolute encoder (FEEDBACKTYPE=19): After restarting, the encoder retains its absolute position within one mechanical revolution, as well as the total number of motor revolutions since the last restart. The multi-turn encoder does not need to return to the original point after each restart.

The multi-turn encoder can store up to 65535 revolutions if it has an external backup battery. The encoder battery is inserted into the battery box on the cable between the motor and the drive. If the cable between the motor and battery box is disconnected, or if the encoder cannot receive battery or drive voltage, the encoder will lose multi-turn revolutions; but the single-turn absolute position will be retained.

The following commands are used to configure and enable a multi-turn absolute encoder.

Table 6-7

VarCom	Description
MTTURNRESET	Reset the counter position of absolute value multi-turn encoder and clear the voltage fault of the battery.
IGNOREBATFLT	IGNOREBATFLT=1 is to prevent the multi-turn absolute encoder from issuing faults caused by dead, disconnected or missing spare batteries, so that the encoder is used as a single-turn absolute encoder.

Replacement of battery of multi-turn encoder

The battery voltage level is measured only during the power-up sequence. If the battery voltage drops below the specified value during operation, no warning or fault will be issued before restarting.

- If the battery power drops below 3.15V, the encoder will issue a low battery warning. The battery should be replaced as soon as possible.

When replacing the battery, keep the drive powered so that the multi-turn position is maintained in memory during the replacement process. Remove the old battery and insert the new battery.

- If the battery power drops below 3.0V, the encoder will issue a battery dead fault (r40); the drive detects the fault and disables the motor. Multi-turn data is no longer reliable.

To replace the battery: power off the drive. Remove the old battery and insert the new battery. Power on the drive. Issue the MTTURNRESET command to reset the multi-turn encoder position counter. The MTTURNRESET command will also clear the fault.

6.5.4 BiSS-C interface

BiSS is an open interface for sensors and actuators. The BiSS-C standard allows suppliers of such feedback devices to define a small set of commands that require the feedback devices to perform specific functions. BiSS-C execution in the drive is bidirectional.

The following commands are used to configure and monitor the BiSS-C feedback device.

Table 6-8

VarCom	Description
BISSFIELDS	Set the number of bits of the position information transmission configuration in the BiSS-C packet and the effective number of bits. It is suitable for both rotary and linear encoders. The value used by the command variable comes from the data table information provided by the encoder manufacturer.
BISSINFO	Return to the related information about BiSS-C device.

6.5.5 EnDat2.x bidirectional interface

The EnDat interface is a digital bidirectional interface for encoders. This interface can not only transmit the position values of the incremental and absolute encoders, but also transmit or update the data stored in the encoders or save new information. The data is transmitted synchronously via the clock signal of the subsequent electronic device. The data type (e.g. position value, parameters, diagnostics) is selected by the mode command sent by the subsequent electronics to the encoder.

CDHD2S-PN-RS supports EnDat2.1 communication protocol, which is a subset of EnDat2.2 protocol. All EnDat2.2 enabled devices support the 2.1 protocol, including commands and queries related to CDHD2S-PN-RS; therefore, all EnDat2.2 enabled devices can be used with CDHD2S-PN-RS.

EnDat2.x can be used with CDHD2S-PN-RS in the following ways:

- EnDat2.x communication only: Suitable for the setting that the drive only depends on the serial data provided by the feedback device (position information source).
- EnDat2.x with Sine/Cosine: Suitable for the following settings (a) the drive performs encoder initialization and uses serial data for position initialization; (b) position update during operation is derived from the sine/cosine signal.

Note: CDHD2S-PN-RS does not support querying and setting parameters during position feedback operation.

The CDHD2S-PN-RS communication rate is 2MHz (to modify the communication rate, please refer to VarComFEEDBACKBR).

EnDat2.x encoder with sine signals: The position feedback (PFB) value is calculated from the HWPOS value and sine/cosine signals during EnDat initialization after power-on and after clearing feedback-related faults. It may take several seconds for initialization to complete. During this time, the position feedback (PFB) value is undefined and therefore the drive cannot be enabled.

EnDat encoder initialization takes approximately 2.5 seconds; during this process, if the drive status is interrogated (using the ST command), the message "ENDAT initialization not completed" will be displayed.

The EnDat encoder +5V DC supply must be switched off during (re)initialization. During EnDat initialization, CDHD2S-PN-RS turns off the DC voltage +5V provided to the encoder. However, if the encoder receives DC voltage +5V from a different source and is not switched off, initialization may fail.

6.5.6 Encoder analog output

The encoder analog output, also known as equivalent encoder output (EEO) or buffer encoder output, is available at the controller interface (C2).

The following parameters are used to configure the analog.

Table 6-9

VarCom	Description
ENCOUTMODE	Turn on or turn off encoder simulation and set functions.
ENCOUTRES	Encoder analog output resolution is expressed by equivalent lines per revolution.
ENCOUTZPOS	Encoder analog output index offset value.

6.5.7 Resolver*

It is a resolver used to measure the position of the motor shaft.

The resolver has a primary winding and two secondary windings - sine and cosine synchronous with motor rotation. The voltage level on the sine and cosine waves is related to the axis position in one magnetic cycle (one pole pair) of resolver.

The resolver usually enables dynamic tracking that is slower than the encoder.

The following parameters are used to configure and monitor resolver feedback.

Table 6-10

VarCom	Description
RESAMPLRANGE	Acceptable range of sine/cosine signal of resolver is expressed as a percentage of its nominal value (plus and minus percentage)
MRESPOLES	Number of electrodes of single resolver feedback device.
RESFILTMODE	Define whether to perform feedback position interpolation on resolver feedback to generate a continuous data stream.
RESBW	Resolver conversion bandwidth. High bandwidth can obtain better dynamic tracking, and the high frequency phase lag is small. Low bandwidth generates low noise. RESBW sets the optimal balance value according to the specific application requirements.

After the drive is powered on, the autotuning of the resolver reference amplitude takes about 3-5 seconds. During this time, the drive cannot be enabled.

6.5.8 Calibration of resolver* and sine encoder

Resolver and sine encoder calibration overview

When the CDHD2S-PN-RS is connected to a motor equipped with a resolver or sine encoder for the first time, the CDHD2S-PN-RS parameters must be calibrated. Calibration is required during system assembly. Since the analog component values may change at any time, it is required to repeat the calibration procedure every two years. After completing the calibration procedure, the calibration parameters will be saved to the CDHD2S-PN-RS.

When calibrating, the CDHD2S-PN-RS needs to read 128 sine signals in one direction or back and forth.

Typically, the 128 sine signals required for resolver generation will require the motor to rotate 128 times. Therefore, it is necessary to make the motor move at a limited velocity through motion commands.

The sine encoder is typically capable of generating 128 sine signals in one rotation of the motor. Therefore, the motor can be operated manually for calibration.

Resolver and sine encoder parameters

The following parameters are used to configure and monitor resolver/sine encoder calibration.

Table 6-11

VarCom	Description
SININITMODE	Enable/disable the automatic calibration of sine and cosine signals of sine encoder or resolver when it is powered on.
SININIT	<p>Activate the program for calibrating sine and cosine signals of sine encoder or resolver. This calibration is to reduce harmonic errors in sine encoder or resolver readings.</p> <p>The program obtains the average value of sine encoder or resolver signal for multi-turn motor rotation, and determines the gain and offset correction.</p>
SININITST	Report the status of the calibration program of the sine encoder or resolver.
SINPARAM	Return to the parameters used to calibrate sine and cosine signals of a sine encoder or resolver. Parameters are expressed in hexadecimal.

Number of motor revolutions required for calibration

If your application has limited stroke, you can run the motor back and forth 128 times. The length of each of these 128 movements must be at least 1.5 sine cycles. If the motor is operated in one direction, the number of revolutions required for calibration is calculated as follows:

$$\text{Resolver: } 128 \div \frac{\text{MRESPOLES}}{2}$$

Where, MRESPOLES refers to the number of individual electrodes in the resolver feedback device.

For example, if MRESPOLES=4, the motor calibration requires 64 revolutions.

$$\text{Sine encoder: } \frac{\text{MENCRES}}{128}$$

Where, MENCRES refers to the number of sine cycles per revolution or per motor pitch.

Motor velocity limit during calibration

During the calibration procedure, the motor velocity should not exceed the following values:

$$\text{Resolver: } \frac{3750 \cdot 2}{\text{MENCRES}} \text{ rpm}$$

$$\text{Sine encoder: } \frac{3750}{\text{MENCRES}} \text{ rpm}$$

Calibrating resolver and sine encoder

Procedure: Calibrate resolver using terminal

1. In the terminal interface, enter the sine/cosine calibration command:

SININIT<Enter>

2. According to your application operation mode, enter a command to run the motor at low speed (e.g., about 800rpm) for about 10 seconds.

3. Enter the sine/cosine calibration status command:

SININITST<Enter>

4. Wait for SININITST to change to 1, then return to 0.

Example: The motor is running in a velocity control loop at 600rpm and a calibration procedure is performed.

```
-->OPMODE
0
-->EN
-->J 600
-->sininit
-->sininitst
1
-->sininitst
1
-->sininitst
0
-->k
-->[
```

Figure 6-17

Procedure: Calibrate resolver using ServoStudio2

1. In the Feedback screen, select Feedback > Resolver.




Figure 6-18


2. In the Motion screen, set parameters such as:

- Select "Operation Mode > Serial Velocity".
- Set the velocity to 600rpm.

Operation Mode

Operation Mode Serial Velocity

Velocity Command ☒ Jog ☐ Alternating



Acceleration 375000 rps/s Jog Command 600 rps

Deceleration 375000 rps/s Time (optional) ms

Figure 6-19

3. In the Feedback screen, make the following settings:

Feedback

Motor Feedback Secondary Feedback

Resolver

Feedback Type = 1 ☐ Inverse Direction

Resolver Conversion Bandwidth 300 Hz

Motor Resolver Poles 2 poles

Resolver Amplitude Range 35 %

Sine/Cosine Calibration Parameters

Sine/Cosine Calibration Status

[Start](#)

Figure 6-20

- Notice that the sine/cosine calibration status is 0.
- Press the "Start" button to begin the calibration procedure.
- Notice that the sine/cosine calibration status changes to 1.
- Wait for the sine/cosine calibration status to return to 0.

Calibration completed.

1. In the terminal interface, enter the sine/cosine calibration command:

SININIT<Enter>

2. According to your application operation mode (current, velocity, or position mode), enter a command to run the motor at a low speed (e.g., 100 rpm). Alternatively, the motor can be run manually.

3. Enter the sine/cosine calibration status command:

SININITST<Enter>

4. Wait for SININITST to change to 1, then return to 0.

Example: The motor is running in a velocity control loop at 6rpm and a calibration procedure is performed.

```
-->OPMODE
0
-->EN
-->J 6
-->sininit
-->sininitst
1
-->sininitst
1
-->sininitst
0
-->sininitst
0
-->sininitst
0
-->MENCRES
128 [LPR]
-->
```

Figure 6-21

Procedure: Calibrate sine encoder using ServoStudio2

Currently, ServoStudio2 does not support sine encoder calibration.

Sine encoder and resolver diagnosis

Overview of sine encoder and resolver diagnosis

When working with a sine encoder or resolver, the CDHD2S-PN-RS measures the sine and cosine signal levels and checks if they are within the specific range. When the signal is out of range, two faults may occur: r4 and r8.

If these faults occur, sine and cosine signals should be recorded to determine whether they are valid.

Record signal

Sine and cosine signals can be recorded by special recording drive - internal data. A typical RECORD (record) command is as follows:

record11000"@ENC SINE"@ENC COSINE

This command records 1000 samples of sine and cosine values at 31.25µs intervals (based on the drive rate).

A typical sine encoder recording might look like the figure below.

Recorded data is expressed in internal drive unit (analog-to-digital converter counts).




Figure 6-22 Sine encoder recording - example

A typical resolver record might look like the figure below.




Figure 6-23 Resolver recording - example

Converting to physical value

The recorded data is expressed in internal drive unit and needs to be converted to physical unit; i.e. drive input voltage.

Since the physical sine and cosine signal scales of the sine encoder and resolver are different, the following equation is used to convert the recorded data:

$$\text{Sine encoder: input voltage} = \frac{\text{recorded value}}{32768} \times \frac{10}{162}$$

$$\text{Resolver: input voltage} = \frac{\text{recorded value}}{32768} \times \frac{10}{325}$$

Check the data diagram

Recorded data can be converted in the ServoStudio2 "Range" screen.

When checking the sine and cosine signals of the sine encoder, you need to calculate as: signal $\times 0.00001883$ ($1/32768 \times 10/16.2$).

The resulting data diagram in the Rang screen will look similar to the figure below. This diagram shows the signal level (expressed in volts) of the actual input signal. As expected, the sine encoder signal is close to 1V peak-to-peak.




Figure 6-24 Sine encoder signal - example

When checking the sine and cosine signals of the resolver, you need to calculate as: signal $\times 0.0000939$ ($1/32768 \times 10/3.25$).

The resulting diagram in the Rang screen will look similar to the figure below. This diagram shows the signal level (expressed in volts) of the actual input signal.




Figure 6-25 Resolver signal - example

6.6 Secondary feedback

Please also refer to *Dual Feedback Position Control Loop Tuning*.

6.6.1 Overview of secondary feedback (dual loop control)

CDHD2S-PN-RS can correct positioning error through secondary feedback device and dual-loop control.

In dual-loop control, two feedback devices (usually encoders) are connected to one axis: one feedback device is mounted on the motor and the other is connected to the load. The load feedback device controls the positioning, while the motor feedback device controls the velocity and current.




Figure 6-26 Dual loop control using secondary feedback

In dual loop control, the secondary (load) encoder acts as primary positioning feedback. Therefore, the following functions are performed on the load feedback:

- Homing, including index homing. Please refer to the *Homing*.
- Encoder analog output. Please refer to *Encoder Analog Output*.
- AB quadrature encoder interpolation.
- Contact probe capture.

Dual loop control is available in the following operation modes:

- OPMODE4 (gearing/pulse train)
- OPMODE8 (serial position)
- CiA402 mode 1 (profile position)
- CiA402 mode 8 (periodic synchronization position)

For dual loop control, the motor feedback device is connected to the CDHD2S-PN-RS feedback connector (C4) and the load feedback device is connected to the secondary encoder pin on the CDHD2S-PN-RS connector (C3).

When using dual loop control, the gearing input must through the controller interface (C2); GEARMODE0, 1 and 2.

Note: When the CDHD2S-PN-RS error correction function is used in a dual control loop system, the secondary (load) encoder value is corrected.

6.6.2 Secondary feedback device

CDHD2S-PN-RS dual loop control can be implemented by using either a rotary motor (MOTORTYPE=0) or a linear motor (MOTORTYPE=2).

In addition, the double loop control secondary feedback device can be AB quadrature, BiSS-C interface or EnDat2.2.

For a stable dual loop control, the effective resolution of the motor encoder must be higher than the effective resolution of the load feedback device. The low resolution of the motor encoder will cause the position loop to issue VCMD (its resolution is too high), and it cannot be executed by the velocity loop. If the load encoder serves closed position and velocity control loop and the motor encoder serves current control loop, a load encoder with high resolution can be used.

6.6.3 Secondary feedback bus

In PROFINET, the drive reports position feedback (PZD G1_XIST1 and XIST_A), velocity feedback (PZD NSOLL_A and NSOLL_B)

- When dual loop is activated, the above objects will be reported based on the load feedback.
- When dual loop is not activated (default), the above objects will be reported based on the motor feedback.

6.6.4 Secondary feedback unit

User unit

Secondary feedback uses the same parameters as motor feedback.

- If the load feedback is a rotary encoder: SFB and SFBVEL are expressed in rotation units: UNITSROTPOS, UNITSROTACC and UNITSROTVEL.
- If the load feedback is a linear encoder: SFB and SFBVEL are expressed in linear units: UNITSLINACC, UNITSLINVEL, UNITSLINPOS.

Secondary feedback motor to load ratio

[LMUNITSNUM/LMUNITSDEN] is the mechanical ratio, defined as follows:

- For a rotating system: the motor rotates once for every n turns of the load.
- For a linear system: the motor rotates once per n millimeter of linear motion.

Load rotating motor and linear encoder - example




Figure 6-27 Load rotating motor (with gear box and ball screw) and linear encoder

Motor reducer speed ratio: 1:11

Ball screw pitch: 20mm

$$\frac{LMUNITSNUM}{LMUNITSDEN} = \frac{1}{11} * \frac{1}{20} = \frac{1}{220}$$

Load rotating motor and rotary encoder - example




Figure 6-28 Load rotating motor and rotary encoder

Motor side pulley diameter: 50mm

Load side pulley diameter: 100mm

N1: Number of teeth of N1 gear (10)

N2: Number of teeth of N2 gear (60)

$$\frac{LMUNITSNUM}{LMUNITSDEN} = \frac{10 \times 100}{60 \times 50} = \frac{1}{3}$$

6.6.5 Secondary feedback parameters

The following parameters are used to configure and monitor dual feedback applications.

Table 6-12

VarCom	Description	Description
SFBMODE	Secondary feedback mode	Activate/deactivate the dual feedback control mode.
SFBTYPE	Secondary feedback type	Feedback device type (rotary or linear) and communication interface.
SFBENCTYPE	AB quadrature encoder secondary feedback type	Load AB quadrature encoder type.
SFBDIR	Secondary feedback direction	Positive feedback from the load.
SFBOFFSET	Secondary feedback offset	Increased offset value of SFB.
SFBRES	Secondary feedback resolution	Resolution of the load feedback device, expressed by the number of lines per revolution or the number of lines per millimeter.
LMUNITSDEN	Denominator of motor and load mechanical ratio	Denominator of conversion factor for motor feedback and load feedback.
LMUNITSNUM	Numerator of motor and load mechanical ratio	Numerator of conversion factor for motor feedback and load feedback.
MFB	Motor feedback position (Read only)	Based on the position of the motor feedback device.
SFB	Secondary feedback position (Read only)	Based on the position of the load feedback device.
PFB	Feedback position (read only)	Position of (motor or load) based on SFBMODE.
MVEL	Motor velocity (read only)	Motor velocity.
SFBVEL	Secondary feedback velocity (Read only)	Load velocity.
SFBVLIM	Secondary feedback velocity limits	Define the maximum load velocity.
V	Velocity (read only)	Velocity of (motor or load) based on SFBMODE.
MACC	Motor acceleration	Acceleration value based on the motor feedback device.
SFBACC	Secondary feedback acceleration	Based on the acceleration value of the load feedback device.
ACC	Acceleration	Acceleration value of (motor or load) based on SFBMODE.
MDEC	Motor deceleration	Deceleration value based on the motor feedback device.
SFBDEC	Secondary feedback deceleration	Deceleration value based on the load feedback device.

DEC	Deceleration	Deceleration value of (motor or load) based on SFBMODE.
-----	--------------	---

6.7 Motor Unit

CDHD2S-PN-RS provides configurable acceleration, velocity and position units for both linear and rotary motor systems. The unit is defined as the user's preference or the specific motor performance being used.

Use the ServoStudio2 Motion Unit screen to view and define motion unit.

The following parameters are used to monitor and configure the motion unit.

Table 6-13

VarCom	Description
UNITSROTPOS	Rotatory system position variable unit.
UNITSROTVEL	Rotatory system velocity variable unit.
UNITSROTACC	Rotatory system acceleration and deceleration variables unit.
UNITSLINPOS	Linear system position variable unit.
UNITSLINVEL	Linear system velocity variable unit.
UNITSLINACC	Linear system acceleration and deceleration variables unit.
PNUM PDEN	User-defined conversion factor for units. Used to multiply the motor revolution (rotary motor) or motor pitch (linear motor) according to the motor type (MOTORTYPE).
FBGDS	Conversion coefficient of velocity of fieldbus driving shaft.
FBGMS	Conversion coefficient of velocity of fieldbus gearing shaft.

6.8 Foldback current

Foldback current is a mechanism used by CDHD2S-PN-RS to protect the drive and motor from overheating due to excess current. Set the foldback current of the drive and motor independently.

The foldback current limits the root mean square (rms) value of the current supplied to the drive and/or motor.

When a motor is selected from the ServoStudio2 motor library, the foldback current parameters are preset and written to the drive. These parameters are defined by the manufacturer and cannot be modified by the user; if you want to modify these parameters, please contact technical support.

Use the ServoStudio2 "Foldback Current" screen to view and configure motor and drive foldback current parameters.

The following parameters are used to monitor and configure the foldback performance.

Table 6-14

VarCom	Description
IFOLD	Drive foldback current
DICONT	Drive continuous current
IFOLDFTHRESH	Drive foldback fault threshold
IFOLDWTHRESH	Drive foldback warning threshold
DIPEAK	Drive peak current
MIFOLD	Motor foldback current
MICONT	Motor continuous current
MIFOLDFTHRESH	Motor foldback fault threshold
MIFOLDWTHRESH	Motor foldback warning threshold
MIPEAK	Motor peak current
MFOLDD	Motor foldback time delay
MFOLDT	Motor foldback time constant
MFOLDR	Motor foldback recovery time
MFOLDDIS	Enable/Disable motor foldback

6.9 Digital Input

The CDHD2S-PN-RS features both regular and fast optoisolated digital inputs. The number of inputs varies with the model. Please refer to the *Input/Output Specifications* table.

- The transmission delay of conventional digital input is less than 1 millisecond.
- The transmission delay of fast digital input is less than 1 microsecond.

Use the ServoStudio2 Digital IO screen to configure and view digital input status.

The following parameters are used to configure and monitor digital inputs.

Table 6-14

VarCom	Description
IN	Read the specified digital input status.
INPUTS	Read all digital input status.
INMODE	Define the digital input function.
ININV	Convert the specified input polarity.

ServoStudio2 includes a drive script tool for compiling digital input instructions. These scripts can modify the drive behavior while the machine is working, such as increasing or decreasing acceleration, starting the action, setting variables, or switching the operation mode. Please refer to the *Digital Input Drive Script Activation* in the ServoStudio2 manual.

6.10 Digital output

The CDHD2S-PN-RS features both regular and fast optoisolated digital outputs. The number of outputs varies with the model. Please refer to the *Input/Output Specifications* table.

- The transmission delay of conventional digital output is less than 1 millisecond.
- The transmission delay of fast digital output is less than 1 microsecond.

Use the ServoStudio2 Digital IO screen to configure and view digital output status.

The following parameters are used to configure and monitor digital outputs.

Table 6-15

VarCom	Description
OUT	Read the specified digital output status.
OUTPUTS	Read all digital output status.
OUTMODE	Define the digital output function.

6.11 Digital Output Control Using Comparison Matching (PCOM)

The drive includes two PCOM modules (PCOM1 and PCOM2) for comparison matching based on position feedback or timer triggering output.

The output is used to activate an external event or device - such as a camera, pick-and-place machine, or measurement device - when the CDHD2S-PN-RS moves through a predefined position or position range.

The two PCOM modules have the same function and can be used to configure pulse or level switching output.

The PCOM module allows three different trigger output configurations.

- Cycle configuration: Trigger output based on the fixed feedback count between positions.

- Table configuration: Trigger output based on the predefined position group.
- Timing configuration: trigger output when there is a time offset with the SYNC0 signal. The controller updates the time offset every cycle.

Note: When using the incremental feedback device, it must be homing before setting any PCOM module parameters.

The following parameters are used to configure and monitor the PCOM module.

Table 6-16

VarCom	CANopen/CoE object		PROFINET parameters	Description
PCOMCNTRL{1 2}	2191h, 2192h,	Sub-Index 0 Sub-Index 0		Configure and match comparison trigger output (PCOM) module.
PCOMDIR{1 2}	2195h, 2196h,	Sub-Index 0 Sub-Index 0		Define whether the motor triggers the output when it moves in negative, positive or any direction.
PCOMEND{1 2}	219Dh, 219Eh,	Sub-Index 0 Sub-Index 0		Position of PCOM module to stop triggering output.
PCOMN{1 2}	219Fh, 21A0h,	Sub-Index 0 Sub-Index 0		Fixed number of feedback counts between each output trigger position.
PCOMSTART{1 2}	219Bh, 219Ch,	Sub-Index 0 Sub-Index 0		Position of PCOM module to start triggering output.
PCOMSTATUS{1 2}	2193h, 2194h,	Sub-Index 0 Sub-Index 0		Actual state of PCOM module.
PCOMTABLE{1 2}	21A1h, 21A2h,	Sub-Index 0 Sub-Index 0		A set of positions to be triggered for output.
PCOMTABLELEN{1 2}	2197h, 2198h,	Sub-Index 0 Sub-Index 0		Number of positions in the PCOM table
PCOMWIDTH{1 2}	2199h, 219Ah,	Sub-Index 0 Sub-Index 0		Pulse output signal width.
DIFPORTMODE	21A3h, sub-index0			Differential (RS422) digital port hardware and output function.
OUTMODEn27 28	209Ch			Output triggered by PCOM module 1 2

6.11.1 PCOM fixed cycle configuration

The cycle configuration is used to output pulses or switch output states at fixed intervals (defined as a set of position feedback counts (PCOMN)). In this mode, the PCOM module continuously compares the actual position with the defined value in PCOMN. When the feedback counter equals PCOMN, the PCOM module triggers the output.

- Two user-defined positions (PCOMSTART and PCOMEND) define the position range within which the position comparison function takes effect and triggers the output.
- The user-defined constant (PCOMN) defines the number of encoder counts (interval) between each output trigger.
- Define the pulse width based on PCOMWIDTH.




Figure 6-28 Position comparison trigger output - cycle configuration

6.11.2 PCOM table configuration

The position table is configured to output pulses at specific positions or switch output states. In this mode, the PCOM module continuously compares the actual position with the position defined by PCOMTABLE. When the feedback counter equals the position in the table, the PCOM module triggers the output.

- For cycle configuration, the pulse width is the defined (PCOMWIDTH)
- The user-defined constant (PCOMN) defines the number of encoder counts (interval) between each output trigger.

Up to 32 user-defined positions (PCOMTABLE) define the specific positions that will trigger output.

Define the number of trigger positions in the table according to the parameter PCOMTABLELEN.




Figure 6-30 Position comparison trigger output - table configuration

6.12 Analog input

The CDHD2S-PN-RS supports both one 16-bit analog input and two 14-bit analog inputs. There are differences between these two input types.

Note The number in the CDHD2S-PN-RS part number indicates that the drive supports one or two analog inputs.

Analog input is used to send commands to the drive through analog voltage. Analog command can control motor velocity or the current supplied to the motor. Analog command can be used when the CDHD2S-PN-RS is operating in "Analog Velocity" mode (OPMODE1) or "Analog Current" mode (OPMODE3).

Use the ServoStudio2 Analog Input 1 panel (and Analog Input 2, if available) in the Analog IO screen to set analog input properties and monitor input values.

6.12.1 Analog input 1

Analog input 1 acts as an analog command for analog velocity (OPMODE1) and analog current (OPMODE3) operation modes. This function cannot be changed.

The following parameters are used to configure and monitor analog input 1.

Table 6-17

VarCom	Description
ANIN1OFFSET	DC voltage offset on analog input.
ANIN1DB	Dead band range of analog input 1.
ANIN1LPFHZ	Low pass filter for analog input.
ANIN1	Analog input voltage. Read only.
ANIN1ZERO	By modifying the analog offset value, the value of analog input 1 signal becomes 0.

6.12.2 Analog input 2

Note Not all drive models have analog input 2.

When a drive has a second analog input, analog input 2 can be used as the analog current limit. In this configuration, parameter ANIN2SCALE is used to set the current limit range in Amperes/Volts.

The following parameters are used to configure and monitor analog input 2.

Table 6-18

VarCom	Description
ANIN2MODE	Define the secondary input function.

ANIN2LPFHZ	This value is the low pass filter used by the analog input. Used to filter the high-frequency noise generated by the output or limit the signal change rate.
ANIN2OFFSET	DC voltage offset on analog input.
ANIN2	Dead band range of analog input 2. Used to prevent the drive from responding to voltage noise near the analog input zero.
ANIN2	Analog input voltage. Read only.
ANIN2ZERO	By modifying the analog offset value, the value of analog input 2 signal becomes 0.

6.12.3 Using analog input as velocity command and current limit

Procedure: Using analog input as velocity command and current limit

Use the following program from ServoStudio2 to configure the CDHD2S-PN-RS. Use analog input 1 as the velocity command and analog input 2 as the current limit.

1. Define the operation mode.

Activate the Movement screen and select operation mode: Analog Velocity (OPMODE1).

When operating in "Analog velocity" mode, a signal is applied to Analog Input 1 and the drive converts the signal into a velocity command.

2. Define velocity scaling.

Velocity Scaling is a user-defined ratio used by the drive to convert analog input into a velocity command. In the example here, the scaling is set up to a velocity command of 100 rpm/V




Figure 6-32 Velocity scaling

3. Define analog input 2 function.

Open a terminal.

Define analog input 2 as current limiter by setting the parameter ANIN2MODE value to 2:

4. Define analog current scaling.

Set the analog current scaling from input 2 by setting the parameter ANIN2ISCALE value.

In the example here, the scaling is 0.5A per volt. The drive will calculate the current limit accordingly.




Figure 6-33 Analog input 2 parameter settings

Note: Since both drive parameter ILIM and analog input 2 define current limit, the drive will recognize the smaller of the two as the current limit at any given time. Use ILIMACT to read actual limit.

The drive parameters ACC and DEC provide acceleration and deceleration limit respectively. If analog input 1 (when used as a velocity command) generates a rate greater than ACC or DEC, the drive will not exceed the ACC and DEC values.

6.13 Analog output

The CDHD2S-PN-RS also has an analog output that can be set to output a voltage equivalent to a specific parameter value.

Use the ServoStudio2 Analog Output panel in the Analog IO screen to set analog output properties and monitor output values.

The following parameters are used to configure and monitor the analog output.

Table 6-19

VarCom	Description
ANOUTMODE	Define analog output function.
ANOUT	Display the analog output value (in volts) set by ANOUTMODE. Read only.
ANOUTCMD	Analog output command (in volt) set by the user in ANOUTMODE0.
ANOUTISCALE	Analog output voltage scaling representing motor current (I) or current command (ICMD).
ANOUTLIM	Analog output command voltage limit for all modes.
ANOUTVSCALE	Analog output voltage scaling representing velocity (V) or velocity error (VE).
OUTMODE	Define the condition that will activate the specified digital output.

6.14 Disabled Mode

The drive may be disabled because the motion controller issues an explicit command or the drive itself responds to a fault condition. When the drive is disabled, the "disabled mode" function can be used under special circumstances to make the motor stop running quickly before turning off the power supply. This can reduce the amount of motor coasting.

Use the ServoStudio2 Emergency Stop screen to select the method and parameters for stopping the motor when the drive is disabled. The disabled mode consists of two mechanisms:

- Active Disable stops the motor by controlling deceleration to zero velocity and then disables the drive. Active Disable cannot be implemented when the drive is operating in current control mode (OPMODE2 or OPMODE3).
- Dynamic braking controls the motor when the drive is disabled by applying the motor back-EMF to the stop current; therefore, it can also be used in the case of feedback loss.

Table 6-20

VarCom	Description
DISMODE	Define how the drive will respond when disabled.
DISMODE0	Non-active disable, non-dynamic braking.
DISMODE1	Non-active disable, dynamic braking on fault only.
DISMODE2	Non-active disable; disable dynamic braking arbitrarily
DISMODE3	Active disable on fault*; non-dynamic braking.
DISMODE4	Active disable on fault*; dynamic braking on fault only.
DISMODE5	Active disable on fault*; disable dynamic braking arbitrarily.

Note: Faults that require immediate disable (to prevent drive damage) and feedback faults that may cause communication errors (motor runaway conditions) cannot issue an active disable.

There are three parameters that affect disable and braking.

Table 6-21

VarCom	Description
DISSPEED	Define the velocity threshold below which the motor is considered stopped and the active disable timer starts the countdown to disable. For a motor to be considered stopped, the motor velocity must be at least 50 ms below this threshold.
DISTIME	Define the continuous time that the motor must remain below DISSPEED before the drive is disabled. DISTIME counter only starts counting after the motor velocity has been lower than DISSPEED for at least 50 ms.
DECSTOP	Define the ramp down deceleration rate.

6.14.1 Active disable

Active disable prevents the motor from coasting when the axis is disabled.

The active disable mechanism stops the motor by controlling the speed to slow down to zero and then disables the drive.

Note: Active disable cannot be implemented when the drive is in current control mode (OPMODE2 or OPMODE3); it is valid in all other operation modes.

Figure 6-34 shows how motor coasting occurs when active disable is not used. The velocity command will be set to zero immediately after the drive is disabled. The actual velocity will then be decreased as a function of inertia and friction.




Figure 6-34 Disable (do not use active disable)

Figure 6-35 shows what happens when active disable is in effect. After the drive receives the disable command, the velocity command will immediately slow down the velocity to zero and then the drive is disabled.




Figure 6-35 Disable (use active disable)

Figure 6-36 shows the effects of DISSPEED and DISTIME. In this example, DISSPEED is set to 1000 and DISTIME is set to 1ms. The motor velocity remains below 1000 for 50ms and after the time defined by DISTIME has elapsed, the drive will be disabled and the motor coasts to a stop.

In this example, it takes approximately 110ms from the time the motor velocity drops below 1000 and the drive is disabled.




Figure 6-36 Impact of DISSPEED and DISTIME on active disable

During the descent process in the active disable mode, the drive will ignore any new motion commands.

If an additional disable command (VarComK) is issued during the descent process, the descent process will be stopped and the drive will be disabled immediately.

Figure 6-37 shows the impact of the second disable command. In this example, DISSPEED is set to 1000 and the second disable command is issued before the motor velocity descend to this level.




Figure 6-37 Impact of the second disable command on active disable

The legend in the "ServoStudio2 Emergency Stop" screen shows active disable behavior.




Figure 6-38 Disable stop

If a digital output is configured for brake control, the brake will be enabled as soon as the DISTIME timer starts counting.

If the internal timeout (calculated based on the actual velocity and DECSTOP) runs out, the descent mechanism will also be suspended, such as the 1 in disable stop figure.

6.14.2 Dynamic braking

The dynamic braking mechanism can disable the drive to control the motor. Only the motor back EMF is used to apply the stopping current. The variable ISTOP is used to set the maximum allowable current during dynamic braking.

Figure 6-39 shows the motor coasting, i.e. without dynamic braking (and without active disable). The velocity command will be set to zero immediately after the drive is disabled. The actual velocity will be decreased due to system inertia and friction.




Figure 6-39 Motor coasting (without dynamic braking)

Figure 6-40 shows what happens when dynamic braking is in effect. As shown in the picture above, the velocity command will be set to zero immediately after the drive is disabled. However, the actual velocity will descend gradually after the brake is applied.

Unlike active disable, velocity does not descend along the motion trajectory. The descend rate is a function of the maximum allowable current (variable ISTOP) and the system inertia and friction.




Figure 6-40 Dynamic braking

Figure 6-41 shows dynamic braking with extremely low ISTOP value. In this case, it takes longer for the motor to stop.




Figure 6-41 Dynamic braking (low ISTOP value)

In both DISMODE4 and DISMODE5 modes, active disable and dynamic braking are supported. In this case, active disable is used to stop the motor and dynamic braking is activated after DISTIME.

6.15 Motor Brake Control Via Relay

The CDHD2S-PN-RS can control the motor brake via an external relay. The relay can be connected to any digital output on the CDHD2S-PN-RS machine I/F (C3) or controller interface (C2). It is recommended to connect digital output 7.

Please refer to the *Motor Brake Wiring* and the following procedures.

The digital output polarity can be changed to match the drive electronics to the motor control circuit.

The CDHD2S-PN-RS disable time can be set through the DISTIME parameter. When the drive receives a disable command, it will turn off the brake output first, then wait for the brake disengagement time to end before actually disabling it.

The brake engagement time cannot be set. When the drive receives the enable command, the brake output is turned on at the same time to complete the enabling. It takes at most 1.5 milliseconds for the drive to complete enabling, while it usually takes tens of milliseconds for the brake to disengage.

Procedure: Configuring the digital output to control the brake

When configuring digital output, please perform the following procedure in ServoStudio2.

1. Define the output.

Go to the Digital Inputs/Outputs screen and set the output (example: Output 1) to Mode "2 - Brake Release Signal".



Figure 6-42 Digital output setup for motor brake control

Default:

- When CDHD2S-PN-RS is enabled, the brake output is on.
- When CDHD2S-PN-RS is disabled, the brake output is off.

2. Go to the Emergency Shutdown screen and set the Active Disable Time (DISTIME). For example, set the value to 30ms.

3. DISTIME defines the time period after the motor falls below the "Active Disable Velocity Threshold" (DISSPEED) until the drive is disabled via the "Active Disable" function.




Figure 6-43 Active disable time (DISTIME)

When the "Disable" command is executed, the CDHD2S-PN-RS immediately changes the brake output value and disables the CDHD2S-PN-RS control after waiting for the Active Disable Time (DISTIME) to end.

When a fault such as STO or loss of feedback occurs, the drive immediately switches the brake output value and disables CDHD2S-PN-RS control.

6.16 Motor temperature sensor

CDHD2S-PN-RS supports two types of motor temperature sensors: thermostat (on/off) and thermistor (thermistor).

The following parameters are used to define the motor temperature sensor type and the response of the drive to over-temperature condition.

VarCom	Description
THERM	Indicate whether the motor has an over-temperature fault.
THERMODE	Define how the drive responds to motor over-temperature fault. If the motor has no temperature sensor, or if the sensor is not wired, set THERMODE=3, and the drive will ignore the fault.
THERMTYPE	Indicate whether the sensor is PTC (positive temperature coefficient) or NTC (negative temperature coefficient) type sensor. When using a thermostat (on/off motor temperature sensor), set THERMTYPE=0 to define PTC type.
THERMREADOUT	Read the temperature sensor resistance.
THERMTRIPLEVELTHE RMCLEARLEVEL	<p>The detection and removal mechanism of motor over-temperature fault is subject to hysteresis mechanism. When the resistance exceeds a certain value, it will trip and the fault can only be cleared when the resistance drops below a different value.</p> <ul style="list-style-type: none"> ● For PTC thermistors, when the resistance is equal to or greater than THERMTRIPLEVEL, the motor over-temperature fault will lead to tripping. When the resistance is equal to or less than THERMTRIPLEVEL, the fault can be cleared. ● For NTC thermistors, when the resistance is equal to or less than THERMTRIPLEVEL, the motor over-temperature fault will lead to tripping. When the resistance is equal to or greater than THERMTRIPLEVEL, the fault can be cleared. ● If the motor temperature sensor is a thermostat, the resistance is zero in normal state and infinite in fault state.

When the drive detects a motor over-temperature condition, it will block the motor over-temperature fault and the digital display will display **H|FH**.

6.17 Error Correction

6.17.1 Overview of error correction

The CDHD2S-PN-RS drive has an error correction function that can cancel repeatable positioning errors.

An error map is generated using an external measurement device such as a laser interferometer. The error map is stored in the non-volatile drive memory. The drive retrieves the correction value in real time based on the actual position and performs dynamic (on-the-fly) correction. After the correction, the error is negligible. Therefore, no additional position feedback device is required.

6.17.2 Error correction table - example

In this example, the load position on the linear axis is measured with a laser interferometer. The axis travel distance is one meter. The drive software commands the motor to rotate every 100mm so that the motor moves through 10 position ranges. As the motor moves the load, the laser system measures the distance traveled by the load, comparing it to the motor encoder position at each point. The difference between the two values is the error correction value.

To ensure smooth movement, the drive performs linear interpolation between the points of the error table. In this example, to move the platform to 275 mm from the origin, the controller selects the two data points closest to the error map (200 and 300 mm) and calculates the correction value for the 275 mm point.

Table 6-23

Motor Encoder position	External measurement position	Corrected value
0	0	0
100	99	1
200	202	-2
300	300	0
400	400	0
500	500	0




Figure 6-44 Laser interferometer measuring travel distance

6.17.3 Error correction function of CDHD2S-PN-RS

The CDHD2S-PN-RS error correction function can be applied in several motor system types:

- Direct drive linear platform
- Direct drive rotary platform
- Linear platform driven by servo drive (motor rotates and the error is linear)
- Rotary platform driven by servo motor (motor rotates and load rotates)

Error correction is available for all absolute and incremental encoders supported by CDHD2S-PN-RS.

Note: When using the error correction function in an incremental system, homing is required.

Note: When the CDHD2S-PN-RS error correction function is used in a dual control loop system, the secondary (load) encoder value is corrected. When the CDHD2S-PN-RS error correction function is used in a single control loop system, the primary (motor) encoder value is corrected.

6.17.4 Error correction parameters and commands

The following parameters are used to configure and execute the error correction function.

Table 6-24

VarCom	Description
ERRCOREN	Define user's request to activate the error correction function.
ERRCORST	Indicate the state of the error correction function after sending the user request (ERRCOREN 1).
ERRCORSTARTPOS	Define the position corresponding to the first valid input of the error correction table.
ERRCORACTIVENUM	Define that effective input times of the error correction table. The error correction table can define (and take effect) up to 1000 inputs.
ERRCORINTERVAL	Define the measurement error and add the distance between the positions where the correction table is located. Defined in unit of (LOAD).
ERRCORUNITS	Define the unit of error position data transmitted through the error correction table.
ERRCORSTARTOFF	Define the offset from the first valid input of the error correction table.
LMUNITSNUM	Denominator of motor feedback and load feedback scaling ratio.
LMUNITSDEN	Numerator of motor feedback and load feedback scaling ratio.
ERRCORRESET	Used to restore all error correction parameters and table inputs to their default values. When ERRCORRESET is set to 1, it will be reset.
ERRCORSETINDEX	Define the correction values specifically entered in the correction table.
ERRCORFAILINDEX	An index indicating that the input of the error correction table failed due to the invalid error size. The error shall not exceed the maximum value of 1 (rotation unit is degree/linear unit is millimeter)
PFBRAW	Position feedback value, excluding error correction and position modulus. Used for troubleshooting debugging.

6.17.5 Error correction feedback unit

Motor load ratio

When using a direct drive linear (DDL) platform or a direct drive rotary (DDR) platform, the motor to load mechanical ratio is 1:1.

$$\frac{LMUNITSNUM}{LMUNITSDEN} = \frac{1}{1}$$

- In this example, the motor and load position feedback (PFB) values and units are the same.

When using a linear platform driven by a servo drive (motor rotates and the load is linear), the mechanical ratio is 1 revolution of the motor per n mm of linear motion.

$$\frac{LMUNITSNUM}{LMUNITSDEN} = \frac{1}{n}$$

When using a rotary platform driven by a servo motor (motor rotates and the load is linear), the mechanical ratio is 1 revolution of the motor for every n turns of the load.

$$\frac{\text{LMUNITSNUM}}{\text{LMUNITSDEN}} = \frac{1}{n}$$

6.17.6 Error correction settings

The following figure shows the parameters used by the error correction map.




Figure 6-45 Error correction map - example

Procedure: Manual configuration and generation of error correction table

Use ServoStudio2 and any measuring device

1. In the ServoStudio2 Error Correction screen, enter the position range settings and setting values for error sampling and correction.

- Start position
- Number of sampling points
- Interval (sampling point spacing)
- Calibration unit (if required)
- Load/motor mechanical ratio (if required)

2. Move the motor to a position that is at least a few millimeters away from the start position (start point) of the error correction table.

3. Move the motor to the start position, and then to several positions consistent with the positions and intervals defined by ServoStudio2.

4. Using a measurement device, perform error correction measurements at each designated position and generate a set of error correction values.

5. In the ServoStudio2 correction table, the index and position values will be displayed based on the values entered on the right side of the screen. Manually enter the correction value for each position, calculated as follows:

- 6.
- 7.
- 8.

9. Table 6-25

Encoder value	Measured value	Corrected value
X1	Y1	$Y1 - X1 = \text{ERR1}$
X2	Y2	$Y2 - X2 = \text{ERR2}$
X3	Y2	$Y3 - X3 = \text{ERR3}$




Figure 6-46 Error correction table - example

10. Save to file (SSV format)

The settings and all indexes in the error correction table are saved to an SSV file.

Procedure: Configure an error correction table for use with RenishawRTL files

Using ServoStudio2 and Renishaw laser interferometer

Note: This procedure is based on RenishawXL=80 laser interferometer and exported RTL file. Renishaw is the only third-party system supported by CDHD2S-PN-RS error correction function at present.

It is assumed that the Renishaw system has been installed in accordance with the manufacturer's instructions and that the user knows how to operate the hardware and software.

CDHD2S-PN-RS|ServoStudio2

1. Make sure CDHD2S-PN-RS is working in serial communication mode (COMMODE0).
2. Configure motor and motor feedback parameters.

3. If using an incremental system, perform homing (HOMECMD).
4. Open the Error Correction screen.

On the right side of the screen, enter the position range settings and setting values for error sampling and correction.

- Start position
- Number of sampling points
- Sampling point interval
- Calibration unit (if required)
- Index offset (if required)
- Load/motor mechanical ratio (if required)

Note The CDHD2S-PN-RS and laser system must have the same physical reference (home) position.

Laser system

5. Use "CARTO Capture - Define Tag" to configure error table.

Select linear definition.




Figure 6-47

6. CARTO Capture - Define Tag > Target menu.
 - a. Define the following settings. Use the same values from the define configuration in ServoStudio2:
 - First target (the first point that will be measured)
 - Last target (the last point that will be measured)
 - Interval (distance between measurement points)
 - Target per round (total number of points that will be measured)
 - b. Define one-way travel: The bidirectional option must be cleared.




Figure 6-48

7. CARTO Capture - Define Tag > Trigger Parameters menu.

Use position triggering. This mode automatically captures data by comparing laser measurements to target positions and records error measurements when the machine is within specified range of tolerance, stability period and stability range.




Figure 6-49

8. CARTO Capture - Capture tab is at the bottom of the screen, press Capture.

(When capture is activated, the laser is reset to 0; if not reset, use the DATUM function.)

The laser system will now perform measurement sampling.




Figure 6-50

CDHD2S-PN-RS|ServoStudio2

9. Issue a command to move the axis to an out-of-range position.

The out-of-range position should be at least a few millimeters from the start capture position. The out-of-range position must be defined as an axis movement from the out-of-range position to the sampling range in the defined direction of laser movement.

10. Issue a command to move the axis from the out-of-range position to the first sampling position.

11. Issue a command to move the axis to the same position where the laser system is set up to perform the measurement. Scripts can be used. Please refer to the example below.

The procedure must include a delay (DELAY) command for each measurement point, with a duration slightly longer than the laser trigger definition time. The recommended value is 5 seconds.

```
#ClearOutput

#Var$start_position=-10

#Var$stop_position=401

#Var$interval=20

#Var$cmd=0

#Var$Vel=80

#Var$index=1

#Var$Corr

en
```

```
#Delay5000  
moveabs-1060  
#Delay5000  
moveabs$start_position$vel  
#delay5000  
#while$cmd<$stop_position  
moveabs$cmd$Vel  
#Delay5000  
#printpfbpfbraw  
#Round$index0  
$corr=errcorsetindex$index  
#print$corr  
$index=$index+1  
$cmd=$cmd+$interval  
#End_While  
k
```

Laser system

12. CARTO capture.

After all sampling is completed, press the Save button to save the error correction data.

13. CARTO exploration. Select Open File.



Figure 6-51

14. From the list, select the data that will be used for error correction and press Export Test (first button) at the bottom of the screen.




Figure 6-52

CDHD2S-PN-RS|ServoStudio2

- 15. In the error correction screen, press Load from File to load the data file saved in CARTO.(*.RTL).
- 16. The data will now be loaded from the file and the error correction table will be imported and displayed.
- 17. Enable option: Activate error correction.
- 18. The yellow line indicates the position that the error correction value is applied.




Figure 6-53

- 19. Use the SAVE command (Save button in the menu bar) to save the error correction table to the non-volatile drive memory.

20. It is recommended that you repeat the measurement process using a laser system and confirm that the error has been reduced.

6.18 Gantry System

6.18.1 Gantry system overview

The gantry system use two parallel axes (Y1 and Y2) to control a single linear axis that is orthogonal (right angle) to the X-axis.




Figure 6-54 Gantry axis

In many gantry systems, the two parallel linear axes (Y1 and Y2) are controlled separately and may interfere with each other, manifesting as vibration, high current consumption, slow acceleration and velocity, and reduced accuracy.

The CDHD2S-PN-RS gantry system synchronizes the two Y-axes through two CDHD2S-PN-RS drives that work together and use high-speed communications to generate and control motion along the Y-axis.

Each Y-axis can be driven by a linear or rotary motor.

Both Y-axes must use the same feedback device type with the same resolution.

6.18.2 Gantry type

The CDHD2S-PN-RS gantry system provides two gantry structure types: rigid and flexible. They are different in the orthogonality of gantry axes and the coupling elasticity of axes.

Gantry type parameters (GANTRYTYPE) must be defined to ensure correct zeroing and appropriate offset compensation.

Rigid gantry system

In a rigid gantry structure, the Y and X axes are strictly orthogonal (at right angles to each other), and the mechanical coupling between them is inelastic. When one Y-axis moves, the other Y-axis moves accordingly without causing any axis offset.




Figure 6-55 Rigid gantry structure

Flexible gantry system

In a flexible gantry structure, the mechanical coupling between one or two Y-axes and the X-axis is elastic.

The differential motion of the two Y-axes causes a certain amount of rotational motion around the center of the gantry. This rotational motion (yaw) is considered a differential axis by the CDHD2S-PN-RS system.

Therefore, the flexible gantry system needs to control the difference between the Y1 and Y2 axis positions.




Figure 6-56 Flexible gantry structure

Flexible gantry yaw alignment

In a rigid gantry system, the yaw value is 0 and the X and Y axes are orthogonally aligned. Therefore, no yaw alignment is required. But in a flexible gantry system, offset may occur. Use parameter GANTRYOFFSET to align yaw.

The GANTRYOFFSET value is the difference (distance) between the Y1 and Y2 reference points. Typically, the reference point is the motor index or home switch.




Figure 6-57 Gantry yaw alignment

If the motor manufacturer's specifications provide the motor index positions of Y1 and Y2, the GANTRYOFFSET value can be simply calculated as the difference between the Y1 index position and the Y2 index position.

If the value of GANTRYOFFSET is unknown, use one of the following methods to determine its value:

- Use an offset measuring device (such as a laser interferometer) to measure manually. This method is regarded as the most accurate and recommended.
- Automatic measurement using parameter GANTRYOFFSET. You can use the command GANTRYFINDOFFST to monitor the measurement status. When the measurement is completed, the GANTRYFINDOFFST value becomes 1. The parameter GANTRYOFFSET represents the measured value. Perform this measurement procedure multiple times to ensure measurement accuracy. To apply and maintain the GANTRYOFFSET value, set GANTRYOFFSETST=1.

Once completed, save the results to drive memory.

System GANTRYOFFSET only needs to be defined once. Subsequent homing commands will use the correct GANTRYOFFSET value. In addition, the flexible gantry system will be aligned according to the GANTRYOFFSET value every time it is powered on or switched from the disabled state to the enabled state.

6.18.3 Gantry control mode

The CDHD2S-PN-RS gantry system is controlled via a pair of two drives mated via communication cables. These two drives are called "paired" drives.

The drive of Y1 axis is the main drive. The gantry main drive receives position commands from the motion controller and executes a position loop on the virtual Y axis (calculated as the average value of Y1 and Y2).

The drive of Y2 axis is a differential drive. The gantry differential drive handles the error between the two axes (Y1 and Y2). In a rigid gantry system, its role is to keep the error between Y1 and Y2 as close to 0 as possible.

Note: While the error can be set to a non-zero value (as defined by the controller), the goal for gantry is usually 0 error between the Y1 and Y2 axes.




Figure 6-58 Gantry control module

Note: Main and differential controllers are available for both rigid and flexible gantry types. However, for rigid gantry, it is not recommended to use a differential controller, and the gain parameter of the differential controller should be set to 0.

In a flexible gantry system using fieldbus, the motion controller can send non-zero reference commands to the gantry differential axis.

The parameter GANTRYCMDTYPE defines whether to accept or ignore (fixed at 0) differential commands.

6.18.4 Gantry operation mode

The CDHD2S-PN-RS gantry drive is only valid in position operation mode.

When COMMODE=0 (serial communication; without fieldbus), the operation mode can be gearing mode (OPMODE4) or serial positioning mode (OPMODE8).

When COMMODE=1 (Profinet communication; with fieldbus), the operation mode can be profile position (opmode1), periodic cycle position (opmode8), and homing (opmode6).

Reference commands can be generated by Profinet, pulse train or serial communication devices.

6.18.5 Gantry parameters and commands

The following parameters are used to configure and monitor gantry applications.

Some parameters apply to both main and differential axes, while others apply only to one gantry axis. Please refer to the VarCom documentation for details.

Table 6-26

VarCom	Description
GANTRYMODE	Define whether the position loop is applied to the mean or the difference between the positions of two gantry motors.
GANTRYCMDTYPE	Define how the gantry drive responds to reference commands. Defines the position feedback value that the drive will report through Profinet object and encoder simulation.
GANTRYALIGNMODE	Define the alignment method of flexible gantry system.
GANTRYTYPE	Define the gantry structure as rigid or flexible.
GANTRYCOMMSTATE	Indicate whether the gantry drive is communicating.
GANTRYINTERFACE	Define the controller interface used to connect the communication cables between gantry drives.
GANTRYMSTRPFB	Gantry main position feedback value= $(Y1+Y2)/2$ (read-only).
GANTRYDIFFPFB	Gantry differential position feedback value= $(Y1-Y2)$ (read-only).
GANTRYMSTRVFB	Gantry main position feedback value= $(V1+V2)/2$ (read-only).
GANTRYDIFFVFB	Gantry differential position feedback value= $(V1-V2)$ (read-only).
GANTRYMSTRICMD	Current command generated by gantry master controller (read-only).
GANTRYDIFFICMD	Current command generated by gantry differential controller (read only).
GANTRYALIGN	Start the gantry Y-axis alignment program.
GANTRYALIGNED	Indicate whether the Y-axis of the gantry is aligned (read-only).
GANTRYFINDOFF	Indicate the program for finding the difference (distance) between reference points Y1 and Y2.
GANTRYFINDOFFST	Indicate the status of gantry offset finding program.
GANTRYOFFSET	Distance difference between reference points Y1 and Y2 Required value of flexible gantry system.
GANTRYOFFSETST	Indicate whether the stored GANTRYOFFSET value is valid and can be used for alignment program.
GANTRYPRTNRMFB	Second (pairing) gantry motor position (read-only).
GANTRYPRTRNICMD	Second (pairing) gantry axis current command (read-only).
GANTRYPRTRNVFB	Second (pairing) gantry motor velocity (read only).

6.18.6 Gantry setup

When setting up a CDHD2S-PN-RS gantry system, perform the following steps:

1. If the gantry system includes limit switches, ensure they are installed as follows:
 - The positive limit switches on Y1 and Y2 must be parallel, and the alignment deviation must not be greater than 5mm.
 - The negative limit switches on Y1 and Y2 must be parallel, and the alignment deviation must not be greater than 5mm.
2. Connect the motor of the first gantry axis to the first drive, and connect the second motor to the second gantry drive. Make sure each pair of power and feedback cables is connected to the right drive.




Figure 6-59 Gantry wiring and communication

3. Gantry drives are connected to each other through two interfaces, C3 and C8. Fast communication between axis drives requires C3 connectors.

Parameter configuration and tuning require C8 daisy chain wiring.

4. Define addresses for each drive. Use HMI panel (medium-voltage models) or rotary switch (low-voltage models). Please refer to the

Drive Addressing section. Restart the drive after setting the address.

Set up and test each axis individually:

Note: For the two gantry Y-axes, the motor cannot be configured with the ServoStudio2 motor setup wizard.

5. The first gantry axis:

a. Configure motor and feedback device parameters according to manufacturer specifications. Use the ServoStudio2 "Motor" screen.

b. Check the current control loop of the first axis.

Open the ServoStudio2 "Motor" screen. Select serial current operation mode. Select parameters IQ (current Q axis) and ICMD (current command) for recording. Enter the Current Command value. Start recording.

If the motor parameters ML (motor induction) and MR (motor impedance) are set correctly, the test results should be good.

If noise occurs, increase the KCD value (minimum level of dead time compensation) from 1 to 10 to improve performance.

c. Test motor movement.

Make sure the second gantry motor drive is disabled.

Open ServoStudio2 operation mode. Select serial current operation mode.

Enter a "Current Command" value less than 10% of MICON (motor continuous current).

When the motor moves, observe the value change in the status bar of ServoStudio2. Ensure that positive values generate positive velocity. If this is not the case, set MFBDIR to reverse the motor feedback direction, and use the ZERO command to adjust MPHASE.

6. The second gantry axis: Repeat step 5.

7. Two gantry axes are tested together.

a. Open the ServoStudio2 gantry screen.

b. In the Configuration tab: Set the ID of main axis and differential axis drives.

c. When both drives are disabled, manually move the gantry platform and observe the position and velocity values of the main axis and differential axis in ServoStudio2.

Make sure that the position values of the two axes increase in the same direction.

Make sure that the velocity values of the two axes also reflect the same direction.

If the directions do not match, modify the DIR of one of the axes.

- d. In the Configuration tab: Define the gantry type as Rigid or Flexible.
8. Execute gantry system homing. Please refer to the *Gantry System Homing* section. If using a flexible system, you must set the GANTRYOFFSET value.
9. Perform gantry main controller and differential controller tuning. Please refer to the *Gantry Tuning* section.

6.19 Homing

CDHD2S-PN-RS provides several methods for homing the motor.

The parameter HOMETYPE defines the time to reverse the direction of motion, the homing trigger (e.g. switch, index) and other conditions during homing.

Homing types 1-14, 17-30 and 33-35 are standard homing methods and are defined in CiA402.

Define additional homing types according to customer requirements.

Use the ServoStudio2 "Homing" screen to define and execute the homing procedure.

The following parameters are used to define and execute the homing procedure.

Table 6-27

VarCom	Description
AUTOHOME	Define whether to perform automatic homing when powered on.
HOMEACC	Acceleration and deceleration values in the homing process.
HOMECMD	Start the homing process.
HOMECMD0	Stop the homing process.
HOMEOFFSET	Set the "zero" position offset (count).
HOMESPEED1	Search the initial velocity used by the homing process in the process of limit switch, zero switch and hard stop.
HOMESPEED2	Search the velocity used by the homing process in the process of homing triggers (which may be index pulses, limit switch transitions, zero switch transitions or other sources (defined by HOMETYPE)).
HOMESTATE	Display the current status of the system homing process.
HOMETYPE	Define the type of homing process that will be executed.

6.19.1 Index homing and motor resolver*

Index pulse homing can be used with resolver motor feedback.

Homing methods: HOMETYPE1-14, 33, 34, -8, -12, -33, -34, -40, -44, -65, -66, -97, -98. The resolver index pulse position refers to the point where the motor mechanical angle (MECHANGLE) is zero.

In order to achieve better accuracy in the homing procedure (i.e. minimum position feedback (PFB) count starting from MECHANGLE0), reduce the value of HOMESPEED2.

6.19.2 Index homing and single/multi-turn encoder

The index pulse homing can also be used with absolute multi-turn and absolute single-turn feedback devices. The index pulse position used for homing is the zero position of the single-turn data.

Homing methods: HOMETYPE1 - 14, 33, 34, -9, -10, -13, -14, -34, -65, -66, -97, -98. In these methods, HOMESPEED1 is used before a limit switch, zero switch, or hard stop is detected.

Once an appropriate sequence time occurs (for example, the direction of the limit switch is reversed), the axis detects the index pulse (or the equivalent signal on the absolute encoder) in HOMESPEED2 motion.

6.19.3 Switch positive edge homing

Homing methods: HOMETYPE24, 28

In some cases, reaching the positive edge with HOMESPEED1 may be too fast, resulting in inaccurate homing position.

In order to improve the homing accuracy of methods 24 and 28, it is recommended to use homing methods -24 and -28. Both methods involve reversing the motion with HOMESPEED2 until the required event occurs.

6.19.4 Gantry system homing

The homing command (HOMECMD) must be sent to the CDHD2S-PN-RS gantry main drive to start and control the two gantry motors to home

In an Profinet system, each drive must be set to the "homing" operation mode (OPMODE6) and then wait to receive a homing command from the motion controller. The homing will be performed first by the gantry main drive, and then the gantry differential drive will be started to home.

Please refer to the *Gantry Setup and Gantry Tuning* section.

Rigid gantry system homing

In a rigid CDHD2S-PN-RS gantry system, the homing requirements and methods are as follows:

- Any standard homing method (HOMETYPE) can be used.
- The HOMETYPE definition is for the Y1 (main) motor and is used on the entire gantry system. The HOMETYPE of Y2 (differential) must be set to HOMETYPE=35 (has no effect on the axis).
- Only the homing reference (index pulse, zero switch, limit switch) is considered for the Y1 motor; the homing reference of the Y2 motor is ignored.
- If the homing type relies on the limit switch to reverse direction during the home search process, the first limit switch detected on Y1 or Y2 will cause a change in direction.
- If the homing type relies on the hard stop to change direction during the home search process, the first hard stop on either Y1 or Y2 will cause a change in direction.

Flexible gantry system homing

In a flexible CDHD2S-PN-RS gantry system, the homing requirements and methods are as follows:

- Each of the two gantry motors must have an index switch or zero switch.
- Apply the same homing type to both Y-axes, and can be any of the following types:
 - HOMETYPE1, 2 (limit switch and index pulse homing)
 - HOMETYPE23, 24, 25, 26, 27, 28, 29 or 30 (limit switch and zero switch homing)
 - HOMETYPE-33, -34 (index pulse homing after hard stop)
 - HOMETYPE-56, -60 (zero switch homing after hard stop)

When the homing command is issued to the gantry host, the following situations will occur:

1. The preliminary rough alignment is performed on both axes. The two are closely aligned with each other but not perfectly aligned.
2. Both axes start moving simultaneously toward the limit switch or hard stop.
3. Both axes move in reverse direction at the same time and search for the Y1 axis homing reference. The axis moves until it reaches the limit switch/hard stop in the opposite direction (on the Y1 or Y2 axis).
4. The axes move in reverse direction at the same time, and search for the Y2 axis homing reference.
5. Finally, to align the two axes orthogonally, the homing process moves the differential axis based on the GANTRYOFFSET value. The gantry system returns to home.

7. Operations

7.1 Power on the drive



Warning! Enabling the drive may cause the motor to move.

Attention! L'activation de l'entraînement peut entraîner le déplacement du moteur.

Three conditions are required to enable the CDHD2S-PN-RS drive:

- No fault.
- The software enable switch must be ON (SWEN=1).
- The remote enable switch must be ON (REMOTE=1).

Use the ServoStudio2 Enable and Fault screen to view and set the conditions required to enable the drive.

The following elements provide a visual indication of the enabled or disabled state of the drive:

- The Enabled|Disabled buttons in the ServoStudio2 toolbar indicate drive state.




Figure 7-1

If it lights up, the drive is enabled (activated). The motor is being energized.

If the light is off, the drive is disabled.

- The decimal point 1 on the digital display of the drive indicates the enabled/disabled state of the drive.

If it lights up when the operation mode is displayed, the drive is enabled, as shown in the example here.

If not, the drive is disabled.

7.2 Drive Operation Mode

The CDHD2S-PN-RS can run in multiple operation modes. Each operation mode has a main control loop (current/torque, velocity or position) and a specific type of command input.

When using the VarCom instruction, the operation mode is set via the OPMODE value:

0=Velocity control, using serial commands

1=Velocity control, using analog inputs

2=Current control, using serial commands

3=Current control, using analog inputs

4=Position control, using pulse/gearing inputs

8=Position control, using serial commands

7.3 Current Operation

7.3.1 Serial current operation

In serial current mode (OPMODE2), only the current loop is active and the drive responds to commands received via the USB or RS232 port.

Other than tuning the current loop, no drive variables need to be set to operate the drive in this mode.

In the ServoStudio2 "Movement" screen, select "Operation Mode" - Serial Current, which is used to modify and test parameters.

7.3.2 Analog current operation

When operating in the analog current mode (OPMODE3), only the current loop is active and the drive responds to analog commands from the main analog input (connected at controller I/F (C2) pins 8 and 26).

In the ServoStudio2 "Movement" screen, select "Operation Mode" - Analog Current, which is used to modify and test parameters.

7.3.3 Current control

Note: It is not necessary to change the values in the Current Loop screen unless requested by technical support.

Current control loop tuning is derived from motor properties and bus voltage. In the ServoStudio2 "Motor Setup" wizard, the current control loop is tuned.

7.4 Velocity Operation

7.4.1 Serial velocity operation

In serial velocity mode (OPMODE0), the drive current and speed loops are active and the drive responds to commands received via the USB or RS232 port. The command specifies that the velocity is subject to acceleration and deceleration limits.

In the ServoStudio2 "Movement" screen, select "Operation Mode" - Serial Velocity, which is used to modify and test parameters.

7.4.2 Analog velocity operation

When operating in "Analog Velocity " mode (OPMODE1), the drive current and velocity loops are active and the drive responds to analog commands from the main analog input (connected at controller interface (C2) pins 8 and 26).

The command specifies that the velocity is subject to the acceleration limit defined by the variable ACC.

7.4.3 Velocity control

Please refer to VarComVELCONTROLMODE.

- PI controller (using KVP and KVI)
- PDFF controller (using KVP, KVI, KVFR)
- Standard pole placement controller (using MJ, MKT, BW, LMJR, TF)
- HD velocity loop (with integrating circuit) (using KNLD, KNLP)

HD velocity control (with integrating loop) (recommended)

Please refer to VarComVELCONTROLMODE7.

Before using the HD velocity controller, first execute the ServoStudio2 "Autotuning" wizard, then adjust the tuning manually (if necessary).

You can then continue using the HD velocity controller.

VELCONTROLMODE7 has the velocity control advantage of HD nonlinear controller.




Figure 7-2 Velocity control loop - HD velocity control (with integrating circuit)

proportional-integral (PI) controller

Please refer to VarComVELCONTROLMODE0.

The figure below shows the PI controller.




Figure 7-3 Velocity control loop - PI controller

The PI controller is a unit feedback system without prefilter. The proportional gain (KVP) stabilizes the system and The integral gain (KVI) compensates the steady-state error.

The controller parameters KVP and KVI as well as KVFR are tuned through trial and error.

Pseudo-differential feedforward feedback (PDFF) controller

Please refer to VarComVELCONTROLMODE1.

The figure below shows the PDFF controller. Like the PI controller, the PDFF controller has an integral gain (KVI) and a proportional gain (KVP), plus a feedforward KVFR.




Figure 7-4 Velocity control loop PDFF controller

When the application requires maximum responsiveness, less integral gain is required and KVFR can be set to a high value. When the application requires maximum low-frequency stiffness, KVFR is set to a low value, allowing high integral gain without causing overshoot. This will also cause the system to respond to commands slowly. Moderate KVFR values are generally suitable for motion control applications.

PDFF is a generalized controller. The control parameters KVP, KVI and KVFR are tuned through trial and error.

Standard pole placement (PP) controller

Please refer to VarComVELCONTROLMODE2.

For pole placement (PP) controller tuning, only two parameters are required: load inertia ratio (LMJR) and closed loop system bandwidth (BW).




Figure 7-5 Velocity control loop - standard pole placement (PP) controller

For controller design, it is not necessary to know the load inertia. Parameter tuning is simple, as described in the following procedure. Use the following procedure to manually tune a pole placement (PP) velocity controller.

Procedure: Manual tuning of pole placement (PP) velocity controller

Manual tuning consists of an initial step of load inertia estimation, and subsequent steps of designing an optimal controller.

In ServoStudio2, go to the Terminal screen or Terminal tab and perform the steps using the standard ASCII protocol. In addition, it is possible to use the ServoStudio2 Range screen to perform and record movements, and to evaluate and adjust parameters.

1. Set operation mode to serial velocity: OPMODE0.
2. Set the velocity compensator to standard pole placement: VELCONTROMODE2.
3. Enable drive: EN.
4. Set the required bandwidth. It is recommended to start with a low value (10Hz) and increase it gradually.
5. Set the load inertia ratio to zero: load/motor inertia ratio (LMJR)0.

The load/motor inertia ratio (LMJR) is expressed as a percentage of the moment of inertia.

The load/motor inertia ratio (LMJR) range is 0 to 10,000. This range value represents the range of load to inertia ratio (from 0:1 to 100:1). For example, to set the ratio of load inertia to motor inertia to 10:1, use the command load/motor inertia ratio (LMJR) 1000. At this time, the step response should have maximum overshoot, but the control loop should be stable (low gain).

6. Activate the recording mechanism to record velocity command, current command and actual (feedback) velocity: RECORD11024 "VCMDICMDV

7. Jog the motor at constant low velocity: J[value 1]

For example: start with command J150

8. Activate recording trigger: RECTRIGVCMD[value2]201.

Value 2 should be greater than value 1 from the previous step; for example: RECTRIGVCMD200201.

9. Jog the motor at a velocity higher than that specified in the RECTRIG command. This is actually a step command. The higher the step size, the better the results. The step distance should be no less than 300(rpm). For example: J500.

10. Recording takes about half a second. After this, reduce the motor velocity.

11. Check whether the recording process is terminated: REC is completed.

12. Display data recorded by dumping to serial port: GET

13. Analyze the results.

If the current command is saturated during the process (the absolute value of ILIM is obtained), reduce the step size or bandwidth, and then return to step 6.

14. Check the feedback velocity:

- If a negative pulse signal or vibration occurs, reduce the load/motor inertia ratio (LMJR) to the average value of the current load/motor inertia ratio (LMJR) and the last load/motor inertia ratio (LMJR) with an overshoot signal, and then Go back to step 6.
- If an overshoot signal occurs, increase the load/motor inertia ratio (LMJR) by 100, and then return to step 6.
- Repeat the process until the overshoot is minimized

(Load/motor inertia ratio (LMJR) may ask for estimated load inertia.)

7.5 Position Operation

7.5.1 Serial position operation

CDHD2S-PN-RS has a dedicated operation mode (OPMODE8) for simple serial port positioning applications. The host transmits serial commands through the serial port. The command specifies the target position and cruise velocity, and sets additional trajectory information (such as acceleration, deceleration and trajectory type) with explicit variables.

In the ServoStudio2 "Movement" screen, select "Operation Mode" - Serial Position, which is used to modify and test parameters.

Table 7-1

VarCom	Description
ACC	Define the acceleration.
DEC	Define the deceleration.
PE	Position error (also called following error). PE is the calculated absolute difference between PCMD and position feedback (PFB). Read only.
PCMD	Position reference command. Read only.
PFB	Actual position based on motor feedback. Read only.

Incremental (relative) motion

Incremental or relative motion moves the motor relative to its current position. Relative motion is always referenced to the current position of the load (and motor shaft) and can be used in indexing applications such as fixed-length shear feeders and turntables.

Reference point parameter position feedback (PFB) is the actual position obtained based on motor feedback.

The movement can be carried out in any direction, depending on the position value mark. For example, if the target position is one revolution, the motor will make one revolution from the starting point.

Table 7-2

VarCom	Description
MOVEINC	Command to perform incremental position movement according to the effective acceleration setting.

The position feedback (PFB) value can be modified or compensated using parameter PFBOFFSET. This parameter is used for manual homing, or just for testing incremental motion.

Procedure: Set current position to 0

1. Enable the drive (PFBOFFSET can only be set if the drive is disabled).
2. Set PFBOFFSET to 0 (zero).
3. Read position feedback (PFB).
4. Set PFBOFFSET to a negative position feedback (PFB) value.

5. When using counts as the position unit, PFBOFFSET can only be set to an integer value, even if the actual position feedback (PFB) count of real value display contains fractions (due to internal interpolation of the encoder signal).

Absolute motion

Absolute motion is always relative to an absolute reference point.

Reference point position feedback (PFB)=0 point.

Table 7-3

VarCom	Description
MOVEABS	Command to perform incremental position movement according to the effective acceleration setting.

End of motion

The following parameters are used to define and represent the motor state at the end of the motion.

Table 7-4

VarCom	Description
PEMAX	Maximum allowable counting position error (no fault).
PEINPOS	<p>Tolerance window that declares "in position" status.</p> <p>When PE (position error) value is less than the PEINPOS (position error tolerance) value, the motor is considered to be in position.</p> <p>When PE (position error) value remains lower than PEINPOSTIME within the time defined by PEINPOS, the motor is considered to be stable.</p>
INPOS	<p>Indicate the "motor in position" state. Read only.</p> <p>When the motor is in position, INPOS=1, regardless of the motion trajectory state.</p> <p>When the motor is not in position, INPOS=0.</p>
STOPPED	<p>Indicate the "motor stable" state. Read only.</p> <p>STOPPED=-1. Motion is interrupted.</p> <p>STOPPED=0. The motion trajectory is in progress.</p> <p>STOPPED=1. The trajectory is completed.</p> <p>STOPPED=2. The trajectory is completed and INPOS=1.</p>

7.5.2 Position control

The CDHD2S-PN-RS has two position control loop options - HD (non-linear) and linear.

HD (non-linear) position controller

HD position control is a proprietary algorithm designed to minimize position errors during movement, and to minimize settling time at the end of movement. We recommend this controller. Please refer to the *Tuning*.




Figure 7-6 Position control loop - HD controller

Linear position controller

Linear position controller is a feedforward PID controller with limited integral saturation (anti-terminal) option.




Figure 7-7 Position control loop - linear

7.6 Gearing/Pulse Train Operation

In the gearing/pulse train operation mode, the drive current, velocity and position loops are active loops and the drive is synchronized to the main input command signal of the pulse train. The CDHD2S-PN-RS can be configured to read this input signal as an encoder follower, up/down counter, or pulse/direction counter.

In the ServoStudio2 "Movement" screen, select "Operation Mode" - gearing/pulse train to modify and monitor parameters.

Various gearing methods are defined by the parameter GEARMODE.

Table 7-5

VarCom	Description
GEARMODE0	Encoder following; send a signal through the controller interface (C2). Signals are received at pins 28 and 11 (quadrature A) and pins 9 and 27 (quadrature B) through the controller interface.
GEARMODE1	Pulse and direction; send a signal through the controller interface (C2). Signals are received at pins 28 and 11 (pulse) and pins 9 and 27 (direction) through the controller interface.
GEARMODE2	CW/CCW (up/down); send a signal through the controller interface (C2). Signals are received at pins 28 and 11 (CW) and pins 9 and 27 (CCW) through the controller interface.
GEARMODE3	Encoder following (secondary encoder); send a signal through the machine interface (C3). Signals are received at pins 1 and 11 (quadrature A) and pins 2 and 12 (quadrature B) through the machine interface.
GEARMODE4	Pulse and direction (secondary encoder); send a signal through the controller interface (C3). Signals are received at pins 1 and 11 (pulse) and pins 2 and 12 (direction) through the controller interface.

Note:

GEARMODE0:

The controller interface (C2) cannot supply voltage to the handwheel or the main encoder of the machine. This voltage is only available from the machine interface (C3).

GEARMODE0, 1, 2:

If inputs 5 and 6 are set for INMODE17 and 18 respectively, signals are received from fast inputs 5 and 6 at controller interface (C2) pins 32 and 15.

Regardless of whether gearing mode is used, the input signal needs to be geared, allowing you to set the input pulse ratio to the encoder count. Gearing establishes the relationship between the number of input pulses (HWPEXT counts) and the motor shaft position increment. The occurrence rate of motor shaft (motor velocity) position increment is determined by gearing relationship and pulse train line frequency. The gearing relationship is as follows:

$$\frac{\text{GEARIN}}{\text{GEAROUT}} \times \frac{1}{\text{XENCRES}}$$

In addition to tuning the current, velocity, and position loops, the following table shows some of the parameters used to configure and monitor the gearing.

Table 7-6

VarCom	Description
GEAR	Activate the gearing function.
GEARIN	Gearing ratio numerator. GEARIN value symbol determines the direction of rotation.
GEAROUT	Gearing ratio denominator.
XENCRES	Resolution of external pulse source.
HWPEXT	Position measured by the external feedback device.

7.6.1 Pulse and direction

In "pulse and direction" position control, the drive is synchronized to a main input command signal in the form of a pulse train.




Figure 7-8 Pulse and direction position control

The drive receives each rising edge of the pulse to increase (or decrease, depending on the direction) the external input position counter (HWPEXT) of the drive by one position count. This counter value is transmitted through the gearing module and becomes the motor position command.

Compare the position command and the motor position (PFB) to determine the position error (PE). The drive corrects the position error by incrementing the motor to the commanded position.

In the "pulse and direction" mode, if the absolute value of GEARIN is equal to GEAROUT, and XENCRES is equal to $4 \times \text{MENCRES}$ (i.e. the resolution of the motor encoder after quadrature), then one input pulse is equivalent to one motor feedback count.

For example, assume that the motor encoder resolution is 2500 lines per revolution. If you set GEARIN=1, GEAROUT=1 and XENCRES=10000, this will cause the motor to rotate once every 10000 pulses (assuming the direction is fixed during this period).

Note: The drive homing function remains active in this configuration.

Pulse and direction operation

For "pulse and direction" operation, the pulse signal must be defined as digital input 5 (INMODE517) and the direction signal must be defined as digital input 6 (INMODE618).




Figure 7-9 Setting pulse and direction commands using optoisolated inputs

Step 1 - Setup and tuning

1. Run the ServoStudio2 "Motor Setup Wizard" to ensure that the motor setup is completed successfully.
2. Run the ServoStudio2 "Autotuning Wizard" to ensure that the autotuning is completed successfully.

Step 2 - Select pulse and direction

1. In ServoStudio2, enter the "Operation Mode" screen and select "Operation Mode - gearing/pulse train" (OPMODE4).
2. In the pulse train tab, select "pulse train source" and "pulse train type":

- If using "differential":

Select controller I/FRS422 and the pulse and direction (P&D) option.

- If using "optoisolated":

Select controller/F optoisolated and pulse and direction (P&D) options. This option will automatically set the definition for digital inputs 5 and 6.

Step 3 - Digital inputs 5 and 6 setup (optoisolated inputs only)

1. Enter the "Drive Configuration > Digital IO" screen.
2. Make sure digital input 5 is set to a 17-pulse signal.
3. Make sure digital input 6 is set to the 18-directional signal.



Figure 7-10 Digital input of pulse and direction signals

Step 5 - Set pulse and direction parameters




Figure 7-11 Pulse and direction operation parameters

1. Make sure gearing mode is enabled (GEAR=1).
2. In the Ratio tab, set the input resolution and gear ratio.

The relationship between input pulse and motor shaft motion is determined by the external encoder resolution (HWPEXT) and the gear ratio (GEARIN/GEAROUT).

For example: Set the PLC controller to provide 1024 line pulses as a CDHD2S-PN-RS system input command to make the motor rotate two turns. The settings should be as follows:

External encoder resolution=1024

Gear ratio multiplier = 2

Gear ratio divisor=1

3. In the Filter tab, set and adjust the gear filter and command smoothing filter as needed.
Command smoothing filter

- Smoothing filter (MOVESMOOTHMODE). Select this option to activate the filter.
- Hard/Soft (MOVESMOOTHAVG). Drag the slider to adjust the value.
- Gear command smoothing filter
- Gear noise filter (GEARFILTMODE). Select this option to activate the filter.
- Hard/Soft(GEARFILTDEPTH). Drag the slider to adjust the value.

7.6.2 CW/CCW (up/down) counting

In a CW/CCW (or up/down) system, a pulse on one signal increases motor position, while a pulse on the other signal decreases motor position. The signal must be connected to the controller interface (C2).

When a pulse signal is applied to the A channel, the external position counter (PEXT) is incremented and the motor is rotated in the positive direction. When a pulse signal is applied to the B channel, the external position counter (PEXT) is decremented and the motor is rotated in the negative direction. Line frequency and gearing relationships determine the velocity and amount of shaft movement.

- Set GEARMODE to 2 and inform the drive to receive signals via the pulse and direction inputs on the control interface (C2).

7.6.3 Encoder follower (master/slave)

In encoder follower mode, the drive follows the quadrature encoder signal generated by the master. The direction of movement is determined by quadrature signals (A is ahead of B, or B is ahead of A).

For example, the master device could be a handwheel, a machine main encoder (connected to the main camshaft), or the equivalent encoder output of another servo drive.

If the master device is a handwheel or a main encoder, after setting XENCRES equal to the encoder resolution (before quadrature) and setting the gear ratio to 1, the motor will rotate once for each input revolution.

For example, assume that the handwheel resolution is 120 lines per revolution (i.e., 480 counts after quadrature). After setting GEARIN=1, GEAROUT=1 and XENCRES=120, the motor will rotate once every turn of the handwheel.

Quadrature signals can be connected to the controller interface (C2) or the machine interface (C3). The GEARMODE parameter informs the drive the interface to which the signal is connected.

- Set GEARMODE to 0 and inform the drive to receive signals via the pulse and direction inputs on the controller interface (C2).

Note that the controller interface (C2) cannot provide voltage to the handwheel or the main encoder of the machine.

- Set GEARMODE to 3 and inform the drive to receive signals through the secondary encoder input on the machine interface (C3).

8. Turning

8.1 CDHD2S-PN-RS HD Controller

The CDHD2S-PN-RS has two user-selectable position control loops - linear and HD (non-linear).

The HD control loop is a proprietary algorithm designed to minimize position errors during movement and settling time at the end of movement.

The HD algorithm uses a parallel configuration where all branches are executed at the same level and within the same sampling period. Introduce variable gain on each branch and automatically optimize for high gain and stability.

The HD controller also includes an adaptive feedforward feature that is applied at the end of the movement to deliver zero or minimal settling time. In addition, the HD controller provides low-pass, notch, and other filters to handle flexible and resonance systems.

The ServoStudio2 Position Control Loop screen provides user-modifiable access to HD control loop parameters.




Figure 8-1 CDHD2S-PN-RS HD control loop

8.2CDHD2S-PN-RS HD Controller Autotuning

Warning! Tuning is potentially dangerous. Before starting any tuning procedure, make sure no one is within the motion envelope curve and that the panic button is within reach.



Attention ! Le réglage est potentiellement dangereux. Avant de lancer toute procédure de réglage, assurez-vous que personne ne se trouve dans la zone d'enveloppe de mouvement et que le bouton d'arrêt d'urgence est à portée de main.

Perform autotuning on the HD control loop of the CDHD2S-PN-RS. There is no autotuning procedure for linear control loop.

Initially use the Autotuning wizard to set the HD control loop parameters. Drive tuning performed by the wizard is usually sufficient. However, you may need to manually tune control parameters to optimize them for your specific application. Parameters can be viewed and modified in the ServoStudio2 Position Loop - HD Controller screen.

Automatic and manual tuning use similar methods. During the autotuning, the movement quality is measured and evaluated by the drive or software. During manual tuning, the quality of movement is evaluated by the user. In both cases, modify the servo control parameters step by step and select the values that deliver the best performance.

The Autotuning wizard can also be used to optimize drive parameters to produce the most efficient transmission for a specific task or application. Setting and optimizing parameters via the Autotuning wizard can be drive-based or PC-based:

- If an electronic motor nameplate is detected at power-up (such as PRO2 and PRDH2 motors with sensAR magnetic encoders), or if the software is running offline, ServoStudio2 will activate the drive-based autotuning wizard.
- If no electronic motor nameplate is detected at power-up, ServoStudio2 will activate the PC-based autotuning wizard.

8.3Drive-based autotuning

If an electronic motor nameplate with a servo parameter bundle is detected at power-up (e.g. PRO2 and PRHD2 motors with sensAR magnetic encoder), ServoStudio2 will activate the drive-based autotuning wizard. This wizard is also activated if the software is run offline.

There are four possible common options for drive-based autotuning: Fast/Internal, Fast/External, Advanced/Internal and Advanced/External.

- Fast autotuning requires no user input, just activate each step.
- Advanced autotuning requires user input.
- Internal reference - Drive commands used for tuning are generated by the drive.

- External reference - Drive commands used for tuning are generated by an external controller (e.g. PLC).

8.3.1 Drive-based autotuning - fast

Fast autotuning requires no user input, just activate each step.

Fast autotuning consists of the following steps:

1. Select Fast/Internal or Fast/External.
2. Start autotuning.
3. Test results.
4. Save parameters.

For details on each step, please refer to the *Drive-Based Autotuning - Advanced*.

Table 8-1 Drive-based autotuning process steps

	Fast	Advanced
Model	x	x
Inertia		x
Movement		x
Options		x
Start	x	x
Test	x	x
Save	x	x

8.3.2 Drive-based autotuning - advanced

The advanced autotuning process includes the following steps:


1. Select Advanced/Internal or Advanced/External.

Optional: Manually move the axis to the start position (available when the drive generates gearing). If necessary, use the positive and negative buttons to place the load in a position where the motor can safely rotate three times in each direction.

2. Load/motor inertia ratio estimation.
3. Set the transmission profile.
4. Set parameter optimization options.
5. Run autotuning.
6. Test results.
7. Save parameters.

Click Next to proceed to the next screen during this procedure.

Step - Tuning mode



Autotuning > Mode Selection

Express Mode Internal Reference

Express Mode External Reference

Advanced Mode Internal Reference

Advanced Mode External Reference

Manual Move ▼

Speed (rpm) 5

Press and hold to move motor

Positive Negative

BACK NEXT


Figure 8-2 Autotuning - tuning mode

1. Select Advanced/External (or Advanced/Internal).
2. Transmission testing usually begins at the midpoint of the motion stroke. If your application requires a different start position, use Manual Move.

Use the negative and positive buttons to place the load in a position where the motor can safely rotate three times in each direction. Press and hold the button for continuous transmission.

3. Click Next to continue.

Step - Load/Motor inertia ratio



Autotuning > Run Inertia Estimation

Selected Options	Tuning Status
Maximum motion for load inertia estimation	Status:
Motor will move back and forth	Running
Distance 3.000 [rev]	Cycle Info:
Velocity 500.000 [rpm]	Start From Default Gains
Acceleration 62500.000 [rpm/s]	Cycles: 0
	General:
	LMJR Est

7%

Start Stop

Figure 8-3 Autotuning - inertia ratio estimation

Typically, you should allow the servo drive to estimate the load/motor inertia ratio (LMJR).

You may need to manually set the moment of inertia (step 4 - option: load/motor inertia ratio (LMJR) value) to get better performance, for example:

- If the load/motor ratio is very large.
- If you know the exact value of the load inertia connected to the motor.
- If the load inertia changes.
- If using a multi-axis robot.

Step - movement

Note: movement steps are only available if the drive (internal) is a gear generator.



Figure 8-4 Autotuning - transmission profile. Not applicable




Figure 8-5 Autotuning - transmission profile. Applicable

Autotuning must be performed using transmission profile, replicating the actual mechanical characteristics of the motion performed in the application. Click Set Defaults to set values that produce a good trapezoidal profile on the graph.

The software will indicate whether this profile is suitable for the autotuning procedure.

- Highlight orange: profile available, but not recommended
- Highlight red, profile not available

Step - Autotuning options




Figure 8-6 Autotuning - options

Option: Vibration suppression

Select Vibration Suppression for the autotuning vibration suppression parameter sets (anti-vibration 2 and anti-vibration 3).

Clear this option if you want to set the vibration reduction parameters manually or apply without vibration reduction.

Increased anti-vibration may lead to the following effects:

- Vibration will be suppressed, thus improving settling time.
- High HD loop gain is allowed.
- Increasing the position error of the motor, but the position error and vibration of the end effector will be decreased.

Option: Vertical application

Select this option for gravity compensation when the axis moves vertically. If checked, autotuning will set the value of parameter IGRAV. Clear this option if the axis moves in two directions in a balanced (non-vertical) way.

Options: Acceleration feedforward

Select this option to reduce tracking errors during exercise. If checked, autotuning will set the value of parameter KNLAFC. If the overshoot is too large, clear this option.

Options: Smoothing

Select this option to automatically tune the input profile command. If checked, autotuning will adjust the profile smoothing parameters. Clear this option if the application is multi-axis and requires equal smoothing on all axes.

If cleared, MOVESMOOTHAVG is used, and its value is in the range of 1-15 ms.

Option: Load/motor inertia ratio (LMJR) value

Typically, autotuning can use the load/motor inertia ratio (LMJR) value calculated in the autotuning step - inertia ratio estimation.


If you need to change the load/motor inertia ratio (LMJR) value detected by the drive, please use this option. Enter a load/motor inertia ratio value.

Please refer to "Step - Load/Motor Inertia Ratio".

Step - start

Click start to run the autotuning process.

Start repeatedly enabling the drive and running the motor!



Autotuning > Run Autotuning

Selected Options	Tuning Status
User-defined motion for autotuning: Motor will move back and forth Distance: 1.000 rev Velocity: 500.000 rpm Acceleration: 62500.000 rpm/s	Status: Running
Selected Options: Tune vibration suppression Not a vertical application Tune acceleration feed forward Tune smoothing filter Use LMJR estimated by drive 5.170	Cycle Info: Start From Default Gains Cycles: 6

5% Start Stop Modified Parameters

Figure 8-7 Autotuning - start

The motor moves continuously back and forth while testing values at intervals over the entire range of each control loop parameter. After autotuning is completed, click Modify Parameters to view the new settings.

Name	Before	After	Description
KNLAFRC	0	66	HD Acceleration Feedforward
KNLD	80.000	105.969	HD Derivative Gain
KNLI	10.000	39.626	HD Integral Gain
KNLIV	40.000	51.597	HD Derivative-Integral Gain
KNLP	30.000	66.045	HD Proportional Gain
KNLUSERGAIN	0.500	1.000	HD Global Gain
KNLUSERVCMGAIN	1.000	0.000	HD Adaptive VCMD Gain
NLAFFLPFHZ	7000	5000	HD Spring Filter
NLANTIVIBSHARP2	0.500	0.050	HD AV 2 Filter Sharpness
NLANTIVIBSHARP3	0.200	0.035	HD AV 3 Filter Sharpness
NLFILTDAMPING	60	85	HD Current Filter Damping
NLFILT1	3.000	0.929	HD Current Filt Low Pass Rise Time
NLNOTCHBW	0	300	HD Current Filter Notch Bandwidth

Figure 8-8 Autotuning - parameters changed by autotuning

Step - Test



Figure 8-9 Autotuning - test

- Click Move and Plot to send the current command to the drive and plot the response.

Move and Plot enables the drive and the motor will run!

The resulting graph shows the position command profile in velocity unit (PTPVCMD). Option can also display motor velocity measured by feedback device (V) and current command (ICMD). The second plot shows position error (PE).

The wizard also displays the system-calculated settling time and position error window values.

Toolbar buttons allow you to examine the drawing more carefully and export the results to a spreadsheet. These functions are also found in the ServoStudio2 Range screen.

5. Optional: modify the motion settings and/or gain settings and repeat the test under different conditions:

- Target position
- Cruising velocity
- Acceleration (and deceleration)
- HD Global Gain (KNLUSERGAIN); This is the global gain parameter of the HD control loop. The higher the gain value, the stricter the control, and the lower the value, the looser the control.

6. Click Save to save the parameters of the autotuning settings.

Step - Save




Figure 8-10 Autotuning - save

To complete the autotuning process, do all of the following:

- Click Save to Drive to save the parameters in the drive RAM to its non-volatile drive memory.
- Click Save to PC to save the parameters in the drive RAM to a backup file on your computer. Parameters are saved in text files with TXT or SSV extension. Text files can be edited using Notepad or any other text editor.
- Click Generate Report to create a record of your system settings that can be used for future reference and/or sent to technical support if needed.

It is recommended that you generate a report every time you complete application configuration, even if the system is running normally.


8.4PC-based Autotuning

If no electronic motor nameplate is detected at power-up, ServoStudio2 will activate the PC-based autotuning wizard.

The PC-based Autotuning wizard overrides the user's unit settings and works with the following units:

- Position: count
- Velocity: rpm/s for rotary motors, mm/s for linear motors
- Acceleration/deceleration: rpm/s² for rotary motors, mm/s² for linear motors

Step - Load/Motor inertia ratio (LMJR) estimation



The screenshot shows the 'Autotuning' window with three steps: 1. Inertia, 2. Gain, and 3. Test. Step 1 is active. The title is 'Step 1: Load to Motor Inertia Ratio Estimation'. The instructions are: 1. Do either of the following: - Let the drive estimate load inertia. - Enter a specific value for load inertia. 2. Optionally, modify the motion distance to be used for the estimation. 3. Click Start Load Estimation. A red caution box says 'Caution: Start enables the drive and moves the motor!'. Under 'Estimation Mode', there are two radio buttons: 'Move and estimate load inertia' (selected) and 'Use known load inertia'. Next to 'Use known load inertia' are input fields for '0.0' and 'kg-m^2*10^-3'. Below that is 'Motion Distance (0.1 - 3)' with an input field for '0.25' and 'rev'. A red 'Stop Load Estimation' button is in the center. At the bottom, a progress bar shows 'First move: Getting data...'. There are 'BACK' and 'NEXT' buttons at the bottom right.

Figure 8-11 PC-based autotuning wizard - load/motor inertia ratio (LMJR) estimation

1. For automatic estimation, select "Move and estimate load inertia". Or

if you know the load inertia connected to the motor, select "Use known load inertia" and enter the value.

2. Modify the number of motor revolutions used as motion distance during load estimation (optional).

3. Click "Start Load Estimation".


Start enabling the drive and running the motor repeatedly!

ServoStudio2 estimates the current load of the motor and displays the results.

4. Click OK to send the calculated parameters to the drive.

5. Click Next to continue.

Step - Gain optimization



The interface shows a progress bar at the top with three steps: 1. Inertia, 2. Gain (selected), and 3. Test. Below this, the 'Autotuning' section contains instructions for Step 2: Gain Optimization, including a caution to start tuning repeatedly. The 'Manual Move' section has buttons for 'Negative' and 'Positive' movement, with a speed setting of 5 rpm. The 'Move Command' section has input fields for Distance (4194300), Speed (500), and Acceleration (25700). A 'Stop Tuning' button is located below these fields. On the right, a 'Parameters' table displays the current values for various control parameters.

Name	Initial Value	Limit Value	Selected Value
HD Global Gain	0.500	3.000	1.181
HD Current Filter Damping	30.000	90.000	85
HD Current Filt Low Pass Rise Time	0.840	0.200	0.68
HD Proportional Gain	44.040	106.400	
HD Derivative-Integral Gain	22.020	106.400	
HD Integral Gain	25.730	106.400	
HD Global Gain	0.000	0.000	

At the bottom right, there are 'BACK' and 'NEXT' buttons.

Figure 8-12 PC-based autotuning wizard - gain optimization

1. The Move Command values shown are recommended; based on the motor you defined in the setup. Use the negative and positive buttons to position the load where the motor can safely rotate a full range in each direction.

2. If necessary, adjust the Manual Move speed setting.

3. Click Start.

Start enabling the drive and running the motor repeatedly!

The motor moves continuously back and forth while testing values at intervals over the entire range of each control loop parameter. Once optimal results are achieved, the optimal values are displayed in the parameter table.

The top bar shows the progress of parameters currently being tested.

The bottom bar shows the progress of the entire process.

4. If necessary, adjust the "Move Command" settings, then click "Start" to repeat the test.

Step - Test movement quality



Figure 8-13 PC-based autotuning wizard – test movement quality

1. Click Move and Plot to send the current command to the drive and plot the response.



Move and Plot enables the drive and the motor will run!

2. A graphic will appear. This figure shows the velocity command generated by the point-to-point position profile map (PTPVCMD) along with the position error (PE).

The wizard also displays the system-calculated settling time and position error window values.

Toolbar buttons allow you to examine the drawing more carefully and export the results to a spreadsheet. These functions are also found in the ServoStudio2 Range screen.

3. Modify the motion settings and/or gain settings and repeat the test under different conditions (optional):

- Target position
- Cruising velocity
- Acceleration (and deceleration)
- HD Global Gain (KNLUSERGAIN); This is the global gain parameter of the HD control loop. The higher the gain value, the stricter the control, and the lower the value, the looser the control.

Step - Save

To complete the autotuning process, do all of the following:

- Click Save to Drive to save the parameters in the drive RAM to its non-volatile drive memory.

- Click Save to PC to save the parameters in the drive RAM to a backup file on your computer. Parameters are saved in text files with TXT or SSV extension. Text files can be edited using Notepad or any other text editor.
- Click Generate Report to create a record of your system settings that can be used for future reference and/or sent to technical support if needed.

It is recommended that you generate a report every time you complete application configuration, even if the system is running normally.

8.5 Summary of Autotuning Parameters

The following table lists the parameters that can be optimized and set during the autotuning procedure.

Not all parameters are modified during this process. The final value of the parameter is determined by the specific options selected by the user in the Autotuning Wizard.

√ Use autotuning to optimize parameter value

Y/N Set parameters by autotuning, or user can manually set the value

8.6 Record and evaluate performance

8.6.1 Diagnosis

After autotuning is completed, the system may show unsatisfactory behavior, such as:

- The servo motor is noisy.
- The servo motor is hot.
- Performance is inconsistent.
- Foldback occurs; i.e. the motor requires a current level that the drive cannot handle continuously.
- System jitter.
- Extreme movement.
- Excessive overshoot leads to reaching the application mechanical limit.

The following figure describes the procedure for diagnosing system behavior and applying filters to improve performance.

CDHD2S-PN-RS recording function is used for performance verification, tuning and debugging. ServoStudio2 provides a full-featured graphical interface for recording, plotting and measuring data. Please refer to the ServoStudio2 Reference Manual for details.

To improve or change the performance of your CDHD2S-PN-RS system, please refer to the performance diagnostic chart and manually modify and evaluate parameters.

Procedure: Modify and test parameters

After each modification of parameters, please perform the following operations:

1. Make sure the operation mode is set to serial position.
2. Perform forward and backward movements, and record PE, ICMD and PTPVCMD.
3. Use the ServoStudio2 "Range" screen to plot and evaluate the recorded values.
4. Check the PE settling time.

8.6.2 Recording data in ServoStudio2

Procedure: Recording data in ServoStudio2 - example

1. In the ServoStudio2 Range screen, select the Run tab.
 - Set the target position value to 3 turns.
 - Set the values of the motion parameters to produce a motion at 50% of the motor's maximum velocity, and 75% of the maximum acceleration required by the application. In this example:
 - Maximum velocity (cruise velocity) is set to 1000
 - Acceleration (and deceleration) is set to 50000
 - If forward and backward movements are required, select the "Alternate" option.

The aim is to obtain motion profiles with a large duration of acceleration, smooth and deceleration stages.

2. In the Logger Setup panel, select the following record variables:
 - PTPVCMD (position command velocity)
 - ICMD (current command)
 - PE (position error)
3. In the "Logger Setup" panel, enter the sample value and trigger variable:
 - Sample: 1000
 - Interval: 16
 - Trigger: IMM

4. Make sure the drive is enabled and click the Run Record and Plot button in the Range toolbar.



Figure 8-14

Note that the trajectory scale factor of the "Position Error" variable shown here is 50.




Figure 8-15 Motion obtained using default parameter values

5. Select the "Parameter Table" tab.

Motion	Terminal	Parameter Table	Data Table	Measure	Script
Parameter		Value	Unit		
HD Global Gain		1.000			
HD Derivative Gain		139.691	Hz		
HD Proportional Gain		88.593	Hz		
HD Derivative-Integral Gain		69.213	Hz		
HD Integral Gain		35.436	Hz		
HD Flexibility Compensation		5000.000	Hz		
HD Spring Filter		5000	Hz		
HD Maximum Adaptive Gain		1.600			
HD Current Filter Damping		85	%		
HD Current Filt Low Pass Rise Time		0.547	ms		
HD Current Filter Notch Center		1333	Hz		

Figure 8-16 Parameter - example

The parameter KNLUSERGAIN (HD global gain) is set to 1.000 during autotuning. For other manual tuning, you can start with this setting. If the gain is too high - as evidenced by vibration and noise - lowering the value of KNLUSERGAIN can deliver a smooth motion.

6. Check the position error and settling time

Right-click in the graph pane and select Show Settling Time.




Figure 8-17 Position error (count) and settling time (ms)

The acceptable range of response (position error) is the motion at the end point (in count).

Acceptable range:

Example:

Mechanical dimensions (connector length) = 0.5 meters

Motor resolution: 1 revolution = 17 bits = 131072 counts

Gear ratio=1:100

Acceptable range:

If the motor rotates 100 times, the end point motion is 0.2×10^{-6} meters. Acceptable range: 50-100.

8.6.3 Recording data in the terminal

Procedure: Record data (terminal)

1. Use the command RECORD to define the variables to be recorded, the recording interval and the number of points to be recorded. The syntax for recording command is:

RECORD{sampling time}{number of points}{variable 1}[variable 2][variable 3]

For example: RECORD32100"VCMD"V"ICMD

Record 100 points of VCMD, V and ICMD every 1 ms

Note that there must be a quotation mark (") before the variable.

2. Use the command RECTRIG to define the variables and conditions that trigger recording.

The syntax for recording trigger command is:

RECTRIG{variable}[level][pretrigger][up|down]

Note: If the specified number of pre-trigger points is greater than the number of points actually recorded before triggering, the recorded pre-trigger segment will include the variable value before the motion started.

For example, when the acceleration is 10000rps/s, record a jog (J) from zero to 1000rpm; specify the recording level as 1rpm, the direction upward, 128 pre-trigger points and the time interval as 1. Since there will be no movement of 128 pre-trigger points, the recorded data will be filled with zeros (zero velocity command before movement).

3. Use the variables REC COMPLETE (recording completed) and/or RECING (recording in progress) to determine whether the recorded data is available.

4. Set the variable GETMODE to 0. Then use the command GET to retrieve data recorded in comma-separated variable (CSV)ASCII format.

Table 8-2

Function	VarCom	Description
Recording activation command	RECORD	Define the variables to be recorded, as well as the recorded time span and sampling time.
	RECTRIG	Define the trigger conditions for starting recording and the pre-trigger duration.
	RECOFF	Turn off the active record.
Record utility information	RECLIST	List all variables that can be recorded by the recording function.
	RECTRIGLIST	List all options that trigger recording.
Status flag	RECRDY	Indicate that the record is ready.
	RECING	Indicate that a trigger condition has occurred and the record is active.
	REC COMPLETE	Indicate that the recording has been completed.
Data retrieval	GETMODE	Define the format of recorded data (binary /ASCII).
	GET	Retrieve the recorded data.

8.6.4 Evaluate PTPVCMD

Note: ServoStudio2 has not been fully updated.

The parameter PTPVCMD (Position Command Generator velocity) reports the derivative of the position command profile in velocity unit. PTPVCMD can be used to record and view actual velocity and velocity commands, which can only be used as derivatives of the position profile.

PTPVCMD is a trajectory velocity command that applies to all position loops.

VCMD is the output velocity command of the linear controller.

VCMD is not used for HD (non-linear) control.

The following figure shows an example of PTPVCMD recording indicating poor performance.




Figure 8-18 Poor performance of PTPVCMD

8.6.5 Evaluation of ICMD and/or PE oscillation

Note: ServoStudio2 has not been fully updated.

The figure below shows an example of ICMD (current command) and PE (position error) oscillations that indicate poor performance.




Figure 8-19 Poor performance of ICMD and PE

To determine if the oscillation is greater than 300Hz, use the ServoStudio2FFT function on the PE or ICMD recording:




Figure 8-20 FFT tracking evaluation

8.7 Current Command Low Pass Filter

Note: ServoStudio2 has not been fully updated.

The HD control loop output is a current command. This current command is low-pass filtered before being transmitted to the current controller. The autotuning procedure sets optimal low-pass filter parameter values during the load estimation process.

- NLFILTDAMPING (HD current filter damping), expressed as a percentage, maintains the filter bandwidth at the cutoff frequency.
- NLFILTT1 (HD current filter low-pass rise time), in milliseconds, defines the reciprocal of the cutoff frequency.

If noise occurs, it may be necessary to fine-tune the low-pass filter.

Increase NLFILTT1 in 10% increments until the noise reaches an acceptable level.

If the system becomes unstable, the global gain (KNLUSERGAIN) may need to be reduced.

After tuning KNLD, NLFILTDAMPING and/or NLFILTT1 can be further tuned. Please refer to the *KNLD - Differential Gain*.


To achieve the fastest response time of the HD control loop, the low-pass filter can be manually adjusted. The goal is to use the maximum value of NLFILTDAMPING and the minimum value of NLFILTT1.

1. Increase NLFILTDAMPING until ICMD noise and/or oscillations are observed, then decrease by 10%.
2. Decrease NLFILTT1 until ICMD noise and/or oscillations are observed, then increase by 20% and at least 0.05ms.


If the equipment to be controlled has resonance at a high frequency, NLFITT 1 can be used for current output. NLFILT1 can effectively reduce the noise, but it will also reduce the control bandwidth and the potential stiffness of the system.

NLFILTDAMPING can minimize low-pass negative effects. NLFILTDAMPING can be set independently of NLFILT1 to provide overshoot response. Combined with the low-pass characteristics of mechanical system, it is helpful to deliver a high bandwidth control.


NLFILTDAMPING0%40%80%



NLFITT1
value too low



NLFITT1
value too low



NLFITT1
selected value

Figure 8-21 Low-pass filter

8.8Gear filter

Note ServoStudio2 has not been fully updated.

The gear filter can be used if the system exhibits the following characteristics:

- The resolution of pulse and direction commands is low.
- The coupling between the motor and the load is not strong.
- The movement stroke is short.
- The motor makes noise after tuning.
- The current fluctuates greatly during the settling process.
- The motor temperature is abnormally high.

Before applying the gear filter, make sure GEARINMODE=1

When a system has multiple axes, the gear filter value must be the same for all axes.




Figure 8-22

Table 8-21

T1	GEARFILTT1	Gear filter depth
T2	GEARFILTT2	Gear filter velocity and acceleration depth
ATHRSR	GEARACCTHRESH*	Gear acceleration threshold
VELFF	GEARFILTVELFF*	Gear filter velocity feedforward
AFF	GEARFILTAFF*	Gear filter acceleration feedforward
*Use default value. If necessary, please contact technical support		




Figure 8-23 Gear filter

Gear filter - example 1
Increasing GEARFILTT1 will smooth the input command PTPVCM, but it will increase the delay.
Suggested value:
GEARFILTT1= $\sqrt{2}$ input step width
GEARFILTT2=2GEARFILTT1





Figure 8-24 Tuning gear filter

Gear filter - example 2
 Increasing GEARFILT2 and VELFF can compensate for the delay, but it will increase the overshoot. If GEARFILTVELFF=GEARFILT2, no delay.

8.9 Moving Smoothing Filter


Note ServoStudio2 has not been fully updated.

The HD control provides three options for smooth position command, defined by the parameter MOVESMOOTHMODE.



MOVESMOOTH0:


Profile smoothing without position command.



MOVESMOOTH1:

MOVESMOOTHLPFHZ-based profile low-pass smoothing (in Hz).

The lower the value, the greater the smoothness.



MOVESMOOTH2:

Average (in ms) S-curve based on MOVESMOOTHAVG.

Time expands the average.

Binary values (2, 4, 8, 32, 64, 128, 256)

Figure 8-25 Smoothing filter

To apply a smoothing filter to external reference commands, such as pulse train or Profinet, specific bits in MOVESMOOTHSRC must first be set.

8.10 Notch filter

Note ServoStudio2 has not been fully updated.

The notch filter can be used to eliminate high-frequency oscillations that can occur in systems with flexible connections between motor and load, such as:

- Ball screw linear slide with coupling
- Belt drive
- Harmonic drive

Oscillation usually occurs during the first step of tuning (feedback gain). Tuning is done by checking the oscillation frequency and setting the notch accordingly. Once the notch parameters are set, the tuning process can continue.

The HD control notch filter can be used at any time during tuning to suppress oscillations at fixed frequencies greater than 300Hz:

- NLNOTCHCENTER (HD current filter - notch filter center)
- NLNOTCHBW (HD current filter – notch filter bandwidth)

The second set of HD control notch filters (NOTCH2CENTER and NLNOTCH2BW) are available through the terminal but do not appear in the ServoStudio2 control loop screen.

8.11 Anti-vibration Filter

Note: ServoStudio2 has not been fully updated.

Anti-vibration overview

The anti-vibration function of the HD controller is based on a proprietary control algorithm and is used to suppress vibration at a constant frequency.

The vibration suppression function operates in a closed loop, detecting oscillations when they occur and suppressing them immediately. Active damping load oscillation significantly reduces the time required for heavy load or end effector to stabilize at the target position. Although the position error at the encoder level may be high, the overall performance of the system evaluated at the load position is improved.

A typical example is that a load is fixed to a servo control motor by means of a shaft with certain flexibility. If the motor's servo control is set to a position error close to zero during motion, the load will oscillate strongly. Every change in acceleration (jerk) creates a disturbance, causing load oscillation. Although a stiff HD control loop will overcome these oscillations at the motor position level, the load will still oscillate strongly.

The anti-vibration feature can handle systems with oscillation frequencies up to 100Hz.

The figure below shows the four stages of the vibration suppression process.




Figure 8-26 Anti-vibration filter

Stage 1: Detect disturbances sensed by the system using various control variables as inputs, such as position error and current. The disturbed values are calculated for the next stage.

Stage 2: The disturbed values are passed through a narrowband bandpass filter, selecting disturbances caused by system oscillations. The center frequency and width of the bandpass filter are set by the parameters NLANTIVIBHZn and NLANTIVIBSHARPn respectively.

Stage 3: Calculate the correction output to be added to the control variable.

Stage 4: Add the correction output to the control variable using the damping gain (parameter NLANTIVIBGAINn).

Anti-vibration tuning procedure

After autotuning, more anti-vibration tuning may be required.

If additional vibration frequencies need to be suppressed, the tuning process can be repeated with a second set of anti-vibration filters. The following table shows the parameter values modified by the tuning procedure.

Table 8-3

HD anti-vibration filter	Parameters	Default	Range
Center frequency 2	NLANTIVIBHZ2	100	5 to 800 [Hz]
Center frequency 3	NLANTIVIBHZ3	400	5 to 800 [Hz]
Sharpness 2	NLANTIVIBSHARP2	0.5	0.01 to 10
Sharpness 3	NLANTIVIBSHARP3	0.2	0.01 to 10
Suppression gain 2	NLANTIVIBGAIN2	0	0 to 99
Suppression gain 3	NLANTIVIBGAIN3	0	0 to 6

Note: Although parameters NLANTIVIBHZ, NLANTIVIBSHARP and NLANTIVIBGAIN are still available, they are not recommended.

1. Set the narrowband center frequency.

- Perform an action and measure the resonance (oscillation frequency) of the current command (ICMD):
 - In the Range screen, right-click the ICMD plot.
 - Select FFT and Differentiation.
 - Select FFT tracking.

The FFT tracking will look like this, for example:




Figure 8-27 FFT tracking

- Set the value of parameter NLANTIVIBHZn to the peak or dominant resonance (in Hertz). In the example shown here, the value is 14Hz.
2. Set the narrowband center sharpness (width).
- Set the value of parameter NLANTIVIBSHARPn according to the resonance sharpness (width) of the narrowband filter.

Estimate the width by comparing the plot in the FF Traking dialog box to the plot below, which shows the NBF frequency response as a function of the NLANTIVIBSHARPn value. Typical setting range is 0.1 to 1.0.

The figure below shows the narrowband filter frequency response.




Figure 8-28 Frequency response varying with NLANTIVIBSHARP_n

Suitable for 20Hz center frequency

Step 2 – Tune damping gain

Increase the value of parameter NLANTIVIBGAIN_n until optimal damping is reached.

- At each increment, the current command (ICMD) is recorded and the oscillation damping is checked. Obtain optimal system damping for better damping current oscillations.

Note: If high-frequency vibration occurs while increasing this parameter, please slightly reduce the adaptive global gain (KNLUSERGAIN).

Anti-vibration tuning – example

Note: Some variable plots are scaled (indicated by "x").

When tuning without vibration suppression, position errors, current oscillations and settling time are very long.




Figure 8-29 Position error and current oscillation without vibration suppression




Figure 8-30 No vibration suppression, long settling time




Figure 8-31 Settling time - without anti-vibration tuning

In order to suppress oscillations and shorten settling time, the following parameters need to be set:

- NLANTIVIBHZ2=14Hz, measure the resonance frequency.
- NLANTIVIBSHARP2=0.5, estimate the width based on the sharpness shown in the FFT tracking.
- NLANTIVIBGAIN2=8, determined by manually increasing the value from 0 until the optimal settling time is reached.




Figure 8-32 Using vibration suppression tuning - position error and current oscillation are reduced




Figure 8-33 Using vibration suppression tuning - settling time is short




Figure 8-34 Settling time - with anti-vibration tuning

8.12 Gain - Manual Tuning


Note: ServoStudio2 has not been fully updated.

KNLD - differential gain


1. Set KNLP to half of the default settings.
2. Set KNLI and KNLIV to zero.
3. Increase the KNLD value until oscillations of ICMD are observed.

The acceptable level of ICMD ripple depends on the system, mainly the load. It can usually be determined by acoustic noise. Light load (load/motor inertia ratio (LMJR) < 2): 5% of rated current may be normal.

High load (load/motor inertia ratio (LMJR) > 2): 10% of rated current may produce acceptable ripple.



KNLD value is too high



KNLD selected value


Figure 8-35 Differential gain tuning

Increase the KNLIV value until the position error (PE) starts to oscillate.


Increasing the KNLIV value can reduce the position error, reduce the sensitivity to external disturbance, and reduce the steady-state position error (if any) when stopping.

Optimal tuning: Position error decreases as quickly as possible after each motion phase change (jerk), no oscillations during phase transitions; no position error overshoot; oscillation at stop is acceptable (± 1 encoder count).

Optimal settling time: If possible, increase the KNLIV value until the position error returns to 0 before the end of the deceleration stage.



KNLIV value is too high;
The oscillation at stop
is too strong;
Position error overshoot



KNLIV selected value;
Good settling time


Figure 8-36 Differential - integral gain tuning

Increase the KNLP value until the position error (PE) starts to oscillate.


With the increase of KNLP value, the shape of position error becomes square, which reflects the constant during acceleration and deceleration.

As the KNLP proportional gain becomes high, the position error reaches a stable value at each stage of motion (acceleration, smooth, deceleration).


Optimal tuning: The shape is as square as possible, indicating that the position error is constant at each stage of motion and that there are no oscillations during the transitions between stages (acceleration to smooth, smooth to deceleration, deceleration to stop).



PE becomes flat during acceleration and deceleration



KNLP value too high;
oscillation at stop



KNLP selected

Figure 8-37 Proportional gain tuning


KNLI - integral gain

KNLI is used to reduce position errors during movement and stop.


Optimal adjustment: the maximum value that does not produce overshoot or oscillation.

Optimal settling time: If possible, increase the KNLIV value until the position error returns to 0 before the end of the deceleration stage.

Result: The position error is slightly reduced; the oscillation at stop is acceptable (± 1 encoder count); there is no position error overshoot at the end of the deceleration stage (stop point).



KNLI value is too high; position error oscillation at stop Position error overshoot



KNLI selected value

Figure 8-38 KNLI tuning

8.13 Flexible compensation tuning

Note ServoStudio2 has not been fully updated.

The flexible compensation parameter reduces the vibration caused by the load and the tracking error through the sudden change of acceleration (jerk). They also minimize overshoot and settling time.

- Set NLPEAFF (HD flexible compensation) according to the stiffness of the system (in Hertz). Stiff systems require high values. Systems with high load inertia and flexible couplings require lower values; the normal range is 400 to 30 Hz. If not used, set to 5000Hz.
- NLAFFLPFHZ (HD spring filter), in Hertz, applies a low-pass filter to the command position acceleration used to perform compensation. The acceleration is calculated based on the input command position, and may be noisy if the input command position has a low resolution (such as a pulse train input). The application of the low-pass filter NLAFFLPFHZ smoothes the calculated command position acceleration, and when applying the parameter NLPEAFF, it should be used when noisy operation is observed.

Optimal tuning: Typically, the maximum frequency is 400Hz. Therefore, for heavy load and flexible systems, the typical range of NLPEAFF is 400 to 30Hz.




Figure 8-39 Equipment flexibility

Procedure: Flexible compensation tuning

1. Set $NLAFFLPFHZ = 3 \times KNLD$
2. Start with the highest value of NLPEAFF and decrease until you reach the best result for your application. The criterion can be settling time or position error.

8.14 Dual feedback position control loop debugging

Note ServoStudio2 has not been fully updated.

The variable position feedback (PFB) represents the feedback used to control positioning when secondary feedback is enabled and used in the control loop (SFBMODE1).

The position controller in the dual feedback control system is a dedicated P-gain controller with velocity feedforward and acceleration feedforward. The velocity loop can be PI or PDFF and uses motor feedback to control the motor. Current loops also use motor feedback to control the motor.

The dual feedback position controller includes three gain parameters:

- KNLDUALLOOPKP: Position loop proportional gain.
- KNLDUALLOOPVFF: Position loop velocity feedforward.
- KNLDUALLOOPAFF: Position loop acceleration feedforward.




Figure 8-4 Dual feedback position control loop

Procedure: Tune a dual feedback position control loop

1. Make sure the drive is running in serial communication mode (COMMODE0).
2. Configure the motor and motor feedback parameters.
3. Set the motor to the load to inertia ratio (LMJR) value.
If unknown, use ServoStudio2 autotuning estimated value.
4. Configure secondary feedback device parameters. Please refer to the *Secondary Feedback*.
5. Make sure the motor feedback and secondary feedback are in the same direction. If not, use SFBDIR to inverse the direction.
6. Enable secondary feedbackinvert ck and activate dual loop mode (SFBMODE1).
7. Tune velocity controller:
 - a. Switch to serial velocity operation mode (OPMODE0).
 - b. Define PDFF velocity controller (VELCONTROLMODE1).
 - c. Select the variables to be recorded: VCMD, MVEL, ICMD
 - d. Use these variables to tune the motor's velocity loop:
 - Adjust velocity proportional gain (KVP).
 - Adjust velocity integral gain (KVI).
 - Adjust velocity feedforward (KVFR).




Figure 8-41 Dual feedback - tune velocity controller—example

8. Adjust the dual feedback position controller:
 - a. Switch to serial position operation mode (OPMODE8).
 - b. Select the variables to be recorded: PTPVCMD, V, PE, ICMD.
 - c. Use these variables to tune the dual feedback position loop:

- Tune proportional gain (KNLDUALLOOPKP)
- Tune velocity feed forward (KNLDUALLOOPVFF)

Best adjustment: Gradually increase the KNLDUALLOOPKP value until ICMD oscillates, or noise is heard. Then reduce the KNLDUALLOOPKP value by 10%.




Figure 8-42 Dual feedback - tune position controller (KNLDUALLOOPKP) - example

- d. Set the velocity feedforward to 100% (KNLDUALLOOPVFF):




Figure 8-43 Dual feedback - tune position controller (KNLDUALLOOPVFF) - example

8.15 Gantry Tuning

Note: The tuning process (movement/recording) of the gantry system is performed by the gantry main drive.

All motion commands of the gantry system must be issued by the gantry main drive.

The gantry differential drive will reject the motion command.

Procedure: Tune the gantry system

1. Make sure you have completed the gantry system setup described in the *Gantry Setup* section.

2. Open ServoStudio2 operation mode screen.

Select serial position (OPMODE8, COMMODO) operation mode for each drive.

3. Open ServoStudio2 Control>Position Loop screen.

Select position controller method 5 - HD Controller for each drive.

(POSCTRLMODE5)

4. Open ServoStudio2 Control > Range screen. Make sure the selected drive is the gantry host.

- Define the parameters to be recorded.

PTPVCMD

PE

V

ICMD

- Define a serial position motion command, execute and record. View the result chart.

Note: ServoStudio2 will record the PE and ICMD of both drives.

5. Gradually increase KNLD (HD differential gain) until the system produces audible noise. The goal is to maintain the highest KNLD with the least amount of filtering.

While continuously testing the system, adjust the gain of the gantry main drive, as described in the following steps.




Figure 8-44 KNLD=1




Figure 8-45 KNLD=20




Figure 8-46 KNLD=50

6. Gradually increase the KNLP (HD proportional gain) value until the position error decreases.




Figure 8-47 KNLD=20




Figure 8-48 KNLD=50

7. Increase the KNLI (HD integral gain) value to reduce the static error.

The maximum value of KNLI should be less than $\frac{\text{KNLP}}{2}$.




Figure 8-49 KNLD=20

8. If necessary, reduce the setup time by increasing the KNLIV (HD differential-integral gain) value. If there is oscillation at the end of the movement, decrease KNLIV.

9. Switch the drive axis to the gantry differential drive.

10. For a rigid gantry system, set the gain parameter of differential drive HD control loop to 0.

For a flexible gantry system, adjust the differential drive gain parameter as described in the previous steps. It is likely that KNLI and KNIV will need to be set to 0 to prevent the current from rising during quiescence.

To test performance, switch the drive axis to the gantry main drive and perform a move/record.




Figure 8-50 Tuning both axes

Tuning using the Terminal - example

```
\1
```

```
K
```

```
#Delay100
```

```
CLEARFAULTS
```

```
KNLUSERGAIN1
```

```
NLTFDESIGNMODE1
```

NLTFBW400

KNLD32

KNLP16

KNLI0

KNLIV0

KNLVFF1

\2

KNLUSERGAIN1

NLTFDESIGNMODE1

NLTFBW400

KNLD32

KNLP8

KNLI0

KNLIV0

KNLVFF1

\1

RECOFF

RECORD322000"PTPVCMD"PE"GANTRYMSTRVFB"ICMD

RECTRIG"PTPVCMD101001

ACC100

DEC100

MOVEABS1400000500

#PLOT

#Delay4000

MOVEABS0250

8.16 Tuning Questions - Q&A

When should I use a notch filter?

When your equipment has high-frequency vibration and produces sharp sound or horn sound when you increase the gain. Although the system has good performance, it will produce a lot of acoustic noise at low speed. What should I do?

Tune the system at high speed, reduce the global gain KNLUSERGAIN value, increase the rise time of low-pass filter NLFILTT1, and then increase NLMAXGAIN.

The system is flexible and overshoots at the end of the movement. How to eliminate overshoot?

Use a low-value acceleration filter NLAFFLPFHZ and reduce NLPEAFF. This will create an overshoot and eliminate it before stopping.

9. PROFINET settings

As a new generation of high-performance bus communication servo driver developed by SERVOTRONIX, the CDHD2S-PN-RS series supports the PROFINET bus communication protocol on the basis of advanced control algorithms.

This instruction manual describes the PROFINET IO functions supported by CDHD2S-PN-RS and their instructions for use.

This manual is intended for technicians who have been trained to operate the equipment described.

9.1 Hardware Wiring

When using PROFINET communication, ensure that the GSD file is installed, as described in 3.1. Gaochuang GSD files can be obtained from Gaochuang's official website or technical support <http://m.servotronix.com.cn/>

RJ45 cable connection method:

C5 port from PLC to high-traumatic drive

C6 port connects to the next node




figure9-1 Interface to CDHD2S-PN-RS top panel

The following figure shows the topology of the hardware connection between the Siemens S7-1500 PLC and the Gaotuang CDHD2S-PN-RS driver.



figure9-2 SERVOTRONIX CDHD2S-PN-RS with Siemens S7-1500 Hardware Topology

9.2 Drive Settings

9.2.2 Drive Command Interface Mode Settings

Some parameters of the drive, such as the command interface mode, are defined in the factory firmware of the drive and can only be modified by the ServoStudio software. Note: ServoStudio requires a serial communication (USB or RS232) connection between the PC and the drive.

The drive is factory configured as a fieldbus (PROFINET) command interface defined by the drive parameter commode = 1. If required, PROFINET command interface mode can be enabled through the ServoStudio Terminal interface. Enter the command commode 1 and issue the serial command save. Alternatively, you can select “Interface Mode” in the ServoStudio “Drive Information” interface as shown in Figure 2-3.

Command Interface Mode

Command Interface Mode	DESCRIPTION	Action Commands
PROFINET	Servo enable, disable and motion commands are transmitted through the PROFINET interface	COMMODE 1
Serial/Pulse/Analog	Servo enable, disable and motion commands are transmitted through serial/pulse/analog interfaces	COMMODE 0




figure9-3 Servostudi Interface Mode Settings

9.2.3 Drive IP and Device Name Settings

The drive IP and device name settings can be set in two ways: TIA Portal and Servostudio.

Broadcasting V17 Settings

After the drive and PLC are hardware connected and the Servostudio is set up, use Broadway to scan for accessible devices. In the case of the gantry, the drive is recognized as an accessible device with its MAC address in suffix brackets.




figure9-4 Two available devices for online scanning




figure9-5 Assigning IP Addresses to Drives

When assigning the PROFINET device name, click "led blinking", you can observe that the upper and lower ends of the eight-segment digital tube of the drive are alternately blinking.



figure9-6 LED Blinking




figure9-7 Assigning Device Names to Drives

Servostudio

The "Profinet Info" can be seen in the drive information of the Servostudio interface, and the IP and device name of the drive can be set through the serial port. It is important to note that the PLC and drive hardware need to be disconnected before doing this, where the Default Router setting needs to be consistent with the PROFINET IP setting.




figure9-8 Set the IP and device name of PROFINET IO in Servostudio

9.3 Application example of CDHD2S-PN-RS with Siemens S7-1500

This chapter describes the configuration of Siemens S7-1500 PLC with Gaotuang CDHD2S-PN-RS driver in different message configurations.

9.3.1 Install GSD Files

After opening Broadway V17, enter the new project interface and directly open the project view.



figure9-9 Added New Project

As shown in Figure 9-10, add the GSD file of Gao Tron and confirm that the file status is installed. It should be noted that the GSD file name provided by SERVOSTRONIX cannot be modified at will.




figure9-10 Install GSD Files




figure9-11 Confirm GSD file status is already installed

9.3.2 Packet 111 Configuration and Application (RT)

1. RT mode configuration settings




figure9-12 Add PLC and Gaochuang CDHD25-PN-RS

As shown in Figure 9-12, add a PLC and a high-invasion driver consistent with the hardware order number in the Network View.

- ①: Left-click the device name of the drive and modify it to match the device name set in 9.1
- ②: Click "Unassigned" to assign the corresponding PLC to the drive device
- ③: Set the completed state

After completing the above actions, it is necessary to confirm that the IP address of the PLC and the driver in the configuration is consistent with the device name and the information scanned by "online access" in Broadway.

Then add 111 packets to the drive according to Figure 9-13.




figure9-13 Add 111 packets to the drive

As shown in Figure 9-14 below, the SinaPos function block corresponding to the EPOs function is found from the "option package" of the Broadway instruction, where "HWIDSTW" and "HWIDZSW" correspond to the hardware identifier of the driver 111 packet, and the setting method is shown in Figure 9-15.

figure9-14 Add SinaPos (FB284) function block




figure9-15 Add Hardware Identifier ID

2. Introduction to SINA_POS (FB284) application

The S7-1200 connects to the CDHD2S-PN-RS drive for basic positioning control by using 111 packets and SinaPos (FB284) function blocks. Below is a table of input and output parameters for this block.

A detailed description of the SinaPos (FB2834) function block can be found at <http://support.automation.siemens.com/CN/view/zh/109765618>

SinaPos (FB284) Input Parameters Table

Parameter name:	Type	Default Value	DESCRIPTION
ModePos	INT	0	Run Mode: 1 = Relative Positioning 2 = Absolute Positioning 3 = Continuous operation mode (running at specified speed) 4 = Active Zero Back 5 = Set the zero return position directly 6 = Running Segment 0 ~ 15 7 = Jogging at specified speed 8 = Jog at specified distance
EnableAxis	BOOL	0	Servo Run Command: 0 = Stop (OFF1) 1. Start
CancelTraversing	BOOL	0	0 = Cancel current run task 1 = Do not cancel the current run task
IntermediateStop	BOOL	0	Pause Task Run: 0 = Pause the currently running task 1 = Do not pause the currently running task
Positive	BOOL	0	Positive
Negative	BOOL	0	Negative Direction
Jog1	BOOL	0	Jog Signal 1
Jog2	BOOL	0	Jog Signal 1
AckError	BOOL	0	Fault reset
ExecuteMode	BOOL	0	Mode of activation request
Position	DINT	0[LU]	Position setpoint when ModePos = 1 or 2 Segment number when ModePos = 6
Velocity	DINT	0[LU/s]	ModePos = Speed setpoint at 1, 2, 3
OverV	INT	100[%]	Setting speed percentage 0 ~ 199%
OverAcc	INT	100[%]	ModePos = 0-100% of set acceleration at 1, 2, 3
OverDec	INT	100[%]	Set deceleration percentage 0-100% when ModePos = 1, 2, 3

Parameter name:	Type	Default Value	DESCRIPTION	
ConfigEPOS	DWORD	0	The relevant functions of the basic positioning can be controlled by this parameter, and the corresponding relationship of the bits is shown in the following table:	
			ConfigEPos	function declaration
			ConfigEPos.%X0	OFF2 stop
			ConfigEPos.%X1	OFF3 stop
			ConfigEPos.%X2	Activate software limit
			ConfigEPos.%X3	Activate hardware limit
			ConfigEPos.%X6	Zero-crossing switch signal
			ConfigEPos.%X7	External Program Block Switching
			ConfigEPos.%X8	When ModePos = 2 or 3, continuous adjustment of the setpoint is supported, with changes taking effect immediately.
Note: If this is variable scored in the program matching, you must ensure that the initial value is 3 (ConfigEPos. %X 0 and ConfigEPos. %X 1 Equal to 1, if not activated, off 2 and off 3 stop always take effect)				
HWIDSTW	HW_IO	0	Hardware identifier for message 111 in CDHD2S device view	
HWIDZSW	HW_IO	0	Hardware identifier for message 111 in CDHD2S device view	

SinaPos (FB284) Output Parameters Table

Parameter name:	Type	Default Value	DESCRIPTION
AxisEnabled	BOOL	0	Drive Enabled
AxisPosOk	BOOL	0	Destination Arrival
AxisSpFixed	BOOL	0	Set Position Arrival
AxisRef	BOOL	0	Reference point set

Parameter name:	Type	Default Value	DESCRIPTION
AxisWarn	BOOL	0	Drive warning
AxisError	BOOL	0	Drive fault
Lockout			The drive is in a disabled state, check whether the 0th and 1th bits in the ConfigEPos pin control bit are set to 1.
ActVelocity	DINT	0	Actual speed [40000000 hex VLIM]
ActPosition	DINT	0[LU]	Current Location [LU]
ActMode	INT	0	Currently Active Operating Mode
EPosZSW1	WORD	0	Status of EPOS ZSW1
EPosZSW2	WORD	0	Status of EPOS ZSW2
ActWarn	WORD	0	Current warning code of the drive
ActFault	WORD	0	Current fault code of the drive
Error	BOOL	0	1 = There is an error
Status	WORD		16 # 7002: No error, function block is executing 16 # 8401: Drive error 16 # 8402: Drive Do Not Start 16 # 8403: Zeroing cannot start during operation 16 # 8600: DPRD_DAT error 16 # 8601: DPWR_DAT error 16 # 8202: Incorrect operating mode selection 16 # 8203: Incorrect set value parameter 16 # 8204: Incorrect program segment number selected
DiagID	WORD		Communication error, error executing SFB call

3. Packet 111 rigid gantry configuration

As shown in the figure, when using the basic positioning controller (EPOs) in gantry mode, it is necessary to pay attention to enabling the gantry to enable two modules at the same time, and the ModePos! = 0 of the slave shaft function block, and the remaining motion control only needs to operate the spindle function block. The "HWIDSTW" and "HWIDZSW" of the two modules correspond to the "hardware identifiers" of the two driver 111 packets, respectively.




figure9-16 Sina_POS (FB284) function block settings in gantry mode

9.3.3 Packet 112 Configuration and Application (RT)

The Gaochuang CDHD2S-PN-RS series drives support the third-generation EPOs positioning control system of Siemens, and the positioning control is realized by matching 112 packets and function blocks [FB38051]. The main feature of the third-generation EPOS positioning system is that its motion parameters such as position, velocity, acceleration, and acceleration are all represented by a 32-bit floating-point type.

Using 112 packets requires updating to the latest version of the Gaotuang GSDML file:

GSDML-V2.41-SERVOTRONIX-CDHD2S-20250227

Library files on details of 112 messages and [FB38051] function blocks can be downloaded from the official Siemens documentation library or contacted for technical support.

https://cache.industry.siemens.com/dl/files/655/109747655/att_1150813/v1/109747655_LIB_SINA_POS_TEL112_LIB_DOC_v10_en.pdf

The CDHD2S-PN-RS series with 112 packets also supports rigid gantry applications. Refer to 9.3.2 for the usage method.

1. RT mode configuration settings

Reference 9.3.2 Complete PLC and drive name and IP address setup



figure9-17 Add PLC and Gaotuang CDHD2S-PN-RS drives in Network View

Add Siemens 112 packets to the drive after installing the latest GSDML file for the Gaotuang CDHD2S-PN-RS




figure9-18 Adding a Siemens 112 packet to a drive

As shown in the following figure, add the global library file for the [FB38051] function block by




figure9-19 Add global library of [FB38051] function blocks

After completing the addition of the global library file, you can find [FB38051] in the template copy shown in the figure below, drag the function block to the middle block interface, and the function block and data block will be automatically generated in the left project tree.




figure9-20 Adding [FB38051] function blocks to a block

2. SINA_POS_TEL112 [FB38051] Application Introduction

The usage of the function block [FB38051] is mostly consistent with that of [FB284], please refer to the introduction in 9.3.2.

Here are the differences in the use of both:

[FB38051] Motion parameter units in input and output are 32-bit floating point type, while integers in [FB284] function block

[FB38051] ModePos in input parameters adds mode 9: encoder adjustment function, which is achieved by setting refCoordinate

[FB38051] fixStopTorque in input parameter is reserved parameter

9.3.4 Packet 105 Configuration and Application (IRT)

The CDHD2S-PN-RS driver supports 750 additional packets when paired with 112 packets. It can achieve additional torque settings, torque upper limit settings, and torque lower limit settings. It needs to be paired with the TorqueFB_TEL750 [FB38052] function block when used.

1. IRT mode configuration settings

Add 750 additional packets to the drive, as shown in the following figure.




figure9-21 Add 750 additional packets to the drive

Add the global library file of TorqueFB_TEL750 [FB38052] by the method shown in the following figure.




figure9-22 Import [FB38052] Global Library File

After completing the addition of the global library file, you can find [FB38052] in the template copy shown in the figure below, drag the function block to the middle block interface, and the function block and data block will be automatically generated in the left project tree.




figure9-23 Adding [FB38051] function blocks to a block

2.TorqueFB_TEL750 [FB38052] Application Introduction

Details on the use of RT and IRT modes for 750 additional messages can be found in the official Siemens documentation:

<https://support.industry.siemens.com/cs/document/109821017/sinamics-s200-pn-torque-application-via-telegram-750?dti=0&lc=en-WW>

TorqueFB_TEL750 [FB38052] Input Parameter Sheet

Parameter name:	Type	Default Value	DESCRIPTION
Enable	BOOL	FALSE	False: Output default value True: Enabling Function Blocks and Input Parameters
refTorque	REAL	0.0	Reference torque should be consistent with PNU10781 (VARCOM: Tref) in N · m
addTorque	REAL	0.0	Additional torque setting in N · m
Upperlimit	REAL	0.0	Upper torque limit setting, in N · m 0.0: Turning off the torque upper limit function > 0.0: Set torque upper limit value < 0.0: Error

Parameter name:	Type	Default Value	DESCRIPTION
Lowerlimit	REAL	0.0	Lower torque limit setting, in N · m 0.0: Turn off the torque lower limit function < 0.0: Set torque lower limit > 0.0: Error
HWIDSTW	HW_IO	0.0	Hardware identifier for message 112 in CDHD2S-PN-RS device view
HWODZSW	HW_IO	0.0	Hardware identifier for message 112 in CDHD2S-PN-RS device view

TorqueFB_TEL750 [FB38052] output parameter table

Parameter name:	Type	Default Value	DESCRIPTION
Busy	BOOL	FALSE	Function block status
inUpperLimit	BOOL	FALSE	Actual torque reaches upper limit
inLowerLimit	BOOL	FALSE	Actual torque reaches lower limit
actTorque	REAL	0.0	Actual torque output by the drive
Error	BOOL	FALSE	Input interface validity status and periodic communication status
ErrorID	WORD	16#0	Error Message
dialID	WORD	16#0	750 Status of message cycle communication

9.3.5 Packet 105 Configuration and Application (IRT)

105 The message only supports IRT mode, which can realize speed control and position control.

1. IRT mode configuration settings

In addition to completing the configuration settings in 9.3.2, IRT mode requires that the PLC and the drives in the Topology View must be connected in a manner consistent with the actual connection of the hardware.




figure9-24 Topology View Connection

In IRT mode, the drive needs to be set to isochronous mode and associated with the corresponding message as shown in Figures 9-26 and 9-27, RT does not have this requirement.

It is important to note that process object settings in 9.3.3 are required before setting the IRT mode.

Double-click the CDHD2S-PN-RS in the Network View, find the 105 packet in the Submodules and drag it into the device view.




figure9-25 05 Message Configuration




figure9-26 Drive isochronous synchronization mode settings




figure9-27 PLC isochronous synchronization settings

Send Clock Settings

If IRT mode is used, the transmission clock of the PLC should be consistent with the "transmission clock" of the MC Servo [OB91], to set the transmission clock to 2ms as an example, as shown in the following figure.




figure9-28 Configuration Settings PLC Send Clock Settings




figure9-29 Property Sets

After setting up MC_Servo, you need to add an organization block to the message, as shown in the following figure.




figure9-30 Organizational block settings for drive packets

2. Process Object Configuration

Double-click the new object in the project tree and select "TO_PositioningAxis" to create a new process object.




figure9-31 Add Process Object

In the configuration of the shaft type, select the type that matches the mechanical transmission mechanism of the shaft. You can use standard motor or linear motor configuration linear shaft: ① standard motor + screw rod, ② linear motor + guide rail

Always use the standard motor configuration rotating shaft: ① standard motor, ② standard motor + gear. Currently, the driver position feedback interface only supports the first encoder. When using the second encoder, SFB will return to the bus through the encoder 1 of the bus.




figure9-32 Process Object Configuration Settings

Set up the Drive Unit as shown in the figure below.



figure9-33 Drive Setup

Set the encoder according to the process shown in Figure 9-33 and if the motor is using an incremental encoder, select Increment. If the motor uses an absolute encoder, select "absolute" or "cyclic absolute encoder" according to the requirements.




figure9-34 Coder Settings

Data exchange with the drive unit does not support automatic application of driver values at runtime and must be configured manually. When using a rotating motor, the "reference rpm" and "maximum rpm" need to be equal to those set in the drive `VARCOM.VLIM`

When using a linear motor, note that the unit of the driver is is, and the unit of the PLC is. Let be the unit speed, is the unit speed, the unit conversion formula is: $VLIMmm/sm/minV_m m/min V_s mm/s$

$$V_m = \frac{60}{1000} * V_s = 0.06V_s$$

where "reference torque" is set to the maximum torque of the motor.




figure9-35 Set up data exchange with the drive

The data exchange with the encoder device supports the automatic application of encoder values at runtime. Generally, it is necessary to configure according to the actual encoder type. If the number of encoder revolutions is not clear, you can use the "Automatically apply the driver value at runtime" function. *PNUM*

If equipped with a rotating motor, the manual setting is shown in Figure 9-36. Refer to the Increments per revolution setting in Figures 9-36. Set the shift values of Gx_XIST1 and Gx_XIST2 according to the user's needs, and Increments per revolution will automatically update.



figure9-36 Settings for data exchange with the encoder when applying a rotating motor




figure9-37 PROFINET encoder data in Servostudio

When using a linear motor, the “incremental spacing” in Figure 9-38 can be set according to the distance between increments shown in Figure 9-37. Set the shift value of Gx_XIST1 and Gx_XIST2 according to the user's needs, and the distance between increments will be automatically updated.




figure9-38 Setting to exchange data with the encoder when applying a linear motor

Varcom parameters related when using the PROFINET encoder high precision function

Parameter name:	Parameter number	Index number	DESCRIPTION
PNXIST1FAC	-	-	Shift value of G1_XIST1 in PROFINET packets <g id="Bold">Institution:</g>
PNXIST2FAC	-	-	Shift value of G1_XIST2 in PROFINET packets

			Institution:
PNENCRES	-	-	Encoder Resolution
PNENCTYPE	-	-	Encoder Type Rotation: 2: Linear
FBGDS	20145	0	Electronic gear ratio load rpm
FBGMS	20145	1	Electronic Gear Ratio Motor Revolutions
PNUM	20146	0	Motion unit molecules
PDEN	20146	1	Motion Unit Denominator

If a linear motor is used, the unit of linear encoder feedback in Broadway is, where "incremental spacing" can be converted according to the "Counts per mm" provided in the "Feedback" interface in ServoStudio. Example: Counts per mm = 20000, you need to enter 0.00005 as shown in the following figure. The shift of Gx_XIST1 is set to 0 and the shift of Gx_XIST2 is set to 0.*mm/counts*

When setting the "mechanical" parameter of the process object, it must be set according to the actual situation of the user load end. As shown in Figure 9-39, if there is no second encoder setting in the encoder setting, the number of motor revolutions and the number of load revolutions in the "mechanical" parameter are set to 1.




figure9-39 Setting of Mechanical Parameters in Process Objects

PNUM Setup Considerations

When using a rotating motor, it is generally recommended to set the pulse number to 1: 1 for one revolution with the actual motor. Set in Servostudio at the following location. *PNUMPNUM*



figure9-40 PNUM Settings

When using a linear motor, the calculation method of setting the feedback of the PLC end and the position feedback of the Servostudio end to 1: 1 is as follows: is the number of pulses per millimeter, taken from "Counts per mm" in the Feedback interface in Servostudio. If a BISS-C type encoder is used.
$$PNUMPNUM = C \times MPITCHCC = \frac{1}{\text{Motor Encoder Resolution}}$$

The Dynamic Servo Control (DSC) function is a control structure that calculates the position controller in a fast speed controller cycle and the controller system provides a set value in the position controller cycle. In this way, a higher position controller gain can be obtained. DSC must work in isochronous synchronization mode (IRT). PROFDrive packets that currently support DSC mode are: 5, 105, and DSC mode must be enabled when used.




figure9-41 Dynamic servo control settings

3. Packet 105 rigid gantry configuration

Gantry Hardware Wiring

Hardware configuration: drive power cord and encoder wiring, refer to Chapter 4.

Gantry communication needs to connect the C3 port of the two drives, and the chrysanthemum links to the C8 port.

The configuration of BoTu at Longmen is shown in the figure below. You need to add TO_PositioningAxis to the two drives and configure them separately.




figure9-42 Broadway configuration in gantry mode

Gantry enable mode

The operation of the gantry mode requires two axes to be enabled at the same time, so the spindle and slave axes of the gantry must be enabled at the same time using the block MC_power, and the gantry can be operated by programming the spindle or controlling the block.




figure9-43 Blocks enable gantry at the same time

Use the MC_MOVEVELOCITY block to speed control the spindle in the gantry as shown below




figure9-44 Use the speed control module to run the gantry

9.3.6 Packet 105 +750/910 Configuration

The torque control of the motor can be achieved by the message 105 and the additional message 750. 910 The message is a Gaochuang exclusive message, and the message 105 and the additional message 910 can provide a position comparison output (PCOM) function while realizing the torque control. The following figure shows the configuration of message 105 +750.




figure9-45 105 +750 message configuration

Add and set process object TO_PositionmingAxis

The new process object can refer to 9.3.3, where the data connection of the additional message needs to be added when configuring "data exchange with the drive device", as shown in the following figure.




figure9-46 Add torque data to process objects

In particular, when using additional packets 910, it is necessary to click "Show all modules" when adding additional packets of torque data, as shown in the following figure.




figure9-47 Adding Torque Data to Process Objects - Additional Packets 910

Due to the application of torque control mode, uncheck "Start Follow Error Monitoring" in "Follow Error" in the process object.




figure9-48 Uncheck to enable follow error monitoring

Add MC_PosServo Tissue Block

As shown in Figures 9-48 and 9-49, enabling closed-loop torque requires setting with the MV_PostServo tissue block and adding a normally open contact and an assignment block to this block. When using the position control mode of the 105 message, the closed-loop moment needs to be set to the closed state.




figure9-49 Add MC_PostServo Organizational Block




figure9-50 Set MC_PostServo

Add MC_TORQUEADDITIVE and MC_TORQUEANGE to the Main block as shown in Figure 9-50. wherein the assignment block is set to the closed-loop torque control bit of the process shaft for enabling the closed-loop torque control. The maximum torque of the torque output is limited by setting "UpperLimit" in MC_TORQUEADDITIVE by adjusting the magnitude of the "Value" control torque output in MC_TORQUEADDITIVE.

Torque conversion relationship between Broadway and the drive

It should be noted here that the torque setpoint sent to the drive by Broadway is a proportional value. For example, if the "Value" in MC_TORQUEADDITIVE is set to, the reference torque of the process object is, the ratio value sent to the drive end is, and the command current of the drive is: $T_0 T_1 T_0 / T_1 I C M D$

$$I C M D = I L I M \times \frac{T_0}{T_1}$$

where $I C M D$ is the current limit set in Servostudio. $I L I M$




figure9-51 Add MC_TORQUEADDITIVE and MC_TORQUEANGE tissue blocks

9.3.7 Packet 105 +900 configuration and application

The 900 message is the exclusive additional message of Gao Chuang, which provides the position comparison output PCOM (Position Compare Output) function. The use of the PCOM function requires the use of non-periodic data reading and writing functions.

1. Non-periodic data read/write function block SinaParaS

The block SinaParaS in Broadway is used to read and write off-cycle data in the drive. The parameters of the drive can be set on the Broadway V17 side using the SinaParaS module. The "AxisNO" entered in all SinaPara blocks is 1, and the "hardwareid" is the hardware identifier of the corresponding drive device message. The method of looking up the hardware identifier is shown in Figure 9-51.

In addition, it should be noted that the reading and writing of 16-bit aperiodic data are completed by "valueread1" and "valuewrite1", respectively, and the reading and writing of 32-bit aperiodic data are completed by "valueread2" and "valuewrite2", respectively.




figure9-52 Find Drive Packet Hardware Identifiers




figure9-53 Hardwareid in SinaParaS

2. Example of message configuration and application

The Broadway parameter number for this function is shown in the following table.

Parameter name:	Parameter number	Index number	DESCRIPTION
PCOMCNTRL1	10401	0	Configure Position Comparison Departure Output (PCOM) Module 1 Bit0: 0 = PCOM module not enabled 1 = PCOM Module Enabled Bits 1, 2: PCOM Module Type 00 = Periodic 01 = Position table 10 = Timing Bit 3: Enable type (valid only for Periodic mode) 0 = PCOM Ongoing Enable 1 = PCOM is enabled between start and end position Bit 4: Output type (valid only for Periodic and Position Table) 0 = Switch to position comparison state 1 = Compare matched pulses

PCOMCNTRL2	10402	0	Id.
PCOMSTATUS1	10403	0	<p>Indicates the actual state of PCOM Module 1</p> <p>Bit 0:</p> <p>0 = PCOM module not enabled 1 = PCOM Module Enabled</p> <p>Bits 1, 2, 3:</p> <p>000 = No Error 001 = PCOM output not configured 002 = Start and end positions do not match 003 = Frequency exceeds maximum</p> <p>Bits 4, 5, 6:</p> <p>000 = No Warning 001 = Pulse width too large</p>
PCOMSTATUS2	10404	0	Id.
PCOMDIR1	10405	0	<p>For the PCOM1 module defines whether the output trigger is in the positive or negative direction during motor movement</p> <p>0 = Negative Direction 1 = Positive Direction 2 = Bidirectional</p>
PCOMDIR2	10406	0	Id.
PCOMTABLELEN1	10407	0	<p>For PCOM1 the quantity in the PCOM table is defined</p> <p>Range: 0 ~ 4</p>
PCOMTABLELEN2	10408	0	Id.
PCOMWIDTH1	10409	0	<p>For PCOM1 the pulse width of the output signal is defined</p> <p>Unit: 0.1µs (in Broadway V17 and Servostudio)</p>
PCOMWIDTH2	10410	0	Id.
PCOMSTART1	10411	0	<p>For PCOM Module 1. Defines where the PCOM module starts triggering output.</p> <p>Valid only if the Periodic type of the PCOM module is defined. Applies only when the PCOM module is defined as active between a specific start and end point.</p> <p>The value of this position must be less than PCOMEND1.</p> <p>Unit: 0.001°</p>
PCOMSTART2	104012	0	Id.
PCOMEND1	10413	0	For PCOM Module 1. Defines where the

			<p>PCOM module stops triggering the output.</p> <p>Valid only if the Periodic type of the PCOM module is defined. Applies only when the PCOM module is defined as active between a specific start and end point.</p> <p>The value of this position must be greater than PCOMEND1</p>
PCOMEND2	10414	0	Id.
PCOMN1	10415	0	<p>For PCOM Module 1. Defines a fixed number (interval) of feedback counts between each output trigger position. Valid only if the Periodic type of the PCOM module is defined. The PCOM module continuously compares the actual position with the values defined in PCOM. Whenever the encoder counter equals PCOM, the PCOM module triggers the output. Applies only when the PCOM module is defined as active between a specific start and end point.</p> <p>Unit: 0.001°</p>
PCOMN2	10416	0	Id.
PCOMTABLE1	10417	-	<p>Define a set of trigger output locations for PCOM Module 1</p> <p>Unit: 0.001° (on the way)</p> <p>See below for how to set up Broadway</p>
PCOMTBAL2	10418	-	Id.

3. Configure additional packets for the drive 900

Using the PCOM function requires reading and writing the module SinaParaS with an off-cycle parameter on the way, and adding a hardware identifier of 900 additional packets in its "HardwareID". The hardware identifier reference method of the corresponding message of the drive is shown in Figure 9-53.




figure9-54 Configure 105 and 900 packets for drives

4. Use the watchdog to modify the control word for PCOM1

It should be noted that before modifying the parameters of the drive PCOM function, the control word of PCOM should be set to 0 in the monitoring table. After modifying the PCOM parameters using SinaParaS, the control word of PCOM should be set to 19 in the monitoring table, as shown in the following figure.




figure9-55 Modify PCOM1 control word

In particular, the PCOM Tble Entry is a position table with parameter number 10417 with a special writing mechanism. The parameter subindexes are: Table address, Write value, Execute, Read value. If the first position in the position table is set to 20°, it needs to be executed 3 times. The first execution determines the sequence number of the position table, the second execution determines the value of the position, and the third execution indicates the confirmation of the above two executions, as shown in the following table.

Set the 2nd value of PCOM1 Tble Entry to 20°

		Parameter	Index	ValueWrite1	ValueWrite2
1	Execution	10417	0	2	2
2	Execution	10417	1	20000	20000
3	Execution	10417	2	1	1

There are two ways to set the interface of the pulse output before using the drive PCOM function:

Use SinaParaS to set the digital output 7 port of the drive to the output port of PCOM1

		Parameter	Index	ValueWrite1	ValueWrite2
1	Execution	10156	0	7	7
2	Execution	10156	1	27	27

Use Servostudio to set the digital output 7 port of the drive to the output port of PCOM1

As shown in the following figure, set the output of the PCOM1 pulse in the "Digital I/O" of Servostudio2, set it to "27-PCOM Module 1" in "Output 7" or "Output 8", and click "Save".




figure9-56 Configure the PCOM1 outlet for the drive

Finally, it should be noted that the "unit of motion" of the drive needs to be set to the unit of rotation position deg.

9.3.8 Packet 111 +920 Configuration and Application

The Gaochuang CDHD2S-PN-RS driver can use the Siemens 111 message and the Gaochuang additional message 920 with an external force sensor to achieve a closed-loop force control function. The sending word FCSETPOINT of the additional message 920 is set through the TIA Portal as the analog voltage command, and the CDHD2S-PN-RS receives the analog signal of the force sensor through the analog input channel 1 (ANIN1), and realizes the closed-loop force control through the above command and feedback. 920 The content of the additional message is detailed in 4.2.2, 4.4.13 and 4.5.12.




figure9-57 Configure 920 additional packets for the drive

Closed loop force control setting precautions

If the PFB is negative in the direction in which the motor is facing the sensor, the FCSETPOINT must be set to a positive value. In this case, the pressure control takes effect when the ANIN1 sensor reads a positive value. As shown in Figure 1.

If the PFB is positive in the direction of the motor towards the sensor, the FCSETPOINT must be set to a negative value. In this case, when the ANIN1 sensor reads a negative value, the pressure control takes effect, as shown in Figure 2.

Otherwise, the ANIN1INV can be reversed, or the direction of motor movement can be reversed.

TIA Portal Parameter Number (PNU) related to closed-loop force control function

Parameter name:	Parameter number	Index number	DESCRIPTION
FCMODE	10566	0	Setting the Closed-Loop Force Control Mode
FCLPF	10567	0	Set the cutoff frequency of the low-pass filter for the closed-loop force control command Unit: Hz
FCSLOPE	10568	0	Set the rate of change of the closed-loop force

Parameter name:	Parameter number	Index number	DESCRIPTION
			control pressure command Unit: V/s
FCKP	10569	0	Set the proportional gain of the closed-loop force control
FCEINSETTIME	10570	0	Set the duration for which the closed-loop force control is considered to "hit the target" Unit: ms
FCE	10571	0	Difference between the set pressure value of the closed-loop force control and the actual pressure Unit: V
FCEINSET	10572	0	Set the voltage tolerance threshold for determining that the force value reaches the target state Unit: V
FCCMD	10573	0	Closed loop force control voltage command, command value after FCSLOPE limit Unit: V
ANIN1INV	10576	0	Set whether the symbol of analog input channel 1 is reversed
FCMAXDIST	10615	0	Set the maximum movement distance after the closed-loop force control is turned on Unit: mm

9.4 PROFINET operation

The PROFINET bus protocol is an open, real-time industrial Ethernet standard for automation developed by PI (Profibus International). Due to its efficiency, flexibility and scalability, PROFINET has an important position and market share in Industrial Ethernet.

PROFINET has three communication modes:

1. Based on Industrial Ethernet TCP/IP and IT standards. Its response time is about 100ms, which is due to application scenarios that do not require high real-time performance.

2. PROFINET RT: The response time for data exchange between the sensor (remote IO device) and the executing device is more stringent, the response time is about 1-10ms.

3. PROFINET IRT: The real-time communication requirements are the highest, which can meet the response time requirements of MotionControl. At 100 nodes, the response time can be less than 1ms, and the jitter error is less than 1μs.

This chapter introduces the functions supported by CDHD2S-PN-RS, packets and their character definitions.

9.4.1 PROFINET newsletter

The drive supports the following features:

- RT (real-time)
- IRT (isochronous real-time)
- MRP (Media Redundancy Protocol): media redundancy without jitter
- MRPD (Media Redundancy with Duplicate Paths): Media redundancy without jitter.
- Diagnostic alarms are equivalent to the fault classes defined in the PROFIdrive protocol.
- No removable storage media required for device replacement: the new drive gets its device name from the IO controller, not from its SD card or programming device.

9.4.2 Messages

1. Supported Messages

The Gaochuang CDHD2S-PN-RS driver supports standard messages, Siemens messages, and Gaochuang's additional messages, which can meet the application needs of AC1, AC2, and AC4.

In order to distinguish the properties of data transmission and reception, a receiving word and a sending word are defined. For drive devices, the field received from the PLC is called the receive word, and the field sent to the PLC is called the send word, where one PZD is a word.

Standard message 5 and Siemens message 105 can only be used in the case of TIA Portal v14 or later.

Supported Messages

Telegram	Maximum of PZD	
	Receive Word	Send Word
Standard Telegram 1	2	2

Telegram	Maximum of PZD	
Standard Telegram 2	4	4
Standard Telegram 3	5	9
Standard Telegram 5	9	9
Standard Telegram 7	2	2
Standard Telegram 9	10	5
SEMENS Telegram 102	6	10
SEMENS Telegram 105	10	10
SEMENS Telegram 110	12	7
SEMENS Telegram 111	12	12
SEMENS Telegram 112	17	12
Supplementary Telegram 750(SEIMENS)	3	1
Supplementary Telegram 900(SERVOTRONIX)	2	2
Supplementary Telegram 910(SERVOTRONIX)	5	3

Packets for speed control mode

Tel.	1		2		3		5		102		105	
A.C.	1		1		1,4		4		1,4		4	
PZD1	STW1	ZSW1	STW1	ZSW1	STW1	ZSW1	STW1	ZSW1	STW1	ZSW1	STW1	ZSW1
PZD2	NSOLL_A	NIST_A	NSOLL_B	NIST_B	NSOLL_B	NIST_B	NSOLL_B	NIST_B	NSOLL_B	NIST_B	NSOLL_B	NIST_B
PZD3	Recevie Word	Send Word										
PZD4			STW2	ZSW2	STW2	ZSW2	STW2	ZSW2	STW2	ZSW2	STW2	ZSW2
PZD5					G1_STW	G1_ZSW	G1_STW	G1_ZSW	MOMRED	MELDW	MOMRED	MELDW
PZD6						G1_XIST1	XERR	G1_XIST1	G1_STW	G1_ZSW	G1_STW	G1_ZSW
PZD7						G1_XIST2	KPC	G1_XIST2		G1_XISIT1	XERR	G1_XIST1
PZD8										G1_XIST2	KPC	G1_XIST2
PZD9												
PZD10												

Packet for basic positioning controller

Telegram	7		9		110		111	
Application Class	3		3		3		4	
PZD1	STW1	ZSW1	STW1	ZSW1	STW1	ZSW1	STW1	ZSW1
PZD2	SATZANW	AKTSATZ	SATZANW	AKTSATZ	SATZANW	AKTSATZ	POS_STW1	POS_ZSW1
PZD3	Recevie Word	Send Word	STW2	ZSW2	POS_STW	POS_ZSW	POS_STW2	POS_ZSW2
PZD4			MDI_TAPROS	XISTA	STW2	ZSW2	STW2	ZSW2
PZD5					VERRIDE	MELDW	VERRIDE	MELDW
PZD6			MDI_VELOCITY		MDI_TARPOS	XIST_A	MDI_TARPOS	XIST_A
PZD7					MDI_VELOCITY		MDI_VELOCITY	NIST_B
PZD8							MDI_ACC	
PZD9							MDI_DEC	
PZD10					MDI_ACC		MDI_ACC	FAULT_CODE

Telegram	7	9	110	111
PZD11			MDI_DEC	MDI_DEC
PZD12			MDI_MOD	user_rx
				WARN_CODE
				user_tx

Packets for basic positioning controller: 112

Telegram	112	
Application Class	4	
PZD1	STW1	ZSW1
PZD2	POS_STW1	POS_ZSW1
PZD3	POS_STW2	POS_ZSW2
PZD4	STW2	ZSW2
PZD5	Override	Reserved
PZD6	MDI_TARPOS_F (Float)	XIST_F (Float)
PZD7		
PZD8	MDI_VELOCITY_F (Float)	VIST_F (Float)
PZD9		
PZD10	MDI_ACC_F (Float)	MELDW
PZD11		FAULT_CODE
PZD12	MDI_DEC_F (Float)	WARN_CODE
PZD13		Reserved (Float)
PZD14		
PZD15		
PZD16		
PZD17	REF_COORDINATE (Float)	

2. Additional Messages

You must first select a primary message before setting up additional messages. If the main message is changed, the attached message will be automatically disabled. Therefore, after changing the main message, the auxiliary message must be reset.

However, if the control mode of the drive is changed, the additional message remains in its state in the previous control mode, and the additional message is not automatically disabled. For example, if the additional message 750 is activated before changing the control mode, the additional message 750 is still available after the control mode is changed.

After the additional message is enabled, the number of the additional message PZD follows the main message PZD. When 750 packets are used in unwinding applications, the built-in braking resistance of the drive is not sufficient to absorb excess regenerative energy. When using the 750 message, if any of the following settings are made, the motor will experience uncontrollable acceleration:

Set the upper torque limit to a negative value via PZD M_limit_POS

Set the lower torque limit to a positive value via PZD M_limit_NEG

Telegram	750	
Application Class	—	
PZD1	M_ADD1	M_ACT
PZD2	M_LIMIT_POS	—
PZD3	M_LIMIT_NEG	

Telegram	900	
Application Class	—	
PZD1	PCOM1_STW	PCOM1_ZSW
PZD2	PCOM2_STW	PCOM2_ZSW

Telegram	910	
Application Class	—	
PZD1	M_ADD1	M_ACT
PZD2	M_LIMIT_POS	—
PZD3	M_LIMIT_NEG	
PZD4	PCOM1_STW	PCOM1_ZSW
PZD5	PCOM2_STW	PCOM2_ZSW

9.4.3 I/O Data Signal

signal	Transceiver Properties	DESCRIPTION	Data Types	
STW1	Receiving Words	Control word 1	U16	
STW2	Receiving Words	Control word 2	U16	
ZSW1	Send word	Status word 1	U16	
ZSW2	Send word	Status word 2	U16	
NSOLL_A	Receiving Words	Speed setpoint A (16 bit)	I16	4000 hex $\hat{=}$ VLIM

NSOLL_B	Receiving Words	Speed setpoint (32 bit)	I32	40000000 hex $\hat{=}$ VLIM
NIST_A	Send word	Rpm Actual A (16 bit)	I16	4000 hex $\hat{=}$ VLIM
NIST_B	Send word	Rpm Actual B (32 bit)	I32	40000000 hex $\hat{=}$ VLIM
G1_STW	Receiving Words	Encoder 1 control word	U16	
G1_ZSW	Send word	Encoder 1 status word	U16	
G1_XIST1	Send word	Encoder 1 physical position 1	U32	
G1_XIST2	Send word	Encoder 1 physical position 2	U32	
MOMRED	Receiving Words	Torque attenuation	I16	4000 hex $\hat{=}$ ILIM
MELDW	Send word	Message word	U16	
KPC	Receiving Words	Position controller gain factor	I32	
XERR	Receiving Words	Position deviation	I32	
SATZANW	Receiving Words	Location Selection Segment	U16	
AKTSATZ	Send word	Selected Location Segment	U16	
MDI_TARPOS	Receiving Words	MDI Location	I32	1 hex $\hat{=}$ 1 LU
MDI_VELOCITY	Receiving Words	MDI Speed	I32	1 hex $\hat{=}$ 1000 LU/min
MDI_ACC	Receiving Words	MDI Acceleration Ratio	I16	4000 hex $\hat{=}$ 100% If set to 0, then MDI_ACC = 4000Hex
MDI_DEC	Receiving Words	MDI deceleration ratio	I16	4000 hex $\hat{=}$ 100% If set to 0, then MDI_DEC = 4000Hex
XIST_A	Send word	Position Actual A	I32	1 hex $\hat{=}$ 1 LU
OVERRIDE	Receiving Words	Speed Speed Multiplier	I16	4000 hex $\hat{=}$ 100%
MDI_MODE	Receiving Words	Location MDI Mode	U16	
FAULT_CODE	Send word	Error code	U16	
WARN_CODE	Send word	Alarm Code	U16	
POS_ZSW	Send word	Position Status Word	U16	
M_ADD1	Receiving	Additional torque	I16	4000 hex $\hat{=}$ ILIM

	Words			
M_LIMIT_POS	Receiving Words	Positive torque limit	I16	4000 hex $\hat{=}$ ILIM When the message is not 102/105, set 0: M_LIMIT_POS=4000Hex
M_LIMIT_NEG	Receiving Words	Negative torque limit	I16	4000 hex $\hat{=}$ ILIM When the message is not 102/105, set 0: M_LIMIT_POS=4000Hex
M_ACT	Send word	Actual Torque	Float	4000 hex $\hat{=}$ ILIM
user_rx	Receiving Words	User-defined receive word PNPZDUSERR = 0: No function 1: Torque Feed Forward 2: Speed feed forward 3: Drive DO output 4: Trip Limit Signal	I16	Torque Feed Forward: (4000 hex $\hat{=}$ ILIM) Speed feed forward: (4000 hex $\hat{=}$ VLIM) Drive DO Output: Bit 0~Bit 5 = DO1~DO5 Trip Limit Signal: 0: Unlimited signal 1: Positive Limit Trigger 2: Negative Limit Trigger 3: Positive and negative limits are triggered
user_tx	Send word	User-defined send word PNPZDUSERT = 0: No function 1: Actual torque 2: Actual absolute current 3: Drive DI status	I16	Actual Torque: (4000 hex $\hat{=}$ ILIM) Actual absolute current: (4000 hex $\hat{=}$ ILIM)
POS_STW	Receiving Words	Positioning control word	U16	
POS_STW1	Receiving Words	Positioning control word 1	U16	
POS_STW2	Receiving Words	Positioning control word 2	U16	
POS_ZSW1	Send word	Positioning status word 1	U16	
POS_ZSW2	Send word	Positioning status word 2	U16	
PCOM1_STW	Receiving Words	Position comparison output control word 1	U16	
PCOM2_STW	Receiving Words	Position comparison output control word 2	U16	

PCOM1_ZSW	Send word	Position Comparison Output Status Word 1	U16	
PCOM2_ZSW	Send word	Position Comparison Output Status Word 2	U16	

9.4.4 Control Word Definition

1. STW1 control word (messages 1, 2, 3, 5)

When using message 5, STW1.4, STW1.5, and STW1.6 are disabled. STW1.10 must be set to 1 to allow the PLC to control the drive.

signal	DESCRIPTION
STW1.0	= ON (can enable pulses) 0 = OFF1 (Dec deceleration by deceleration stop, eliminate pulse, ready to start)
STW1.1	1 = No off 2 (can be enabled) 0 = OFF2 (cancel pulse immediately and disable connection)
STW1.2	1 = NO off 3 (allowed to enable) 0 = OFF3 (Decstop deceleration stop by OFF3 deceleration, eliminate pulse and disable connection)
STW1.3	1 = allowed to run (can enable pulses) 0 = No Running (Cancel Pulse)
STW1.4	1 = Operating condition (can enable ramp function generator) 0 = Disable the ramp function generator (set the output of the ramp function generator to zero)
STW1.5	1 = Continue Slope Function Generator 0 = Freeze ramp function generator (freeze ramp function generator output)
STW1.6	1 = Enable Setpoint 0 = Prohibit set value (set the input of the ramp function generator to zero)
STW1.7	= 1 Answer Fault
STW1.8	Keep
STW1.9	Keep
STW1.10	1 = Controlled by PLC
STW1.11	1 = Set value is reversed
STW1.12	Keep
STW1.13	Keep
STW1.14	Keep
STW1.15	Keep

2. STW2 control word (message 2, 3, 5)

signal	DESCRIPTION
STW2.0	Keep
STW2.1	Keep
STW2.2	Keep
STW2.3	Keep
STW2.4	Keep
STW2.5	Keep
STW2.6	Keep
STW2.7	Keep
STW2.8	1 = Run to fixed stop
STW2.9	Keep
STW2.10	Keep
STW2.11	Keep
STW2.12	Master station life symbol, bit 0
STW2.13	Master station life symbol, bit 1
STW2.14	Master station life symbol, bit 2
STW2.15	Master station life symbol, bit 3

3.STW1 control word (message 102, 105)

When using message 105, STW1.4, STW1.5 and STW1.6 are disabled. STW1.10 must be set to 1 to allow the PLC to control the driver.

signal	DESCRIPTION
STW1.0	= ON (can enable pulses) 0 = OFF1 (Dec deceleration by deceleration stop, eliminate pulse, ready to turn on)
STW1.1	1 = NO off 2 (allowed to enable) 0 = OFF2 (cancel the pulse immediately and disable the connection)
STW1.2	1 = NO off 3 (allowed to enable) 0 = OFF3 (decelerate DESTOP stop by OFF3, eliminate pulse and disable connection)
STW1.3	1 = allowed to run (can enable pulses) 0 = No Running (Cancel Pulse)
STW1.4	1 = Operating condition (can enable ramp function generator) 0 = Disable the ramp function generator (set the output of the ramp function generator to zero)
STW1.5	1 = Continue Slope Function Generator 0 = Freeze ramp function generator (freeze ramp function generator output)

signal	DESCRIPTION
STW1.6	1 = Enable Setpoint 0 = Prohibit set value (set the input of the ramp function generator to zero)
STW1.7	= 1 Answer Fault
STW1.8	Keep
STW1.9	Keep
STW1.10	1 = Controlled by PLC
STW1.11	1 = ramp function generator active
STW1.12	Keep
STW1.13	Keep
STW1.14	1 = Closed-loop torque control is in effect 0 = Closed-loop speed control is in effect
STW1.15	Keep

4.STW2 control word (message 102, 105)

signal	DESCRIPTION
STW2.0	Keep
STW2.1	Keep
STW2.2	Keep
STW2.3	Keep
STW2.4	Keep
STW2.5	Keep
STW2.6	Keep
STW2.7	Keep
STW2.8	1 = Run to fixed stop
STW2.9	Keep
STW2.10	Keep
STW2.11	Keep
STW2.12	Master station life symbol, bit 0
STW2.13	Master station life symbol, bit 1
STW2.14	Master station life symbol, bit 2
STW2.15	Master station life symbol, bit 3

5.STW1 control word (message 7, 9, 110, 111, 112)

STW1.10 must be set to 1 to allow PLC control drive.

signal	DESCRIPTION
STW1.0	= ON (can enable pulses) 0 = OFF1 (Dec deceleration by deceleration stop, eliminate pulse, ready to turn on)
STW1.1	1 = NO off 2 (allowed to enable) 0 = OFF2 (cancel the pulse immediately and disable the connection)
STW1.2	1 = NO off 3 (allowed to enable) 0 = OFF3 (Decstop deceleration stop by OFF3 deceleration, eliminate pulse and disable connection)
STW1.3	1 = allowed to run (can enable pulses) 0 = No Running (Cancel Pulse)
STW1.4	1 = Do not refuse to perform tasks 0 = Refuse to perform the task (ramp down at maximum deceleration)
STW1.5	1 = No pause in tasks 0 = Suspend Task
STW1.6	= Activate Run Task
STW1.7	= Answer Fault
STW1.8	1 = Jog 1 signal source
STW1.9	1 = Jog 2 signal source
STW1.10	1 = Controlled by PLC
STW1.11	1 = Start Back to Reference Point 0 = stop back to reference point
STW1.12	Keep
STW1.13	= External Segment Switching
STW1.14	Keep
STW1.15	Keep

6.STW2 control word (message 9, 110, 111, 112)

signal	DESCRIPTION
STW2.0	Keep
STW2.1	Keep
STW2.2	Keep
STW2.3	Keep
STW2.4	Keep
STW2.5	Keep
STW2.6	Keep

signal	DESCRIPTION
STW2.7	Keep
STW2.8	1 = Run to fixed stop
STW2.9	Keep
STW2.10	Keep
STW2.11	Keep
STW2.12	Master station life symbol, bit 0
STW2.13	Master station life symbol, bit 1
STW2.14	Master station life symbol, bit 2
STW2.15	Master station life symbol, bit 3

7.G1_STW encoder 1 control word

signal	DESCRIPTION															
G1_STW.0	Select the features that need to be activated (by setting the bit value = 1)															
G1_STW.1																
G1_STW.2																
G1_STW.3	功能编号	位7=0时的功能（搜索参考点挡块）		位7=1时的功能（实时测量）												
	1	参考点挡块 1		↗ 测量指针 1												
	2	参考点挡块2		↘ 测量指针2												
	3	参考点挡块3		↗ 测量指针3												
	4	参考点挡块4		↘ 测量指针4												
G1_STW.4	Start/Stop/Read Selected Functions															
G1_STW.5	<table><tr><td>0</td><td>1</td><td>0</td><td>1</td></tr><tr><td>0</td><td>0</td><td>1</td><td>1</td></tr><tr><td>0</td><td>0</td><td>0</td><td>0</td></tr></table>				0	1	0	1	0	0	1	1	0	0	0	0
0	1	0	1													
0	0	1	1													
0	0	0	0													
G1_STW.6	Interrupt function Read ratings Activate selected features No function															
G1_STW.7	Mode that requires activation of the feature 1 = Rapid Measurement 0 = Search Reference Point Block															
G1_STW.8	Keep															
G1_STW.9	Keep															
G1_STW.10	Keep															
G1_STW.11	Keep															
G1_STW.12	Master Vital Signal, Bit 0															
G1_STW.13	1 = Request periodic transmission of absolute position values in Gn_XIST2															

signal	DESCRIPTION
G1_STW.14	1 = Request dwell axis encoder
G1_STW.15	= Answer encoder failure

8.SATZANW control word

signal	DESCRIPTION
SATZANW.0	1 = Run Segment Selection, Bit 0
SATZANW.1	1 = Run Segment Selection, Bit 1
SATZANW.2	1 = Run Segment Selection, Bit 2
SATZANW.3	1 = Run Segment Selection, Bit 3
SATZANW.4	1 = Run Segment Selection, Bit 4
SATZANW.5	1 = Run Segment Selection, Bit 5
SATZANW.6	Keep
SATZANW.7	Keep
SATZANW.8	Keep
SATZANW.9	Keep
SATZANW.10	Keep
SATZANW.11	Keep
SATZANW.12	Keep
SATZANW.13	Keep
SATZANW.14	Keep
SATZANW.15	1 = Activate MDI 0 = Do not activate MDI

9.MDI_MOD control word

signal	DESCRIPTION
MDI_MOD.0	1 = Absolute Positioning Selected 0 = Relative Positioning Selected
MDI_MOD.1	0 = Absolute positioning by shortest distance 1 = Absolute positioning in the positive direction 2 = Absolute positioning in the negative direction 3 = Absolute positioning by shortest distance
MDI_MOD.2	Keep
MDI_MOD.3	Keep
MDI_MOD.4	Keep
MDI_MOD.5	Keep
MDI_MOD.6	Keep
MDI_MOD.7	Keep

signal	DESCRIPTION
MDI_MOD.8	Keep
MDI_MOD.9	Keep
MDI_MOD.10	Keep
MDI_MOD.11	Keep
MDI_MOD.12	Keep
MDI_MOD.13	Keep
MDI_MOD.14	Keep
MDI_MOD.15	Keep

10. POS_STW control word

signal	DESCRIPTION
POS_STW.0	1 = Tracking Mode Active 0 = Tracking mode not activated
POS_STW.1	1 = Set Reference Point 0 = no reference point set
POS_STW.2	1 = Reference point block active
POS_STW.3	Keep
POS_STW.4	Keep
POS_STW.5	1 = jog, incremental activation 0 = jog, speed activation
POS_STW.6	Keep
POS_STW.7	Keep
POS_STW.8	Keep
POS_STW.9	Keep
POS_STW.10	Keep
POS_STW.11	Keep
POS_STW.12	Keep
POS_STW.13	Keep
POS_STW.14	Keep
POS_STW.15	Keep

If the tracking mode is activated, the position setting will follow the actual position value, that is, the position setting value = the actual position value.

11. POS_STW1 Positioning Control Word

signal	DESCRIPTION
POS_STW1.0	Running segment selection, bit 0
POS_STW1.1	Run Segment Selection, Bit 1

signal	DESCRIPTION
POS_STW1.2	Run Segment Selection, Bit 2
POS_STW1.3	Run Segment Selection, Bit 3
POS_STW1.4	Run Segment Selection, Bit 4
POS_STW1.5	Run Segment Selection, Bit 5
POS_STW1.6	Keep
POS_STW1.7	Keep
POS_STW1.8	1 = Absolute Positioning Selected 0 = Relative Positioning Selected
POS_STW1.9	0 = Absolute positioning by shortest distance
POS_STW1.10	1 = Absolute Positioning/MDI Direction Selection, Fwd 2 = Absolute Positioning/MDI Direction Selection, Negative 3 = Absolute positioning by shortest distance
POS_STW1.11	Keep
POS_STW1.12	1 = continuous transmission 0 = Activate MDI Segment Switching by Running Task (STW1.6)
POS_STW1.13	Keep
POS_STW1.14	1 = Selected signal adjustment 0 = Selected signal positioning
POS_STW1.15	1 = MDI Selection

12.POS_STW2 Positioning Control Word

signal	DESCRIPTION
POS_STW2.0	1 = Tracking Mode Active
POS_STW2.1	1 = Set Reference Point
POS_STW2.2	1 = Reference point block active
POS_STW2.3	111 Message: Keep 112 Message: Encoder adjustment function
POS_STW2.4	Keep
POS_STW2.5	1 = jog, incremental activation 0 = jog, speed activation
POS_STW2.6	Keep
POS_STW2.7	Keep
POS_STW2.8	Keep
POS_STW2.9	Keep
POS_STW2.10	Keep
POS_STW2.11	Keep

signal	DESCRIPTION
POS_STW2.12	Keep
POS_STW2.13	Keep
POS_STW2.14	1 = Activate Soft Limit Switch
POS_STW2.15	1 = Activate Hard Limit Switch

If the tracking mode is activated, the position setting value will follow the actual position value, that is, the position setting value = the actual position value.

9.4.5 Status Word Definition

c1.ZSW1 Status Word (Messages 1, 2, 3, 5)

signal	DESCRIPTION
ZSW1.0	1 = Servo is ready to be turned on
ZSW1.1	1 = Ready to run
ZSW1.2	1 = Run Enabled
ZSW1.3	1 = faulty
ZSW1.4	1 = Invalid free parking (invalid off2)
ZSW1.5	1 = Invalid fast parking (invalid off3)
ZSW1.6	1 = Prohibit connection takes effect
ZSW1.7	1 = Alarm present
ZSW1.8	1 = deviation of speed setpoint from actual value within VELWINDOW tolerance
ZSW1.9	1 = Control Request
ZSW1.10	1 = Comparison value of f or n reached or exceeded
ZSW1.11	0 = Limit of I, M or P reached
ZSW1.12	1 = Open brake
ZSW1.13	1 = No motor over-temperature alarm
ZSW1.14	1 = Motor forward rotation ($V \geq 0$) 0 = Motor reverse rotation ($V < 0$)
ZSW1.15	1 = Power Unit No Heat Overload Alarm

2.ZSW2 status word (message 2, 3, 5)

signal	DESCRIPTION
ZSW2.0	Keep
ZSW2.1	Keep
ZSW2.2	Keep
ZSW2.3	Keep

signal	DESCRIPTION
ZSW2.4	Keep
ZSW2.5	1 = alarm level 0
ZSW2.6	1 = Alarm level 1
ZSW2.7	Keep
ZSW2.8	1 = Run to fixed stop
ZSW2.9	Keep
ZSW2.10	1 = Pulse Enabled
ZSW2.11	Keep
ZSW2.12	Slave Life Symbol, Bit 0
ZSW2.13	Slave Life Symbol, Bit 1
ZSW2.14	Slave life symbol, bit 2
ZSW2.15	Slave life symbol, bit 3

3. ZSW1 status word (message 102, 105)

signal	DESCRIPTION
ZSW1.0	1 = Servo is ready to be turned on
ZSW1.1	1 = Ready to run
ZSW1.2	1 = Run Enabled
ZSW1.3	1 = faulty
ZSW1.4	1 = Invalid free parking (invalid off2)
ZSW1.5	1 = Invalid fast parking (invalid off3)
ZSW1.6	1 = Prohibit connection takes effect
ZSW1.7	1 = Alarm present
ZSW1.8	1 = deviation of speed setpoint from actual value within VELWINDOW tolerance
ZSW1.9	1 = Control Request
ZSW1.10	1 = Comparison value of f or n reached or exceeded
ZSW1.11	1 = alarm level 0
ZSW1.12	1 = Alarm level 1
ZSW1.13	Keep
ZSW1.14	1 = Closed-loop torque control is in effect
ZSW1.15	Keep

4. ZSW2 status word (message 102, 105)

signal	DESCRIPTION
ZSW2.0	Keep

signal	DESCRIPTION
ZSW2.1	Keep
ZSW2.2	Keep
ZSW2.3	Keep
ZSW2.4	1 = Slope Function Generator is not active
ZSW2.5	1 = Open brake
ZSW2.6	Keep
ZSW2.7	Keep
ZSW2.8	1 = Run to fixed stop
ZSW2.9	Keep
ZSW2.10	Keep
ZSW2.11	Keep
ZSW2.12	Slave Life Symbol, Bit 0
ZSW2.13	Slave Life Symbol, Bit 1
ZSW2.14	Slave life symbol, bit 2
ZSW2.15	Slave life symbol, bit 3

5. ZSW1 status word (message 7, 9, 110, 111, 112)

signal	DESCRIPTION
ZSW1.0	1 = Ready to connect
ZSW1.1	1 = Ready to run (DC bus voltage loaded, pulse suppression)
ZSW1.2	1 = Run Enabled (Drive Follow VCMD)
ZSW1.3	1 = faulty
ZSW1.4	1 = Invalid free parking (invalid off2)
ZSW1.5	1 = Invalid fast parking (invalid off3)
ZSW1.6	1 = Prohibit connection takes effect
ZSW1.7	1 = Alarm present
ZSW1.8	1 = follow error within tolerance
ZSW1.9	1 = Control Request
ZSW1.10	1 = Destination Arrived
ZSW1.11	1 = Reference point set
ZSW1.12	= Answer run segment activated
ZSW1.13	1 = Fixed setpoint
ZSW1.14	1 = axis accelerated
ZSW1.15	1 = axis decelerated

6.ZSW2 status word (message 9, 110, 111, 112)

signal	DESCRIPTION
ZSW2.0	Keep
ZSW2.1	Keep
ZSW2.2	Keep
ZSW2.3	Keep
ZSW2.4	Keep
ZSW2.5	1 = alarm level 0
ZSW2.6	1 = Alarm level 1
ZSW2.7	Keep
ZSW2.8	1 = Run to fixed stop
ZSW2.9	Keep
ZSW2.10	1 = Pulse Enabled
ZSW2.11	Keep
ZSW2.12	Slave Life Symbol, Bit 0
ZSW2.13	Slave Life Symbol, Bit 1
ZSW2.14	Slave life symbol, bit 2
ZSW2.15	Slave life symbol, bit 3

7.G1_ZSW encoder 1 status word

signal	DESCRIPTION		
G1_ZSW.0	Feedback signal for activation of the function (1 = activation of the function)		
G1_ZSW.1			
G1_ZSW.2	功能编号	用于参考点编号和实时测量	
G1_ZSW.3	1	参考点挡块1或测量指针1	⬆
	2	参考点挡块2或测量指针1	⬇
	3	参考点挡块3或测量指针2	⬆
	4	参考点挡块4或测量指针2	⬇
G1_ZSW.4	1 = Position Actual for Function 1		Rating in Gn_XIST2 (readable)
G1_ZSW.5	1 = Position Actual for Function 2		
G1_ZSW.6	1 = Position Actual for Function 3		
G1_ZSW.7	1 = Position Actual for Function 4		
G1_ZSW.8	Keep		
G1_ZSW.9	Keep		
G1_ZSW.10	Keep		
G1_ZSW.11	1 = Answer encoder fault activation		
G1_ZSW.12	Reserved (for reference point offset)		
G1_ZSW.13	Absolute value periodic transmission		
G1_ZSW.14	Resident encoder activation		

signal	DESCRIPTION
G1_ZSW.15	Encoder failure in Gn_XIST2

8.AKTSATZ

signal	DESCRIPTION
AKTSATZ.0	Running segment activation, bit 0
AKTSATZ.1	Running segment activation, bit 1
AKTSATZ.2	Running segment activation, bit 2
AKTSATZ.3	Running segment activation, bit 3
AKTSATZ.4	Running Segment Activation, Bit 4
AKTSATZ.5	Running segment activation, bit 5
AKTSATZ.6	Keep
AKTSATZ.7	Keep
AKTSATZ.8	Keep
AKTSATZ.9	Keep
AKTSATZ.10	Keep
AKTSATZ.11	Keep
AKTSATZ.12	Keep
AKTSATZ.13	Keep
AKTSATZ.14	Keep
AKTSATZ.15	1 = MDI activation 0 = MDI not activated

9.MELDW status word

signal	DESCRIPTION
MELDW.0	1 = ramp up/down completed 0 = ramp function generator active
MELDW.1	1 = Torque Utilization [%] < ILIMACT
MELDW.2	1 = $ V \leq$ rpm threshold VELTHRESH
MELDW.3	Keep
MELDW.4	Keep
MELDW.5	Keep
MELDW.6	1 = No motor over-temperature alarm
MELDW.7	1 = Power unit has no overheat alarm
MELDW.8	1 = deviation of speed setpoint from actual value within VELWINDOW tolerance
MELDW.9	Keep
MELDW.10	Keep

signal	DESCRIPTION
MELDW.11	1 = Controller Enabled
MELDW.12	1 = Drive Ready
MELDW.13	1 = Pulse Enabled
MELDW.14	Keep
MELDW.15	Keep

10. POS_ZSW1 Positioning Control Word

signal	DESCRIPTION
POS_ZSW1.0	Running program segment bit 0 activation, bit 0
POS_ZSW1.1	Running Program Segment 0 Activated, Bit 1
POS_ZSW1.2	Running Program Segment 0 Activated, Bit 2
POS_ZSW1.3	Running Program Segment 0 Activated, Bit 3
POS_ZSW1.4	Running Program Segment 0 Activated, Bit 4
POS_ZSW1.5	Running program segment 0 activated, bit 5
POS_ZSW1.6	Keep
POS_ZSW1.7	1 = Zero signal activation
POS_ZSW1.8	1 = Negative stop stop block active
POS_ZSW1.9	1 = Forward stop stop stop active
POS_ZSW1.10	1 = jog activation
POS_ZSW1.11	1 = Back to Reference Point Activation
POS_ZSW1.12	Keep
POS_ZSW1.13	1 = Run Segment Activation
POS_ZSW1.14	1 = Adjustment Mode Active
POS_ZSW1.15	1 = MDI activation 0 = MDI not activated

11. POS_ZSW2 Positioning status word

signal	DESCRIPTION
POS_ZSW2.0	1 = Tracking Mode Active
POS_ZSW2.1	1 = Speed Limit Active
POS_ZSW2.2	111 Message: 1 = setpoint available, 112 Message: 1 = Arrive at target location
POS_ZSW2.3	Keep

signal	DESCRIPTION
POS_ZSW2.4	1 = axial forward movement
POS_ZSW2.5	1 = axial backward movement
POS_ZSW2.6	1 = Reach Negative Software Limit Switch
POS_ZSW2.7	1 = Reach forward software limit switch
POS_ZSW2.8	1 = Position Actual $\leq$ Stop Switch Position 1
POS_ZSW2.9	1 = Position Actual $\leq$ Stop Switch Position 2
POS_ZSW2.10	1 = Direct output via run segment 1
POS_ZSW2.11	1 = Direct output via run segment 2
POS_ZSW2.12	1 = Reach a fixed stop
POS_ZSW2.13	1 = Clamping torque to a fixed stop point
POS_ZSW2.14	1 = Run to Fixed Stop Activation
POS_ZSW2.15	1 = Run command activation

12. FCZSW closed loop force control status word

signal	DESCRIPTION
FCZSW.0	1 = Closed-loop force control is on 0 = closed loop force control not on
FCZSW.1	1 = Pressure has reached the set point 0 = pressure does not reach set point
FCZSW.2	1 = Closed loop force control position exceeds set position
FCZSW.3	
FCZSW.4	
FCZSW.5	
FCZSW.6	
FCZSW.7	
FCZSW.8	
FCZSW.9	
FCZSW.10	
FCZSW.11	
FCZSW.12	
FCZSW.13	
FCZSW.14	
FCZSW.15	

9.4.6 General Features

How to park when servo is off

Through the control words STW1.0 and STW1.1 in the PROFINET message, ramp descent and free parking can be triggered:

Ramp down (OFF1)

CONTROL WORD	Set	Instructions
STW1.0	0→1	Power circuit connected, servo motor ready
	0	Motor ramp down

Free Parking (off2)

CONTROL WORD	Set	Instructions
STW1.1	1	Servo motor ready
	0	Motor Free Parking

Quick Stop (OFF3)

Quick stop can be set via PROFINET control word STW1.2

Configure STW1.2

CONTROL WORD	Set	Instructions
STW1.2	1	Servo motor ready
	0	Quick Stop

9.4.7 Detailed explanation of the function of message 111

Bus Gear Ratio Setting

In order to establish the conversion relationship between the actual motor movement parameters and the TIA Portal movement parameters, all movement parameters in the TIA Portal are expressed in units of pulse equivalent (LU), and the conversion relationship is as follows.

For example: PNUM in Servostudio is set to 360000, then:

Rotating motor, $360000 \text{ LU} = 1 \text{ rev}$

a linear motor, where is the actual pitch of the linear motor in Servostudio. $360000 \text{ LU} = 1 \text{ MPITCHMPITCH}$

MDI

When using the MDI function of message 111, the relationship between the input parameters in the SinaPos of the TIA Portal and the actual motor movement parameters is as follows:

Positive: $1 \text{ dec} = 1 \text{ LU}$

Velocity: 1 dec = 1 LU/s

OverV: 1 dec = 1%

OverAcc: 1 dec = 1%

OverDec: 1 dec = 1%, where dec represents decimal.

When ModPos = 1,2,3, relative positioning, absolute positioning and continuous operation modes can be activated respectively. The acceleration and deceleration during its movement are determined by the ACC and Dec in Varcom, respectively, and can be set through the SinaParaS function block.

Related Varcom parameters in MDI mode

Parameter name:	Parameter number	Index number	DESCRIPTION
ACC	20131	0	Acceleration value of the motor Unit:LU/s ²
DEC	20132	0	Deceleration value of the motor Unit:LU/s ²

OverV, OverAcc, OverDec in SinaPos (FB284) is the specified percentage of speed, acceleration, and deceleration. It is recommended that ACC and Dec in Velocity and Varcom in SinaPos (FB284) be set to a constant value, and scaled by setting OverV, OverAcc, and OverDec to meet the needs of the application.

Relative Positioning Mode

Access Requirements

Run mode selection ModePos = 1

Axis EnableAxis = 1

The axis does not have to go back to zero or the absolute value encoder can be in an uncorrected state.

If the switching mode is greater than 3, the shaft must be at rest and can be switched at any time when ModePos = 1,2,3

Specify the target position and speed by inputting the parameter Position, Velocity

Operating conditions CancelTraversing and IntermediateStop must be set to 1, Jog1 and Jog2 must be set to 0

In relative positioning, the direction of movement is determined by the positive and negative values set in Position.

Absolute Positioning Mode

Access Requirements

Run mode selection ModePos = 2

Axis EnableAxis = 1

Axis must be zeroed or encoder corrected

If the switching mode is greater than 3, the shaft must be at rest and can be switched at any time when ModePos = 1,2,3

Specify the target position and speed by entering the parameters Position, Velocity

Specify the percentage of speed, acceleration and deceleration by input parameters OverV, OverAcc, OverDec

Operating conditions CancelTraversing and IntermediateStop must be set to 1, Jog1 and Jog2 must be set to 0

In absolute positioning, the running direction runs to the target position according to the shortest path, and the input parameters Positive and Negative must be 0. If it is a modal axis, the direction can be specified by Positive or Negative

Continuous Operation Mode

Access Requirements

Run mode selection ModePos = 3

Axis EnableAxis = 1

The axis does not have to go back to zero or the absolute value encoder can be in an uncorrected state

If the switching mode is greater than 3, the shaft must be at rest and can be switched at any time when ModePos = 1,2,3

Specify the running speed by inputting the parameter Velocity

Specify the percentage of speed, acceleration and deceleration by input parameters OverV, OverAcc, OverDec

Operating conditions CancelTraversing and IntermediateStop must be set to 1, Jog1 and Jog2 must be set to 0

The direction of operation is determined by Positive and Negative

Proactively return to zero

The active zero return function of the drive is realized by SinaPos ModPos = 4. The PCL sends a zero return signal to the drive, and the drive executes the zero return mode set internally. The following table shows the relevant parameters of the drive zero return. It can be set via the SinaParaS module introduced in 3.2.

Supports 35 zero-return methods for Gaotuang CDHD2S-PN-RS drives, where 17 ~ 32 zero-return methods need to configure the limit DI of the drive. A detailed description of the zero-return method can be found in Hometype in the Varcom manual for the Gaochuang CDHD2S-PN-RS servo drive. <https://www.servotronixdownload.com/h-col-136.html>

Zero back correlation parameter in Varcom

Parameter name:	Parameter number	Index number	DESCRIPTION
HOMETYPE	20152	0	<p>Zero return method performed during zero return</p> <p>Defines when to reverse the direction of motion during zero return, zero return flip-flops (e.g. switch, index), and other conditions.</p>
HOMEACC	20154	0	<p>The rate of addition (subtraction) of the return to zero process.</p> <p>HOMEACC is defined based on currently active units.</p> <p>It is used for acceleration and deceleration of all trajectories (movements) during zeroing back. If the limit switch is enabled, the stop takes effect according to decstop and/or decstoptime and overrides the HOMEACC</p>
HOMESPEED1	20153	0	<p>The initial speed used in the search for limit switches, zero return switches, and zero return on emergency stops.</p> <p>HOMESPEED is defined based on the current limited units</p>
HOMESPEED2	20153	1	<p>The speed used during the zero return process to look for Index marks, + switch transitions, zero return switches, or other zero return trigger sources.</p> <p>To increase the accuracy of trigger capture HOMESPEED2 should be set much lower than HOMESPEED1</p>

Claim:

Run mode selection ModePos = 4

Axis EnableAxis = 1

The zero return switch must be connected to the input point of the PLC, and its signal state passes through the ConfigEPos of the FB284 function block. %X 6 to drive

Specify the percentage of speed, acceleration and deceleration by input parameters OverV, OverAcc, OverDec

Operating conditions CancelTraversing and IntermediateStop must be set to 1, Jog1 and Jog2 must be set to 0

The direction of operation is determined by Positive and Negative

Hardware/Software Limits

Hardware Limit Switches:

- a. If the hardware limit switch is used, you need to input the FB284 function block to ConfigEPos. Set %X 3 to 1 to activate the Hardware Limit feature.
- b. If a hardware limit switch is used, the positive and negative hardware limit switches need to be connected to the IO interface C2 of the CDHD2S-PN-RS drive, and the corresponding interface functions need to be set by Servostudio, as shown in the following figure.

If the hardware limit switch function is activated, the axis can only be run when the hardware limit switch signal is high.




figure9-58 Servostudio I/O Port Function Settings

The following table defines the function of a digital input port for CDHD2S-PN-RS using SinaParaS

Parameter name:	Parameter number	Index number	DESCRIPTION
INMODE	10224	0	Gets/Sets a value that gets the index value of one of the available numeric inputs Range: 0 ~ 11
INMODE	10224	1	Gets/Sets a value that defines the function of the acquired numeric input 5 = Positive Limit 6 = Negative Limit

Software limit switch:

c. If the software limit switch is used, the FB284 function block needs to be input to ConfigEPos. %X 2 set to 1,

Activate the software limit function.

d. Set the negative soft limit position and the positive soft limit position in the drive, as shown in the following table by Varcom

Parameter name:	Parameter number	Index number	DESCRIPTION
POSLIMNEG	20125	0	Minimum position of software limit Unit:LU
POSLIMPOS	20125	1	Maximum position of software limit Unit:LU

Set the zero return position directly

This mode of operation allows the axis to be set to zero position when the axis is in any position.

Access Requirements

Run mode selection ModePos = 5

The shaft can be in an enabled state, but it must be in a quiescent state when in execution mode

Set the zero position of the axis through the rising edge of the ExecuteMode when the axis is stationary

Multi-segment position

This block operation mode allows the creation of automatic running motion tasks, running to a fixed file block (clamping), setting and resetting the output and other functions. The use of the multi-session position mode needs to be pre-set in the drive and invoked in the TIA Portal. Specific setting parameters can be referred to PATHPOS and other parameters in the Varcom manual of the high-tron drive.

Parameter name:	Parameter number	Index number	DESCRIPTION
PATHPOS	10774	0-15	<p>Index x for position x</p> <p>Gets or sets the location command saved in drive memory. It contains up to 16 position commands and can be followed by position instructions determined by the Position in the EPOs module</p> <p>Unit:LU</p>
PATHSPEED	10775	0-15	<p>Index x represents the xth speed</p> <p>Gets or sets the motion speed of the corresponding path</p> <p>Unit:LU/s</p>
PATHACC	10776	0-15	<p>Index x represents the xth acceleration</p> <p>Gets or sets the motion acceleration of the corresponding path</p> <p>Unit:LU/s²</p>
PATHDEC	10777	0-15	<p>Index x represents the xth deceleration</p> <p>Gets or sets the corresponding path motion deceleration</p> <p>Unit:LU/s²</p>
PATHCTRL	10778	0-15	<p>Index x for path x</p> <p>Gets or sets the behavior of the executed path</p> <p><g id="Bold">Institution:</g></p>

Access Requirements

Run mode selection ModePos = 6

Axis EnableAxis = 1

Axis is currently at rest

Axis must be zeroed back or absolute value encoder corrected

The operating mode, target position and dynamic response have been set in the driver run segment parameters, and the OverV parameter of the speed is scaled as a percentage of the speed setpoint in the block

Operating conditions CancelTraversing and IntermediateStop must be set to 1, Jog1 and Jog2 must be set to 0

The program block number is set in the input parameter Position, and the value should be 0 to 15

The direction of the movement is determined by the working mode and the settings in the procedure, regardless of the Positive and Negative parameters, they must be set to 0

Jog

Jogging at specified speed

Movement mode selection ModePos = 7, through JOG1 and JOG2 to make the motor move according to the speed setpoints of JOGSPD1 and JOGSPD2, respectively. The parameter numbers of JOGSPD1 and JOGSPD2 are shown in the following table and can be set through the SinaParaS function block.

Parameter name:	Parameter number	Index number	DESCRIPTION
PNJOGSPD1	10768	0	<p>The jog speed of JOG1 with ModePos = 7 in 111 packets is defined. ACC and Dec for acceleration and deceleration</p> <p>Unit:LU/s</p>
PNJOGSPD2	10769	0	<p>The jog speed of JOG2 with ModePos = 7 in 111 packets is defined. ACC and Dec for acceleration and deceleration</p> <p>Unit:LU/s</p>

Parameter name:	Parameter number	Index number	DESCRIPTION
PNJOGPOS1	10770	0	<p>The jog position of JOG1 with ModePos = 8 in 111 packets is defined. PNJOGSPD1 is its movement speed, ACC and Dec are its acceleration and deceleration</p> <p>Unit:LU</p>
PNJOGPOS2	10771	0	<p>The jog position of JOG2 with ModePos = 8 in 111 packets is defined. PNJOGSPD2 is its movement speed, ACC and Dec are its acceleration and deceleration</p> <p>Unit:LU</p>

Access Requirements

Run mode selection ModePos = 7

Axis EnableAxis = 1

Shaft is at rest

The axis does not have to go back to zero or the absolute value encoder can be in an uncorrected state

Jog speed is set in the drive and the OverV parameter of the speed is scaled by percentage for the jog speed setpoint

The operating conditions CancelTraversing and IntermediateStop are independent of the inching operation mode, the default setting is 1

Jog at specified distance

Movement mode selection ModePos = 8, make the motor move according to the distance specified by JOGSPD1 JOGPOS1 through JOG1, and make the motor move according to JOGSPD2 JOGPOS2 through JOG2. The parameter numbers for JOGPOS1 and JOGPOS2 are shown in the table above and can be set through the SinaParaS function block.

Access Requirements

Run mode selection ModePos = 8

Axis Enable AxisEnable = 1

Shaft is at rest

The axis does not have to go back to zero or the absolute value encoder can be in an uncorrected state

The jog speed is set in the drive, and the OverV parameter of the speed is scaled by percentage for the jog speed setpoint

The operating conditions CancelTraversing and IntermediateStop are independent of the inching operation mode, the default setting is 1

Modulo Axis Modulo Mode

The use of the modal axis is realized by the [FB284] function block of the 111 packet

Access Requirements

Mode of operation ModePos = 1/2

Axis Enable AxisEnable = 1

Enable modal axis function

Parameter name:	Parameter number	Index number	DESCRIPTION
MODULOMODE	10334	0	Defines whether the modal axis function is enabled

The direction of motion and working mode of the modal axis are determined by the setting of [FB284] and are related to the Positive and Negative in the function block. See the table below for details:

Positive	Negative	DESCRIPTION
0	0	When enabling the modal axis mode, move towards the target position through the shortest path of motion
1	0	When the mode axis mode is enabled, move in the positive direction towards the target position
0	1	When the mode axis mode is enabled, move in the negative direction to the target position

9.4.8 Detailed explanation of the function of message 112

The Siemens 112 message supports the third-generation EPOs positioning control system. Its main feature is that its motion parameters such as position, velocity, acceleration, and acceleration are all represented by a 32-bit floating-point type. Use 112 packets with [FB38051] function blocks. For the specific use of 112 messages, please refer to the Siemens official 112 message documentation or contact technical support.

https://cache.industry.siemens.com/dl/files/655/109747655/att_1150813/v1/109747655_LIB_SINA_POS_TEL112_LIB_DOC_v10_en.pdf

Bus Gear Ratio Setting

In particular, it should be noted that the CDHD2S-PN-RS driver is used with the parameter unit conversion method of 112 packets. In order to facilitate the customer to set the target position in the TIA Portal or obtain position feedback, the default TIA Portal position feedback unit when using the rotary motor is, the speed unit is, and the default TIA Portal position unit when using the linear motor is, the speed unit is. Therefore, it is necessary to set the corresponding driver parameter PNUM according to the motor type. The relationship between the position feedback of the drive and the position feedback in the TIA Portal is:°/smmm/s

$$X_{\text{Drive}} \cdot \frac{\text{PNUM}}{\text{PDEN}} = X_{\text{FB}} \cdot 1000$$

Among them, is the position feedback in the driver, the unit when rotating the motor is, and the unit when rotating the linear motor. is the position feedback in the TIA Portal, the unit is when the motor is rotated, and the unit is when the linear motor is rotated. According to the above, it needs to be set when the rotary motor is used, and it needs to be set when the linear motor is used. $X_{\text{Drive}} \cdot \text{revMPITCH} \cdot X_{\text{FB}} \cdot \text{mmPNUM} = 360 \cdot 1000$, $\text{PDEN} = 1 \cdot \text{PNUM} = \text{MPITCH} \cdot 1000$, $\text{PDEN} = 1$

ModePos Feature Usage

ModePos=1~8

The ModePos = 1 ~ 8 function of 112 packets is the same as that of 111 packets. Note that when ModePos = 1, 2, 7, 8 is used, the unit settings of Positon, Velocity, Accleration, and Deceleration in the function block [FB38051] need to be referred to 4.8.1.

Encoder Calibration Mode

112 The encoder calibration function has been added to the packet, and the current position feedback can be set to ref_Corrdinate.

Access Requirements

Run mode selection ModePos = 9

Shaft is at rest

Move the axis to the desired position, set refCoordinate to the desired encoder position feedback value, and implement the setting through the rising edge of "executeMode".

10. Functional Safety

10.1 Safety Torque Shutdown (STO) Overview

Functional safety in CDHD2S-PN-RS servo drives is implemented through the Safe Torque Off (STO) function. Activating the Safe Torque Off (STO) function will cause the drive to stop supplying power to control motor movement. STO ensures that the energy generated by no torque can continue to act on the motor, and prevents the drive from accidentally starting or the motor from rotating when it remains connected to the power supply.

The advantage of STO integration using standard safety technology (using electromechanical switchgear) is that it eliminates separate components and does not require associated wiring and servicing.

In addition, the switching time of this function is shorter than the switching time of electromechanical components in traditional safety concepts.

Note: When the STO function is in effect, the STO circuit power is removed and the motor power is disabled.

The STO function is defined in the standard EN/IEC61800-5-2 and is related to uncontrolled stop that complies with the IEC60204-1 standard Category 0 Stop.

Standard EN/IEC61800-5-2 specifies functional safety requirements for adjustable velocity electric drive systems. According to the requirements of this standard, when the STO function is in effect, no power is applied to the motor to make it move.

The STO function can be used when power needs to be removed to prevent accidental start-up.

Warning: Drives with suspended loads must be equipped with an additional mechanical safety block (e.g. motor brake) because the drive cannot control the load when STO is active. If the load is not properly protected, it may cause serious personal injury.



Attention : Les entraînements soumis à des charges suspendues doivent être équipés d'un bloc de sécurité mécanique supplémentaire (ex : frein moteur), car l'entraînement ne peut pas maîtriser la charge lorsque la fonction STO est activée. Si la charge n'est pas correctement protégée, cela peut entraîner des blessures corporelles graves.

The STO function in CDHD2S-PN-RS removes the power provided by the power module gate drive, suppressing the PWM pulses generated by driving IGBT, as shown in the figure below.

10.2 STO Module in Servo Drive

At present, there are many types of STO modules used in different CDHD2S-PN-RS servo drives:

- STO_A3, STO_A4 and STO_A5 only generate the positive power supply voltage for the gate drive.

- STO_B generates both positive and negative supply voltages for the gate drive.

Table 10-1

Product series	Dimensions	Input voltage	Nominal output current	STO circuit	STO compliance
CDHD2S	2A	AC 120/240V	1.5A, 3A	STO_A3	Yes*
CDHD2S	2B	AC 120/240V	4.5A, 6A	STO_A3	Yes*




Figure 10-1 STO circuit wiring

10.3 STO system requirements

STO power supply

To avoid excessive voltage levels at the STO input, safety-related parts must use low voltage.

A 24V power supply must be used. The power supply device must comply with the PELV/SELV requirements stipulated in the EN60204-1 standard *Safety of machinery — Electrical equipment of machines Part 1: General requirements*.

Note: The built-in 24V DC power supply of the CDHD2S-PN-RS is not approved for safety applications and is therefore prohibited from being used as an STO power supply.

STO cable

According to the EN61326-3-1 standard, the STO cable length must be less than 30 meters.

Shielded and double insulated cable must be used. Double insulation refers to the need for cable sleeves on supply wires. Cable sheathing must be connected to the power ground.

The optimal size of cable is 22AWG (0.34mm²). Since the current consumption of the STO circuit is less than 0.25A, 24AWG (0.25mm²) is also suitable.

STO cable must be spatially isolated from any source of environmental stress, whether mechanical, electrical, thermal or chemical.

10.4 Use STO

STO behavior

In accordance with the STO specifications specified in the IEC61800-5-2 standard, the STO function is specially used to provide safe stop of motion system. Triggering STO function causes the power supply of the motor control circuit to be removed, thus making the motor out of control. When STO is triggered during the motor movement, the motor shaft and its connected mechanical components slide until it stops moving by its own friction.

The immediate effect of STO is that the drive cannot provide any energy generated by torque. STO can be used in the case that the motor is planned to come to a standstill in a sufficiently short time based on load and friction, and in the application where the motor coasting and deceleration will not have any impact on safety.

The figure below shows what will happen to the motor when the STO function is active. The figure depicts that the motor is driven in constant speed mode, and when the power supply of STO circuit is removed, the motor coasting stops.

The figure shows the motor velocity according to time. The behavior of the motor when it is controlled to stop (STO function is not effective - VCMD and V trace) and coasting to stop (STO function is effective - reference trace) is compared.




Figure 10-2 Motor coasts to a stop when STO takes effect

STO indicator

STO status and diagnostic information is provided in the following ways.

Digital display

If the drive is disabled and STO is in effect (STO power is removed), a warning condition will occur and n will be normally on when the panel is in status mode (08 indicates the operation mode in this example). If the drive is enabled and STO is active (STO power is removed), a fault condition will occur and the digital display will automatically switch to fault mode.

If panel mode switches back to status mode while a fault condition still exists, the display will show Sn with n flashing (according to panel mode behavior).

Serial communication

When using serial communication (terminal), ST query returns the status report list. The state is slightly different when STO takes effect (STO power supply is removed), depending on whether the drive is enabled or disabled when STO power supply is removed.

If the drive is disabled and STO is in effect (STO power is removed), a warning condition will occur and the status report will display the warning:

Drive is not active

Drive is not ready:

No SW enabled

Warning exists:

WRN1STO signal not connected

If the drive is enabled and STO power is removed, this is a fault condition and the status report will indicate the fault.

Drive is not active

Drive is not ready:

No SW enabled

Fault exists

FLT4STO fault

Since the drive is enabled and fails, the failure recovery procedure must be performed.

Profinet

If the drive is enabled and STO power is removed, a fault condition will occur.

Object 603Fh subindex 0 provides the current error error code.

The STO fault code is 12673 (decimal).

STO event recovery

If the drive is disabled while the STO function is in effect, no recovery procedure is required. Once power is restored to STO, the drive will operate normally.

If the drive is enabled while the STO function is active, the drive will enter a fault state. Since the drive fault status is blocked, the drive cannot be enabled until the fault status is clearly cleared, so a fault recovery procedure is required.

After STO power is restored, the fault clearing command must be executed. After successful fault clearing, the drive works again. Fault clearing can be performed in any of the following ways:

- Switching drive enable: This can be done by executing the drive disable (K) command followed by the enable (EN) command, or by switching the remote enable line (REMOTE).
- In some systems, specific drive inputs are defined as alarm clearing. In such systems, the fault is cleared by switching the input.
- Execute the clear fault command (CLEARFAULTS).

If the STO fault condition no longer exists, the drive will be re-enabled.

STO is forbidden to use

When the STO function is in effect, the STO function shall not be used under the condition that external influence will cause danger (such as hanging load falling).

The STO function is explicitly prohibited in elevator applications. In these cases, additional measures (e.g. mechanical braking) are required to prevent any danger.

STO special circumstances

A short circuit between two non-adjacent IGBTs in a short period of time can cause the movement to reach 120 electrical degrees, even if STO function takes effect. The probability of such an event is extremely low, but it could still happen. However, the probability of such fault is considered negligible.

10.5 STO Maintenance

Users must perform manual testing of STO functionality at least once every three months.

The diagnostic test needs to remove the STO power supply voltage and verify that the drive is really in the STO fault state and that the movement is prohibited.

Maintenance procedures are performed as follows:

The system is set up to provide nominal STO voltage to the drive and the drive is enabled.

- The drive is in a fault state and displays an STO fault.
- The drive cannot be enabled.

2. Restore STO voltage and clear the fault. Verify that the drive is enabled.

11. Trouble shooting

11.1 Report Generator

Before contacting technical support, generate an application setup report through the report generator in ServoStudio2. The information contained in the report file will help technical support troubleshoot your issue and provide support.

In general, it is highly recommended that you generate a report every time you complete application configuration, even when the system is functioning normally.

Report generator options can be accessed in two places in ServoStudio2:

- Autotuning Wizard (last step)
- Backup and restore screen

11.2 Faults and Warnings

If the CDHD2S-PN-RS is connected to the host through the serial interface, the fault code is transmitted to the host through a text message. This message is saved in the fault history log (FLTHIST) in the non-volatile drive memory, so the fault history will not be lost when the power supply of the drive is restored.

- Warnings are not considered faults and do not disable operation. The system automatically clears the warning status when the conditions that generated the warning no longer exist.
- Faults will occur when settings or conditions may cause improper drive/motor operation and/or damage to the equipment. A fault will automatically disable the drive and display the fault status on the drive display as well as in the software interface.

The fault state of the drive is usually blocked, and the drive will not be enabled until the fault state is clearly cleared. The fault state can only be cleared when the fault condition no longer exists. This can be done in any of the following ways:

- Switch a drive for enabling. This can be accomplished by executing the drive disable command (K) and then executing the enable (EN) command or by switching the remote enable line (REMOTE).
- In some systems, specific drive inputs are defined as alarm clearing. In such systems, the fault will be cleared by switching the input.

The drive will be re-enabled when the fault condition no longer exists.

- Fatal faults. Some faults are called fatal faults because they disable nearly all drive functionality (including communications), preventing the drive from enabling. This condition is typical of internal failure faults, such as watchdog events or internal power failure. Fatal faults require technical support intervention.

Table11-1

VarCom	Description
CLEARFAULTS	Clear all blocking faults.
FLT	Return to the list of faults blocked by the drive.
FLTHIST	Return to the content of the fault buffer.
K EN	Disable drive Enable drive
READY	Indicate whether the drive is ready to be enabled.
REMOTE	Indicate the external hardware enabling input status.
ST	Return to the detailed status message of the drive.

11.3 Warning, error and fault messages

The following table shows the faults, warnings and error codes that may be displayed when operating in terminal mode.

All faults as well as many warnings are also displayed via the drive digital display. Certain conditions generate only on-screen warning messages.

11.4 Warning messages

CDHD2S-PN-RS drive warnings are reported in object 2011h.

Table 11-2 Warning codes and messages

Warning# Number	Warning message (click description for more information)
WRN1	STO
WRN2	Drive foldback warning
WRN3	Motor foldback warning Error!Referencesourcenotfound.
WRN4	Undervoltage
WRN5	Power stage over-temperature
WRN6	Motor over-temperature
WRN9	Control board over-temperature
WRN10	Require phase find The phase difference is required to initialize the commutation angle.
WRN11	PLL not synchronized The phase locked loop (PPL) is not yet synchronized (SYNCSOURCE>0).
WRN15	Hardware positive limit switch open circuit
WRN16	Hardware negative limit switch open circuit
WRN17	Hardware positive and negative limit switches open circuit
WRN18	Software forward limit switch trip
WRN19	Software negative limit switch trip
WRN20	Software limit switch trip

Warning# Number	Warning message (click description for more information)
WRN21	HIPERFACE encoder resolution mismatch The encoder resolution determined by the detected HIPERFACE device differs from the MENCRES setting currently in effect.
WRN22	Multi-turn encoder battery low voltage
WRN24	EnDat encoder resolution mismatch MENCRES does not match the encoder resolution read during initialization.
WRN25	Position feedback (PFB) backup not read PFBBACKUP data has not been received.
WRN27	Detected offset and/or gain adjustment value after SININIT
WRN32	Bus AC power cord disconnected
WRN34	Regenerative resistor overload
WRN35	SensAR: Encoder warning The drive detected a warning on SensAR.
WRN36	Real-time overload warning
WRN37	SFBTYPE1 cannot be used to simulate OPMODE
WRN38	Integrated power module over-temperature
WRN40	Online load/motor inertia ratio (LMJR) estimation active Online load/motor inertia ratio (LMJR) estimation is active.
WRN41	PDO packet does not meet expected length (too long) The PDO packet does not meet the expected length based on the PDO drawing. The packet is too long.
WRN42	RPDO data out of range RPDO data is out of range or beyond min/max limits.
WRN43	Unable to write data while drive is enabled RPDO data cannot be written while the drive is enabled.
WRN44	The command is close to the forward software limit The command is close to the negative software limit.
WRN45	The command is close to the negative software limit The command is close to the forward software limit.
WRN47	CAN communication input passive state CAN bus communication error
WRN48	Default drive configuration Drive configured to default factory settings
WRN49	Fieldbus target command lost The fieldbus controller has not sent the target command 3 times in a row.
WRN50	I2C fails to read the temperature sensor.
WRN51	BiSS-C encoder indicates internal warning
WRN52	Motor compatibility warning

Warning# Number	Warning message (click description for more information)
WRN53	Conflicting digital inputs are turned on
WRN54	Fan circuit warning Blower circuit overloaded or disconnected
WRN55	Excessive electrical noise warning System produces excessive electrical noise
WRN56	Feedback type mismatch The configured feedback type and the connected encoder do not match
WRN57	sensAR encoder over-temperature warning sensAR encoder over-temperature warning
WRN58	sensAR encoder built-in flash memory failure sensAR built-in flash memory failure
WRN59	An excessively high axis shift is detected. The device has detected abnormally high axis shift
WRN60	Gantry paired axis positive limit switch The second gantry axis has reached the forward hardware or software limit switch
WRN61	Gantry paired axis negative limit switch The second gantry axis has reached the negative hardware or software limit switch
WRN62	Internal axis synchronization lost (without HMI) Internal FPGA communication synchronization problem
WRN63	Motor foldback disabled
WRN64	A connection between the controller and the drive is removed Reconnect the controller and drive
WRN65	LOAD failure parameter set to default value LOAD failure parameter set to default value
WRN66	Inter-drive communication warning There is a synchronization loss or timeout error at the inter-drive communication layer
WRN67	Too many communication errors Too many consecutive errors, check errors , or timeout errors
WRN68	Gantry does not receive PFB reply from partner axis The axis sends position feedback data to the partner axis, but the partner axis does not acknowledge receipt.
WRN69	Multi-turn encoder battery voltage low During the secondary feedback, the battery voltage is close to the fault level. Replace the battery as soon as possible.
WRN70	Knusergain switch threshold configured incorrectly Knusergain switch threshold configured incorrectly

Warning# Number	Warning message (click description for more information)
WRN71	Scroll display EnDat encoder flipped
WRN72	Invalid VBUSREADOUT In CDHD2-LV, VBUSREADOUT will be equal to VBUS when customerid =
WRN73	Homing is not completed, PEINPOS is too low When homing in gantry mode, the drive waits to settle to zero. When the unit is a degree or lower resolution, corresponding configuration must be performed.
WRN74	Automatic activation of fault triggering function error after power-on Automatic activation of fault triggering function error after power-on
WRN75	PROFINET master requests drive flashing PROFINET master requests drive flashing
WRN76	Self-test failed Self-test failed

11.4.1 Error messages - manufacturers only

Table 11-3 Error codes and messages - manufacturers only

Warning# Number	Error message	Digital display	Error code
ERR20	Unknown command	E0020	08000000h
ERR21	Unknown variable	E0021	08000000h
ERR22	Checksum error	E0022	08000000h
ERR23	Drive activated	E0023	08000000h
ERR24	Drive deactivated	E0024	08000000h
ERR25	Value out of range	E0025	06090030h
ERR26	Value too low	E0026	06090032h
ERR27	Invalid OPMODE	E0027	08000000h
ERR28	Syntax error	E0028	08000000h
ERR29	Value is too high	E0029	06090031h
ERR36	Not programmable	E0036	06010002h
ERR37	Not configured	E0037	08000000h
ERR38	Not applicable	E0038	08000000h
ERR42	Invalid flash memory	E0042	06060000h
ERR43	Record active	E0043	08000000h
ERR44	Recording data is not available	E0044	08000000h
ERR45	NVRAM clear	E0045	08000000h
ERR46	Value must be even	E0046	08000000h
ERR49	Value must be a multiple of 0.25	E0049	08000000h
ERR50	Save to flash memory failed	E0050	08000000h

Warning# Number	Error message	Digital display	Error code
ERR51	Not applicable	E0051	06060000h
ERR54	Direction limit switch command	E0054	08000000h
ERR55	Homing mode active	3005S	08000000h
ERR60	Motor is running	30090	08000000h
ERR62	Communication error	3009Z	08000000h
ERR63	EnDat is not ready	3009c	08000000h
ERR64	EnDatCRC error	3009v	08000000h
ERR65	EnDat busy	3009S	08000000h
ERR66	Password protection	30099	08000000h
ERR67	TM failed to write to EEPROM	3009L	06060000h
ERR68	TM communication CRC failed	30098	05040004h
ERR71	Homing type is not used	300LL	08000000h
ERR72	Invalid homing type	300LZ	08000000h
ERR73	Homing trigger input source is not set	300Lc	08000000h
ERR74	Homing in progress	300Lv	08000000h
ERR75	Homing direction - inverse input is not set. Please refer to CiA402.	300LS	08000000h
ERR82	Function is defined	3008Z	08000000h
ERR94	Command exceeds software limit	3006v	08000000h
ERR95	Invalid feedback	3006S	08000000h
ERR96	Variable is not recordable.	30069	08000000h
ERR97	Value must be an integer	3006L	08000000h
ERR98	Input/output is not supported.	30068	08000000h
ERR99	Active disable in progress	30066	08000000h
ERR100	I2C bus busy	30L00	08000000h
ERR102	Other programs are running	30L0Z	08000000h
ERR103	Clear faults before executing the program	30L0c	08000000h
ERR104	Movement pending	30L0v	08000000h
ERR105	Invalid PTP mode	30L0S	08000000h
ERR106	Invalid checksum	30L09	08000000h
ERR107	Invalid analog output mode	30L0L	08000000h
ERR108	Keep mode active	30L08	08000000h
ERR109	Invalid motor commutation type	30L06	08000000h
ERR113	HC actual velocity out of range	30LLc	08000000h
ERR114	This hardware does not support	30LLv	08000000h
ERR115	Value must be a multiple of 0.125	30LLS	08000000h
ERR116	Fieldbus mode (COMMODE=1) active	30LL9	08000000h

Warning# Number	Error message	Digital display	Error code
ERR201	Current loop design failed	30Z0L	08000000h
ERR202	MENCRES out of range	30Z0Z	08000000h
ERR204	MSPEED out of range	30Z0v	08000000h
ERR206	MVANGLF out of range	30Z09	08000000h
ERR210	VLIM out of range	30ZL0	08000000h
ERR212	MVANGLH out of range	30ZLZ	08000000h
ERR213	DICONT is greater than DIPEAK	30ZLc	08000000h
ERR214	MENCTYPE does not match	30ZLv	08000000h
ERR215	DIPEAK out of range	30ZLS	08000000h
ERR216	MIPEAK out of range	30ZL9	08000000h
ERR217	MICONT is greater than MIPEAK	30ZLL	08000000h
ERR218	VBUS out of range	30ZL8	08000000h
ERR219	ML out of scope	30ZL6	08000000h
ERR220	MPOLES out of range	30ZZ0	08000000h
ERR221	Velocity loop design failed	30ZZL	08000000h
ERR222	Built-in dual gain exists	30ZZZ	08000000h
ERR223	Require PHASEFIND	30ZZc	08000000h
ERR224	The value is not allowed	30ZZv	06090030h
ERR225	Built-in dual gain does not exist	30ZZS	08000000h
ERR226	MENCTYPE is not valid for linear motors	30ZZ9	08000000h
ERR227	ENCOUTRES*VLIM too high	30ZZL	08000000h
ERR228	Function is not valid for this input	30ZZ8	08000000h
ERR229	MJ out of range	30ZZ6	08000000h
ERR230	MMASS out of range	30Zc0	08000000h
ERR232	Autotuning active	30ZcZ	08000000h
ERR233	Internal configuration failed	30Zcc	08000000h
ERR234	Feedback type mismatch	30Zcv	08000000h
ERR250	Velocity configuration failed	30ZS0	08000000h
ERR254	Cycle recognition active	30ZSv	08000000h
ERR255	Phase find mode is invalid	30ZSS	08000000h
ERR256	Feedback device disconnected	30ZS9	08000000h
ERR257	Feedback device initialization	30ZSL	08000000h
ERR260	No input assigned to touch probe	30Z90	08000000h
ERR261	COMMERRVTHRESH exceeds VLIM	30Z9L	08000000h
ERR263	SensAR: Device is busy	30Z9c	08000000h
ERR264	SensAR: Request time out	30Z9v	08000000h
ERR265	SensAR: Flash save failed	30Z9S	08000000h

Warning# Number	Error message	Digital display	Error code
ERR266	SensAR: protocol error	30Z99	08000000h
ERR267	SensAR: Illegal request	30Z9L	08000000h
ERR268	SensAR: inconsistent addresses	30Z98	08000000h
ERR269	Unable to read motor nameplate data	30Z96	08000000h
ERR270	Unable to set when MTPMODE>0	30ZL0	08000000h
ERR271	Unable to set when COMMODO>0	30ZLL	08000000h
ERR272	POSCONTROLMODE is not supported	30ZLZ	08000000h
ERR274	Unable to publish when SFBMODE>0	30ZLv	08000000h
ERR275	HDTUNE profile is not trapezoidal	30ZLS	08000000h
ERR276	This feedback is not supported	30ZL9	08000000h
ERR277	Feedback returns too much data	30ZLL	08000000h
ERR278	Invalid HDTUNEAVMODE	30ZL8	08000000h
ERR279	SensAR: internal requirement error	30ZL6	08000000h
ERR280	SensAR drive occupied	30Z80	08000000h
ERR281	SensAR drive fault	30Z8L	08000000h
ERR282	SensAR drive acquisition timeout	30Z8Z	08000000h
ERR283	The drive does not home	30Z8c	08000000h
ERR284	SensAR address out of range	30Z8v	08000000h
ERR285	SensARCRC error occurs	30Z8S	08000000h
ERR286	Autotuning activation failed	30Z89	08000000h
ERR287	Homing failed. If ILIM=0, it cannot be homed.	30Z8L	08000000h
ERR288	Communication feedback default value not defined	30Z88	08000000h
ERR289	Feedback memory is not partitioned	30Z86	08000000h
ERR290	Cannot be changed in modulo mode	30Z60	08000000h
ERR291	EnDat stamp value does not match	30Z6L	08000000h
ERR292	EnDat2.X is not supported	30Z6Z	08000000h
ERR293	MENCRES of this drive is too high	30Z6c	08000000h
ERR294	HDTUNEVcruise too low	30Z6v	08000000h
ERR295	HDTUNE distance is not equal	30Z6S	08000000h
ERR296	Flash memory failed to store data	30Z69	08000000h
ERR297	Flash memory failed to read data.	30Z6L	08000000h
ERR298	CANopen internal error	30Z68	08000000h
ERR299	CANopen: object index not found	30Z66	06020000h
ERR300	CANopen: object subindex not found	30c00	06090011h
ERR301	CANopen: wrong object size	30c0L	06070010h
ERR302	CANopen: drive NMT status error	30c0Z	08000000h
ERR303	SFBMODE nonlinearity is not supported	30c0c	08000000h

Warning# Number	Error message	Digital display	Error code
ERR304	Use different signs for positive and negative directions	30c0v	08000000h
ERR305	Use the same sign for positive and negative directions	30c0S	08000000h
ERR306	PHASEFINDMODE=4 (old KCMODE)	30c09	08000000h
ERR307	CANopen: unable to transmit data	30c0L	08000020h
ERR308	Positive limit switch active	30c08	08000000h
ERR309	Negative limit switch active	30c06	08000000h
ERR310	Homing switch is in the reverse state	30cL0	08000000h
ERR311	Movement suddenly stops	30cLL	08000000h
ERR312	BiSS-C: address out of range	30cLZ	08000000h
ERR313	BiSS-C: device busy	30cLc	08000000h
ERR314	BiSS-C: illegal request	30cLv	08000000h
ERR315	BiSS-C: EEPROM save failed	30cLS	08000000h
ERR316	BiSS-C: busy timeout	30cL9	08000000h
ERR317	BiSS-C: internal error	30cLL	08000000h
ERR318	BiSS-C: protocol error	30cL8	08000000h
ERR319	BiSS-C: drive error	30cL6	08000000h
ERR320	BiSS-C: drive acquisition timeout	30cZ0	08000000h
ERR321	BiSS-C: drive occupied	30cZL	08000000h
ERR322	BiSS-C: error in requesting CRC	30cZZ	08000001h
ERR324	HIPERFACE data error. Use HSAVE1.	30cZv	08000000h
ERR325	Predefined and automatic settings	30cZS	08000000h
ERR326	DDHD not allowed	30cZ9	08000000h
ERR328	COMMODE=1 no serial enabled	30cZ8	08000050h
ERR329	Specific user ID command	30cZ6	08000050h
ERR330	VLM is smaller than VCRUISE	30cc0	0x08000000
ERR331	Total cycle time is greater than 1 second	30ccL	0x08000000
ERR332	Motor parameter estimation active	30ccZ	0x08000000
ERR333	Pulse and direction modes do not allow unidirectional	30ccc	0x08000000
ERR334	DECSTOP is less than autotuning acceleration	30ccv	0x08000000
ERR335	Cannot be changed when PCOM is enabled	30ccS	0x08000000
ERR336	PCOM output not configured	30cc9	0x08000000
ERR337	PCOM cycle data error	30ccL	0x08000000
ERR338	Exceeding PCOM output frequency	30cc8	0x08000000
ERR339	PCOM motor runs during initialization	30cc6	0x08000000
ERR340	PCOM table order wrong	30cv0	0x08000000
ERR341	PCOM feedback is invalid	30cvL	0x08000000
ERR342	PCOM drive does not home	30cvZ	0x08000000

Warning# Number	Error message	Digital display	Error code
ERR343	PCOM type does not exist	30cvc	0x08000000
ERR344	PCOM output mode is undefined	30cvv	0x08000000
ERR345	Dual loop invalid VELCONTROLMODE	30cvS	0x08000000
ERR346	Dual loop invalid ENCOUTMODE	30cv9	0x08000000
ERR347	Dual loop invalid GEARMODE	30cvL	0x08000000
ERR348	Dual loop invalid POSCONTROLMODE	30cv8	0x08000000
ERR349	Invalid SFBTYPE-SFBMODE combination	30cv6	0x08000000
ERR350	MOVESMOOTHAVG128 maximum	30cS0	0x08000000
ERR351	FOE is in progress. Value not allowed.	30cSL	0x08000000
ERR352	Drive not set to correct gantry mode	30cSZ	08000000h
ERR353	Gantry system misaligned	30cSc	08000000h
ERR354	The requested operation mode is not available in gantry mode	30cSv	08000000h
ERR355	Gantry clear fault program active	30cSS	08000000h
ERR356	Gantry system is not ready for activation	30cS9	08000000h
ERR357	Gantry alignment program active	30cSL	08000000h
ERR358	Operation is not allowed when gantry differential controller PEMAX=0	30cS8	08000000h
ERR359	Reject location command based on GANTRYCMDTYPE	30cS6	08000000h
ERR360	Rigid gantry differential controller must use HOMETYPE35	30c90	08000000h
ERR361	Gantry paired axis trips the limit switch	30c9L	08000000h
ERR362	PCOM error from last cycle	30c9Z	08000000h
ERR363	PCOM counter is reset	30c9c	08000000h
ERR364	PCOM types cannot be allocated as PDO	30c9v	08000000h
ERR365	The PCOM time base is not available when the position base is active	30c9S	08000000h
ERR366	The PCOM position base is unavailable when the time base is active	30c99	08000000h
ERR367	Linear control is not supported	30c9L	08000000h
ERR368	Not available in DDHD2CAN when gantry mode is active	30c98	08000000h
ERR369	GANTRYMODE and SFBMODE cannot be configured at the same time	30c96	08000000h
ERR370	PCOMTM value exceeds limit	30cL0	08000000h
ERR371	Recognition process active	30cLL	08000000h
ERR372	Function is not valid for this output	30cLZ	08000000h
ERR373	Gantry system does not home	30cLc	08000000h
ERR374	Error correction enabling requirements are not allowed to be modified.	30cLv	08000000h

11.4.2 Fault messages

Table 11-4 Fault codes and messages

Fault# Number	Fault message (Click the description for more information)	Digital Display	Emergency (fault) Error code
FLT1	Drive locking	b	8180h
FLT2	Parameter memory checksum failed	E	5585h
FLT3	Overcurrent	P	2214h
FLT4	STO fault	n	3181h
FLT5	FPGA configuration failed	E101	6581h
FLT6	Control EEPROM fault	E106	5581h
FLT7	Power supply EEPROM fault	E107	5530h
FLT8	Vbus measurement circuit failed	E108	3182h
FLT9	Overvoltage	o	3110h
FLT10	Power stage over-temperature	t1	4310h
FLT11	Undervoltage	u0	3120h
FLT12	Not configured	-1	6381h
FLT13	Writing to flash memory failed	E	5586h
FLT14	Exceeding the velocity limit	J	8481h
FLT15	Encoder simulation frequency is too high	r9	7387h
FLT16	Drive foldback	F1	2311h
FLT17	Motor foldback	F2	2310h
FLT18	A/B disconnection	r4	7383h
FLT19	Invalid Hall	r6	7384h
FLT20	Index disconnected	r5	7111h
FLT21	Sine feedback communication failed	r10	738Eh
FLT22	A/B out of range	r8	738Fh
FLT23	Motor over-temperature	H	4410h
FLT24	Sine encoder quadrature fault	r14	7391h
FLT25	Sine/cosine calibration is invalid	r15	7392h
FLT26	Feedback 5V overcurrent	r16	7393h
FLT27	Secondary feedback index disconnected	r17	7180h
FLT28	Secondary feedback A/B line disconnected	r18	7181h
FLT29	Regenerative overcurrent	n1	3180h
FLT30	Field bus velocity overrun	Fb1	6380h
FLT31	Secondary encoder 5V overcurrent	r19	2189h
FLT32	CAN power supply fault	A4	5582h
FLT33	Self-test failed	e105	5583h

Fault# Number	Fault message (Click the description for more information)	Digital Display	Emergency (fault) Error code
FLT34	Feedback communication error	r20	7380h
FLT35	Nikon encoder operation fault	r21	7381h
FLT36	+15V out of range	o15	5111h
FLT37	-15V out of range	o-15	5111h
FLT38	Watchdog fault	≡	—
FLT39	Integrated power module over-temperature	t2	4080h
FLT40	Control board over-temperature	t3	4081h
FLT41	Phase find failed	r23	7082h
FLT42	Tamagawa initialization failed	r24	7382h
FLT43	Current sensor offset is invalid	e109	2380h
FLT44	Motor setup failed	-5	7081h
FLT45	Exceeding the maximum position error	J1	8611h
FLT46	Pulse and direction input lines disconnected	r25	7182h
FLT47	FPGA version mismatch	e120	7090h
FLT48	PLL (Phase Locked Loop) synchronization failed	b1	7386h
FLT49	Tamagawa Abs operation fault	r26	7388h
FLT50	CAN heartbeat lost	C1	8130h
FLT51	Motor phase disconnection	r27	2381h
FLT52	5V out of range	o5	5180h
FLT55	Resolver initialization failed	r28	7394h
FLT56	Absolute multi-turn encoder battery low voltage fault	r29	7385h
FLT57	Issuing an emergency stop	n3	7091h
FLT58	Endat2X feedback fault	r32	7395h
FLT59	Stall fault	F3	7121h
FLT60	Position feedback (PFB) off checksum Invalid	r34	FF8Dh
FLT61	Position feedback (PFB) off data mismatch	r35	FF8Eh
FLT62	No position feedback (PFB) off data	r36	FF8Fh
FLT63	Dynamic brake open circuit load	n41	7112h
FLT64	Power brake short circuit	n42	7113h
FLT65	Fieldbus cable disconnected	Fb3	7580h
FLT66	Command exceeds acceleration/deceleration limit	Fb2	7581h
FLT67	Exceeding the maximum position error	J2	8482h
FLT68	Encoder phase error	r37	738Bh
FLT69	Fieldbus target command lost	Fb4	7582h
FLT70	Internal error	E121	FF01h
FLT71	Differential Hall line disconnected	r38	738Ah

Fault# Number	Fault message (Click the description for more information)	Digital Display	Emergency (fault) Error code
FLT72	Logical AC power fault	o6	—
FLT73	Temperature sensor fault	t4	4096h
FLT76	Pulse train frequency too high	F2H	FF97h
FLT77	Communication error (motor out of control) condition detected	J4	7198h
FLT78	Bus AC power cord disconnected	o7	3183h
FLT80	AB positive switching direction fault	r39	738Ch
FLT82	sensAR encoder fault	r40	738Dh
FLT83	Regenerative resistor overload	o8	3199h
FLT85	Motor board read failed	E123	FF02h
FLT86	Need to save and restart	E124	FF03h
FLT87	High PE value	J3	8689h
FLT88	CAN is in bus off state	Fb7	—
FLT89	Real-time overload fault	—	FF04h
FLT90	Secondary feedback position mismatch	J5	8688h
FLT91	EtherCAT packet loss	Fb8	818Dh
FLT92	CAN/EtherCAT status not working	Fb9	F080h
FLT93	Fieldbus version mismatch	E125	7093h
FLT94	ESI version mismatch	E126	7094h
FLT95	Internal fault of self-defined absolute encoder	r33	7389h
FLT96	Digital output overcurrent detected	E127	2382h
FLT98	Power brake fault	n45	718Fh
FLT99	Sankyo absolute encoder fault	r41	7390h
FLT100	Unstable current loop	P2	8380h
FLT102	BiSS-C encoder indicates internal fault	r42	7097h
FLT103	HIPERFACE encoder data error	r43	7098h
FLT104	High IQ current detected	P3	8381h
FLT105	Digital output overcurrent fault	o9	2382h
FLT106	Feedback type automatic detection failed	E129	7396h
FLT107	EnDat high resolution fault	E130	7397h
FLT108	MOTORNAME/Electronic Motor Nameplate (MTP) data mismatch	E131	FF14h
FLT109	This drive model does not support drive firmware.	E132	FF16h
FLT110	ESI supplier mismatch	E134	7099h
FLT111	MENCZPOS does not match Hall	r45	70A0h
FLT112	sensAR encoder position fault	r46	7398h

Fault# Number	Fault message (Click the description for more information)	Digital Display	Emergency (fault) Error code
FLT113	sensAR over-temperature fault	r47	4380h
FLT114	sensAR working power supply is insufficient	r48	3184h
FLT115	sensAR battery voltage is below threshold	r49	3185h
FLT116	sensAR requires a configuration command.	r50	7399h
FLT117	Internal position synchronization failed.	r51	3186h
FLT118	General fault of multi-turn encoder	r52	3187h
FLT119	sensAR firmware does not match sensAR hardware	r53	FF15h
FLT120	Fieldbus interpolation cycle exceeds synchronization time	Fb12	7583h
FLT121	Secondary feedback communication error	r22	7380h
FLT122	Received object index exceeds object array size	Fb13	—
FLT129	Gantry differential axis fault (active disabled)	G1	FF98h
FLT130	Gantry differential axis fault (inactive disabled)	G2	FF99h
FLT131	Drive internal communication fault	G3	FF9Ah
FLT132	Gantry alignment process failed	G4	FF9Bh
FLT133	Gantry differential controller saturation	G5	FF9Ch
FLT134	The gantry cannot receive position feedback confirmation from the paired axis	G6	FF9Dh
FLT135	Gantry FIFO buffer higher than expected	G7	FF9Eh
FLT136	Too many communication errors	G8	FF9Fh
FLT137	Gantry high communication error rate	G9	FFA0h
FLT138	The gantry cannot receive the zero offset confirmation of the paired axis.	G10	FFA1h
FLT139	Gantry paired axis is not enabled	G11	FFA2h
FLT140	Gantry paired axis reports fault	G12	FFA3h
FLT141	Gantry homing failed	G13	FFA4h
FLT143	Drive parameters set to default values	e110	—
FLT144	Gantry enable failed	G15	FFA6h
FLT145	Maximum position error exceeding motor load	J10	8612h
FLT146	Positive limit switch is activated	L1	FF10h
FLT147	Negative limit switch is activated	L2	FF11h
FLT148	Current exceeds trigger limit	e135	709Ah
FLT149	Turn off the drive and change the motor phase	-6	7083h
FLT154	Gantry fieldbus disable failed	G16	FFA7h
FLT155	Multi-turn secondary encoder battery voltage is low	r54	739Ah

Fault# Number	Fault message (Click the description for more information)	Digital Display	Emergency (fault) Error code
FLT156	Tamagawa second feedback Abs operation fault	r55	7388h
FLT157	Serial communication timeout	r56	—
FLT158	PLC has stopped or disconnected	Pn1	1C34h
FLT159	Synchronous communication signal timeout	Pn2	1C35h
FLT160	Fieldbus slave chip timeout	FbA	1C36h

11.5 Fieldbus status-LED

11.5.1 Status LED - PROFINET

Interfaces C5 and C6 (PN models) each have two LED lights that indicate the status of the fieldbus when communicating on the Profinet network.




Figure 10-1 Top panel interfaces and LEDs on the Profinet model

Table 11-5

Green light	Flashing - communication activity
	Off - no communication activity
Orange light	Normally on - working (OP) status
	Slow flash - SAFEOP status
	Fast flash - preparation (PREOP) status
	Super fast flash - boot program (BOOT) status
	Off - initial (INIT) state

11.5.2 Status LED - PROFINET

Interfaces C5 and C6 (PN models) each have two LED lights that indicate the status of the fieldbus when communicating on the PROFINET network.




Figure 10-2 Top panel interfaces and LEDs on the PROFINET model

Table 11-6

Green light	Normally on - communication activity
	Off - no communication activity
Yellow light	Normally on - port is connected
	Off - no connection to the port



致力于成为自动化设备领域的 核心综合解决方案提供商

DEVOTING TO BEING A CORE COMPREHENSIVE SOLUTION PROVIDER
IN THE FIELD OF INDUSTRIAL AUTOMATION EQUIPMENT

高创传动科技开发有限公司
Servotronix Motion Control Ltd.

Address: 13B01, Block B, Kelu Building, Nanshan District, Shenzhen, China

Tel: 400-111-8669

Website: www.servotronix.cn